

521
/DEVELOPMENT OF DATA ACQUISITION AND CONTROL
FACILITIES FOR THE OPTIMIZATION OF
DRIVE LINE EFFICIENCY/

by

KENT DOUGLAS FUNK

B.S., KANSAS STATE UNIVERSITY, 1984

A THESIS

submitted in partial fulfillment of the
requirements for the degree


MASTER OF SCIENCE

Department of Mechanical Engineering

KANSAS STATE UNIVERSITY
Manhattan, Kansas

1986

Approved by:


Major Professor

LD
2668
.T4
1986
F86
C.2

AL1206 799894

PREFACE

The development of data acquisition and control facilities for the optimization of drive line efficiency has been a great challenge to my abilities. Although difficult, this work has allowed me to further develop my skills as both a programmer and an electronic hardware designer. Considerable personal satisfaction has been achieved by transforming the concepts discussed during project meetings into reality. I wish to thank all the individuals who have helped me to make this project a success. In addition, a number of groups and individuals deserve special credits.

Thanks are extended to Caterpillar Tractor Company, Peoria IL, and Funk Manufacturing Company, Coffeyville KS, for their generous equipment donations. Likewise, thanks are also extended to the Kansas Department of Economic Development for providing matching funds to these equipment grants.

For their time and support, thanks go to the members of my graduate committee, Dr. Mark Schrock, Dr. Stanley Clark, and Dr. Ralph Turnquist. A special thanks goes to Dr. Garth Thompson, my major advisor, for allowing me a great deal of freedom in this work. His confidence and support are greatly appreciated.

Thanks also go to Mr. Mike Schwartz for his expertise in software design. Finally, thanks go to my wife, Tara, for her patience, support, and understanding.

TABLE OF CONTENTS

Chapter	Page
I. INTRODUCTION	1
Literature Review	1
Project Overview	4
Purpose Statement	6
II. COMPUTER ORGANIZATION	7
Project Needs	7
Division of Responsibility	9
III. ADAC 1000	10
System Evaluation	10
Multi-Process Approach	11
Task Process Structure	14
IV. MC68000ECB	20
System Overview	20
Hardware Details	24
Optical Isolation	27
Interfacing Stepper Motors	29
Software Details	33
SUMMARY	41
REFERENCES	43
Appendix	
A. DRIVE LINE PARAMETERS	45
B. ADAC 1000 SUPERVISOR SOFTWARE LISTINGS	51
C. MC68000ECB HARDWARE	92
D. MC68000ECB SOFTWARE LISTINGS	109
E. AOAC 1000 HOST DEVELOPMENT SOFTWARE LISTINGS	156
F. OATA SHEETS	165

LIST OF TABLES

Table	Page
1. MC68000ECB User Memory Allocation	40
2. Temperature Conversions	50
3. Bus Expansion Buffer: Parts List	95
4. I/O Expansion: Parts List	97
5. High Current Outputs: Parts List	104

LIST OF FIGURES

Figure	Page
1. Multi-Process Relationships	13
2. Task Process Structure	16
3. Hardware Configuration	21
4. Software Structure	22
5. Typical Isolated Output	27
6. Stepper Motor Driver Circuit	31
7. MC68000 Educational Computer Board	93
8. Block Diagram - Educational Computer Board	94
9. Bus Expansion Buffer: Board Layout	95
10. Bus Expansion Buffer: Schematic	96
11. I/O Expansion: Schematic	99
12. Digital Inputs: Schematic	103
13. High Current Outputs: Schematic	105

CHAPTER I

INTRODUCTION

Literature Review

Due to escalating fuel costs and increased capital costs associated with operating and owning agricultural tractors, considerable research has been conducted to improve the fuel efficiency and work rate of these units. The primary focus of this research has been to accurately define field load variations and to optimize engine power utilization. The potential savings from tractor performance optimization depends upon several factors; load variability, power level, engine characteristics, transmission characteristics, and tractive efficiency.

In a typical field application, the operator selects an appropriate gear ratio and throttle setting, and then allows the engine governor to compensate for load variability. The choice of gear and engine speed have traditionally been made by the operator, based upon field conditions and the type of work to be done. Recently, researchers have directed their efforts to improve the operator's decision. Meiring et. al. (1979) developed a tractor efficiency meter which determines the engine operating point in the speed and power range. By educating the operator to the characteristics of the engine speed vs. power map, the efficiency meter can be used as a valuable tool to improve both fuel consumption and productivity. Schrock et. al. (1982) developed a gear selection aid which informs the operator of an optimum gear and engine

speed for a given power demand. The average of four tests, with operators responding to instructions from the device, indicated a fuel savings of 19.8 percent compared with the operator's normal practice. There have been other similar works, but in each case the results are generally the same. Tractor efficiency can be improved by supplying the operator with additional information, and by educating the operator how to use that information.

Three limitations may be identified in past research work which will cause the optimization device to yield a non-optimal solution. The first limitation is that the operator must understand and respond to all information which is presented to him. If the operator does not understand, or if the device is continuously directing the operator to change the set point of the drive line, the device may be ignored. This problem can be avoided by automation of the drive line, thus taking the operator out of the optimization loop. Chancellor et. al. (1983) has developed a simple control device for tractor transmission ratio and governor setting so that experience could be gained in control design, operator interactions, and tractor performance. Early tests have shown good response, and work is continuing on development of a complete microprocessor based controller.

The second limitation is that the optimization device has a limited number of discrete transmission ratios from which to choose. This situation often results in a non-optimal solution. For example, the tractor may be operating at a specific gear ratio and throttle setting. First, the device examines the current state and establishes a base

point. Next, the device examines other gear ratio and throttle combinations which will produce the same power output. Due to the small number of admissible combinations which exist with conventional incremental transmissions, the device often can not improve the current combination. Obviously, the level of drive line optimization could be improved by increasing the number of admissible gear ratio and throttle setting combinations which will produce a given output power. This can be accomplished either by using a transmission with a large number of discrete ratios or a variable transmission with nearly an infinite number of ratios. One possible approach would be to use a hydrostatic unit, however, these units have a 10 to 15 percent lower efficiency than conventional gear type transmissions. These lower efficiencies would cancel much of the gain achieved by the optimization process. Another possible approach would be to use a mechanical continuously variable transmission (CVT). These transmissions have recently shown great promise due to improved reliability, durability, and efficiency. The major disadvantage of these units is that they suffer from a limited range of gear ratios, therefore, they must be cascaded with an additional discrete transmission in order to achieve the required ratio range.

The third limitation arises from an examination of the assumptions used in the development of most optimization algorithms. Generally, it has been assumed that the variation of transmission efficiency between gears is small and can be neglected in the selection of an optimum gear ratio and throttle setting. This has allowed researchers to develop algorithms based only upon engine optimization. Although this approach

often produces desirable results, extreme care must be exercised when developing algorithms which select the optimum combination from a large group of admissible gear ratios and throttle settings. Future work must move towards complete drive line optimization, rather than focusing only on the engine.

In summary of the current research work in the area of tractor performance optimization, most work has been done in the areas of defining load variability and optimization of engine efficiency. It is expected that future work will continue in the following areas.

1. Accurately define field load variations from which standard loading cycles can be developed for various field applications.
2. Develop algorithms and test devices which optimize work productivity and fuel economy over the entire tractor drive line.
3. Develop intelligent systems which adjust operating conditions based upon operator input, tractive efficiency, load variability, and other environmental conditions.

Project Overview

A joint study of Computer Control of Agricultural Tractor Drive Lines was initiated in April, 1984, between the Agricultural Engineering and Mechanical Engineering Departments at Kansas State University. The objective of this effort is to develop and test a computer control system for optimizing the performance of a diesel engine and a continuously variable transmission as applied in an agricultural tractor. The

objective of the project may be further divided into the following tasks.

1. Develop laboratory facilities for the study of drive line efficiency. This facility will include a drive line composed of a Caterpillar 3304 diesel engine, an experimental continuously variable transmission (CVT), a Funk model 2263 six speed power shift transmission, a Funk model 27 single speed planetary transmission, and a Midwest eddy current-type dynamometer. In addition, the facility will also include adequate computer facilities and instrumentation for implementation of data acquisition and control algorithms.
2. Collect and analyze data in order to determine performance relationships between control inputs and drive line outputs.
3. Develop an algorithm which will minimize fuel consumption at a specified work rate, and adequate controls in order to automate the optimization process.
4. Evaluate dynamic considerations of the control algorithm so that stable response is obtained from the controller.
5. Test and evaluate the performance of the algorithm against various loading cycles. These loading cycles will be derived from field data collected for the determination of field load variability.

This project is on-going with the test facility completed, the performance data collected, the basic optimization algorithm outlined, and the

standard loading cycles nearly completed.

Purpose Statement

The purpose of this thesis is to present the work completed on the development of computer facilities for implementation of data acquisition and control algorithms as related to the above project. These facilities consist of two separate computers; an ADAC 1000 data acquisition system based on the DEC LSI-11/23 microprocessor, and a Motorola MC68000 Educational Computer Board which is a single board computer based on the powerful MC68000 16-bit microprocessor.

CHAPTER II

COMPUTER ORGANIZATION

Project Needs

During the planning stages of the project, considerable attention was given to computer organization with respect to both data acquisition and control. Early discussions exposed three concerns. The first concern was that real time operation in data collection and control be achieved, secondly, that computer hardware should not be unnecessarily duplicated, and thirdly, that preliminary developments should not limit future work. As project discussions continued, the following list of specific needs emerged.

1. A supervisory system must be developed which has access to all data. It is the responsibility of the supervisor to insure complete system integrity. Desirable features of the supervisor are:
 - A. Periodically check all data against a set of boundary values in order to identify system abnormalities.
 - B. Provide a display of all data in an easy to read form along with appropriate warning messages.
 - C. Provide immediate system shut down in the case of catastrophic drive line failure.
2. A flexible data recording system must be developed which has access only to specific data. It is the responsibility of the data recorder to accurately measure and store data for later use in mapping the drive line and developing control algorithms. Desirable

features of the data recorder are:

- A. Accurate control over sampling rates.
 - B. Flexibility in specifying which physical parameters are to be measured and recorded.
 - C. Data recorded should be stored in a readable form to facilitate spot checking.
3. A drive line controller must be developed which implements the optimization algorithm. It is the responsibility of the controller to adjust the state of the drive line based upon decisions made by the optimization algorithm. Desirable features of the controller are:
- A. Accurate real time operation.
 - B. Control of the engine throttle position.
 - C. Control of the CVT ring position which ultimately determines the CVT gear ratio.
 - D. Control of the power shift gear ratio.
4. Additional drive line sub-system controllers must be developed as needed. These controllers should be developed and implemented independently of the drive line controller. Currently, the CVT oil temperature and the dynamometer loading pattern are the only sub-systems in need of computer control.

In order to meet these computer needs, a large amount of instrumentation has been developed to transform the physical drive line parameters into measurable signals. A complete list of parameters and their corresponding signal characteristics are presented in Appendix A. The information in Appendix A is divided into four sections; engine, CVT, power shift, and dynamometer. Each of the four main sections is further

divided into primary and secondary parameters.

Division of Responsibility

The above project needs are now divided as tasks between the two computers. The ADAC 1000 has responsibility for the supervisory functions, data recording, sub-system controls, and conversion of all analog data into digital forms. The Motorola single board computer has responsibility for drive line control and optimization. In addition, each of the computers has responsibility over digital data which is directly associated with their specific tasks.

It must be emphasized that the two computers can not work independently of each other. For example, the ADAC computer records certain digital information which only the single board computer can access. Therefore, an adequate communication link must be established between them. These links take the form of an RS-232 standard protocol, and all communication follows ASCII standards. These communications must be minimized since the inherent time delays will affect the real time operation of both computers.

In summary, this chapter has defined the project's overall computer needs, and has further grouped these needs into specific tasks for each of the two computers. In addition the need for inter-computer communications has been established and several concerns have been expressed. Chapter III will outline the work done on the ADAC 1000, and Chapter IV will present a discussion of the MC68000ECB.

CHAPTER III

ADAC 1000

System Evaluation

The ADAC 1000 data acquisition system is based upon the DEC LSI-11/23 microprocessor. It has been equipped with a 7.5 Mbyte hard disk, an 8 inch floppy disk, 256 Kbytes of RAM, and 4 serial ports. Data acquisition capabilities include 32 channels of low level analog inputs, 64 channels of high level analog inputs, 64 digital I/O ports, 4 analog output channels, and 4 pulse counters, along with a real time clock.

Soon after the division of responsibilities was made, a thorough evaluation of the ADAC 1000 was completed to determine the suitability of the system for its intended tasks. This evaluation concluded that an extensive update was in order to overcome previous reliability problems. The following modifications were made.

1. The computer enclosure was reorganized to improve access to data acquisition modules and to allow for a pressurized air circulation system. In addition, a 1 KW Tripp Lite model SB-1000a UPS was added.
2. The interface between the data acquisition modules and real world instrumentation was rebuilt. The new interface provides user access to all A/D, D/A, thermocouples, frequency, digital, and RS-232 signals. The interface also provides for custom signal

conditioning for a variety of applications.

3. The original DEC RT-11 operating system was replaced by 2.9BSD UNIX which is based on Bell Labs UNIX Version 7. In addition, all data acquisition service routines were rewritten in C, the intermediate language on which the UNIX operating system is based.

After the above modifications were made, extensive tests were conducted on both the operating system and data acquisition facilities. This work went well with few difficulties, and the complete system was ready for development of its specific tasks. Currently, the ADAC 1000 is a multi-user computing facility, which supports data acquisition capabilities, several compilers, graphics, statistical analysis, and many other 2.9BSD UNIX application programs. Since the modifications, work has proceeded with remarkable system reliability and the overall response has been excellent.

Multi-Process Approach

As outlined in chapter II, the ADAC 1000 is responsible for the supervisory functions, data recording, sub-system controls, and conversion of all analog data into digital forms. Due to the interactions between the various tasks, all of the ADAC responsibilities have been grouped together into one program. In addition, a terminal handler program has been developed which controls the communications between the real time task program and the terminal. The structure of these programs has been developed from concepts used in concurrent programming where inter-process communication is accomplished by message passing.

All together there are three processes executing under the supervision of the UNIX operating system. One of the three processes is the parent which initiates the creation of two other processes, known as children. These children are the screen and task processes. The parent also establishes all communication links between the children and itself. After successful creation of the two children and their intercommunications, the parent becomes the keyboard process. Following is a description of the relationships between the parent and the two children as shown in Figure 1, page 13.

The keyboard process accumulates input from the terminal keyboard until a full line of information has been recognized. After which, the keyboard process sends the line to the task process and informs the task process that information is waiting. In addition, the keyboard process echoes input data to the screen process one character at a time.

One of the two children is a terminal screen process. This process accepts input from the task and keyboard processes, and displays the information on a static screen. The screen process input requires x-y coordinates, attributes, data format, and data. This process does not send information back to the other processes.




Figure 1 Multi-Process Relationships

The other child is the real time task process which carries out the specific tasks assigned to the ADAC 1000. When the parent process creates the task process, the standard input (stdin) is connected to the keyboard process and the standard output (stdout) is connected to the screen process. When the task process begins execution, the first step is to initialize all connections which have not been created by the parent. The initialization consists of five items.

1. Attach the UNIX signal associated with the keyboard process to the

task process.

2. Establish necessary links to the UNIX software timer in order to schedule real time activities.
3. Establish the communication link to the MC68000ECB.
4. Attach the data acquisition and control facilities to the UNIX operating system so that physical addressing is possible.
5. Send headings and other general information to the screen process.

After the task process initialization is complete, all relationships shown in Figure 1 have been created. It should be noted that the connection between the task process and mass storage is attached and detached as needed by normal execution of the task process.

Task Process Structure

As shown in Figure 2, page 16, the task process is divided into three regions; real time, human, and MC68000. These regions all have a source of external request stimulus, a common event detection mechanism, and a request handler. The common event mechanism detects the presence of an external request and then passes control to the appropriate request handler. In addition, all three regions are bound together by a common data structure which allows the regions to influence one another. Following is a detailed discussion of each of the three regions.

The real time region consists of the software timer request, event detection, real time handler, and the common data structure. During the

Initialization of the task process, a link between the UNIX software timer and the common data structure was created. Each time the timer signal makes a request, a variable in the common data structure is changed. The event detection mechanism detects this change and passes control to the real time handler. It is the responsibility of the real time handler to schedule those tasks which require real time control. Within the real time handler, there are four real time loops.

1. The supervisory monitor loop reads all drive line parameters and compares these values to a set of boundary values. In addition, the monitor sends all parameter values along with warnings to the screen process.
2. The data recorder loop reads specific drive line parameters and stores these values in mass storage.
3. The CVT oil temperature controller loop reads the needed parameters to determine the necessary heater input control.
4. The dynamometer controller loop reads the needed parameters to determine the necessary dynamometer input control.

Each of these real time loops has a different loop time associated with them. Therefore, the real time handler must determine which loops need to be executed, if any, and passes control to those specific loops. It should be noted that the time interval of the software timer request is chosen as the greatest common factor of all four loop times.




Figure 2 Task Process Structure

The human region consists of the keyboard process request, event detection, keyboard handler, and the common data structure. During the initialization of the task process, a link between the keyboard signal and the common data structure was created. Each time the keyboard process signals the task process that data is waiting, a variable in the common data structure is changed. The event mechanism detects this

change and passes control to the keyboard handler. It is the responsibility of the keyboard handler to read the waiting line of information, interpret meaning, and execute the command.

The keyboard handler provides a powerful mechanism by which the operator can examine and modify most of the common data structure. This ability allows the operator to control the normal execution of the other two regions. Although the possibilities are almost limitless, the basic capabilities of the keyboard handler can be grouped into four areas.

1. Data Acquisition.

Through the keyboard handler the operator can deal with all data acquisition facilities. This involves channel assignments to drive line parameters, calibration of offsets and gains, and printing additional information about a particular parameter to the screen.

2. Program Control.

The keyboard handler also allows the operator to manipulate those variables in the common data structure which control program execution flow. This involves real time loop intervals, and the ability to turn specified loops on and off. In addition, parameters needed by the real time loops may be passed by the keyboard handler to the common data structure.

3. Boundary Values.

As was described earlier, the supervisory monitor periodically compares all parameter values against a set of boundary values. These boundary values are stored in the common data structure, thus

allowing the keyboard handler to access them. This allows the operator to change the boundary values during normal execution of the task process.

4. Maintenance.

The keyboard handler allows the operator to perform maintenance on the common data structure. This involves saving the entire structure on mass storage, allowing complete examination of the structure at a later time.

The program structure of the keyboard handler is much like a common interactive command line interpreter. However, all information needed to fully execute the command must be contained in a single line of information.

The MC68000 region consists of the MC68000ECB request, event detection, MC68000 handler, and the common data structure. During the initialization of the task process, a serial communications buffer was connected to the task process. Each time that the MC68000ECB makes a request or sends data, characters appear at the communications buffer. The event detection mechanism reads characters in from the buffer until a line has been recognized and then verifies the line. After the event detection mechanism receives a valid request or data, control is passed to the MC68000 handler. This method of event detection is much different than that of the other two regions. In this case the event detection mechanism must poll the communication buffer since no UNIX signal is connected to the common data structure. It should be noted

that this form of event detection represents a violation of the real time intent of the task process. Therefore, communication between the task process and MC68000ECB has been minimized.

Once control has been passed to the MC68000 handler, two possible actions can take place. If the request line contains input data, the request handler parses the line and stores the data in the common data structure. If the request line contains a request for data, the request handler reads the drive line parameters needed by the MC68000ECB and sends the data back through the serial line.

In summary, the purpose of this chapter is to give an overview of the work completed on the ADAC 1000. This work falls into two main categories; a complete system update, and development of the specific tasks. In order to implement the specific tasks, a great deal of software was needed. This software package is based upon concepts used in concurrent programming in order to preserve real time capabilities. A complete listing of the real time task process software is included in Appendix 8.

CHAPTER IV

MC68000ECB

System Overview

As outlined in chapter II, the responsibility of the MC68000ECB is to control the drive line in an optimal manner. In order to accomplish its intended tasks, the single board computer hardware has been greatly expanded. Software has also been developed to manage and test the added hardware. The purpose of this chapter is to discuss both hardware and software developments.

The MC68000ECB hardware has been expanded into a three board computer as shown in Figure 3, page 21. An enclosure has been built to provide a suitable environment for the MC68000ECB, the I/O expansion board, the high current driver board, and two power supplies. The main power supply services the MC68000ECB and the bus interface section of the I/O expansion board. The instrument power supply services the external digital inputs and the isolation section of the I/O expansion board. The high current driver board provides the connections between the driver interface section of the the I/O expansion board and the external high current digital outputs. Power for the digital outputs is provided by the engine electrical system. In addition, a number of manual switches provide control of the various power supplies. Finally, serial communications has been established between the MC68000ECB and its console, and between the MC68000ECB and the ADAC 1000.




Figure 3 Hardware Configuration

The software developed on the MC68000ECB provides the framework for all future software developments. Since the final optimization algorithm has not been completely defined, a flexible software structure has been established. As shown in Figure 4, page 22, the software package is divided into four blocks; sequential program execution, software interrupt (SWI) processing, hardware interrupt (HWI) processing, and a common data structure.




Figure 4 Software Structure

Normal sequential program execution begins by initialization of the common data structure, software and hardware interrupt vectors, and all system hardware. After the initialization sequence is complete, the entire software structure is functional. The normal program execution then enters a continuous loop. During one pass through the loop all inputs are read, the new desired drive line state is determined, and the outputs are set. In its final form, the sequential program execution block will contain the optimization algorithm. It is emphasized that normal program execution never deals directly with hardware devices. In order for sequential program execution to communicate with a hardware device, it must generate a software interrupt. The interrupt causes control to be passed to the software interrupt processing block which performs the hardware manipulation. All data transfer between the sequential program execution block and the software interrupt processing

block is accomplished through the common data structure.

The hardware interrupt processing block handles physically generated interrupts. These interrupts are non-sequential. That is, they may occur at any time without regard to the current state of the microprocessor. These interrupts may occur from the hardware timer used for real time control, an ADAC 1000 request for data, or an operator request for system shutdown. In any case, the hardware interrupt processing block contains the code to handle these specific hardware interrupts. In order to service these interrupts, it is often necessary to communicate with external hardware devices. Therefore, the hardware interrupt processing block may also generate software interrupts in a similar manner as the sequential program execution block.

The software interrupt processing block is partitioned into a number of small groups of code called device drivers or utilities. Each of these small groups has a specific software interrupt level associated with it. Whenever a software interrupt is generated, the calling block must specify a level. The level of the interrupt specifies which utility or device driver is to be executed. This technique of control transfer is similar to calling a subroutine except that the calling program does not need to know the starting address of the desired utility.

The concept of software interrupt processing is the backbone of the entire software package. This has allowed individual device drivers and utilities to be written and tested before the other two blocks were completely defined. Since nearly all of the hardware is experimental, this

modular design has also increased the speed of testing hardware and software designs. After the basic software and hardware elements were proven, the rest of the system was built upon these basic elements.

The above discussion has given a brief overview of the entire system. Both hardware and software have been discussed in order to give prospective to the entire system development. In the following two sections, greater details will be discussed.

Hardware Details

The MC68000 Educational Computer Board (ECB) is a complete single board computer. Features of the computer are:

1. A 4 megahertz MC68000 16-bit MPU. This microprocessor has a 16-bit data bus and a 24-bit address bus. The address bus provides a memory addressing range of 16 megabytes. The processor also has eight 32-bit data registers, seven 32-bit address registers, two 32-bit stack pointers, a 32-bit program counter, and a 16-bit status register.
2. 32 Kbytes of dynamic RAM. Approximately 2 Kbytes are reserved for the operating system leaving 30 Kbytes for user programs.
3. 16 Kbytes of ROM. A small operating system called TUTOR resides on read only memory. The firmware provides monitor/debug, assembly/disassembly, program entry, and simple I/O control functions.

4. Two serial communication ports. These ports are fully RS-232C compatible and have hardware selectable baud rates.
5. A parallel port. This port can be used for a standard Centronics interface or custom I/O.
6. Audio tape serial I/O port. This feature allows for program storage on a standard tape recorder.
7. A 24-bit programmable timer. This timer is a synchronous device which can be used for generating or measuring both time delays and various frequencies. The timer can be clocked with a 5-bit prescaler or directly, and the clocking source can be the 4-Mhz system clock or an external clock.
8. Wire-wrap area provided for custom circuitry.
9. RESET and ABORT function switches.

A picture of the MC68000ECB and a functional block diagram are shown in Appendix C (pages 93 and 94). Additional information on the MC68000ECB is given in the Motorola User's Manual.

The first step in expanding the MC68000ECB was to develop a standard asynchronous bus buffer. This buffer was installed in the wire wrap area on the board and provides full protection to all system data, address, and control lines which are taken off the board. Due to physical space limitations of the on board wire wrap area, only eight of the sixteen data lines are available. Otherwise, all address and control

lines are provided. This limitation is not serious since most peripherals developed for the MC68000 have an 8-bit data bus. Complete details of the buffer including parts list, board layout, and schematic are presented in Appendix C (pages 95 and 96).

Once the MC68000ECB system buses were buffered, they were extended onto a second board by a standard ribbon cable connection. The second board, called the I/O expansion board, provides access to all external devices. The bus interface section of the I/O expansion board consists of two MC68230 parallel interface/timers (PI/T) along with necessary address decoding. Each of the PI/Ts is actually two separate devices in one package. A parallel interface section provides two 8-bit external ports, and a timer section provides a 24-bit programmable timer. The driver interface and isolation section of the I/O expansion board consists of the hardware needed to provide the low current interface and high voltage isolation between the PI/Ts and the external devices. These facilities include two stepper motor drivers, two incremental encoder inputs, one absolute encoder input, and numerous single bit I/O. Complete schematics of the I/O expansion board are presented in Appendix C (pages 97 to 102). In addition, a schematic for the digital inputs is given on page 103, schematics for the high current outputs are presented on pages 104 to 108, and relevant data sheets are given in Appendix F.

The remaining hardware discussion will focus on two topics which are unique to the drive line interface. These discussions are intended to supplement the schematics in Appendix C. The first topic is optical isolation, and the second is interfacing stepper motors.

Optical Isolation

In this application, numerous external devices are connected to the I/O expansion board. Each of these devices has its own specific power supply requirements. It is important that these power supplies be separated in some way. Without separation, a failure in any one of the external branches could cause devastating damage to other devices and to the main boards. To provide complete isolation for all power supplies from each other and for all external devices from the main boards, a system of optical isolation has been developed.

Figure 5, shows a typical isolated output. The last chip in the low level board logic must have TTL Open Collector high current outputs. This allows the designer to customize the value of the pull-up resistor (R1) to the specific current requirements. The output of the open




Figure 5 Typical Isolated Output

collector drives the input to a 4N33 Opto-Isolator. This chip provides full separation of power grounds, and 7500 V isolation. The input of

the 4N33 consists of an infrared light emitting diode and the output consists of a photo darlington transistor pair. The open collector design of the output of the 4N33 allows the designer to customize the value of the pull-up resistor (R2) which drives the input to the external load. Note that the load may need to include current amplifiers.

There are a number of design considerations in the selection of the pull-up resistors. The following is the procedure used in the present design.

1. R1 is selected so that the low level output current of the TTL open collector is not exceeded. The maximum value is typically 25 milliamps, therefore, R1 must be greater than 200 ohms. A value of 220 ohms has been used in the present design.
2. R2 is selected so that the at the low level output current of the 4N33 is not exceeded. The maximum value is 50 milliamps, therefore, R2 must be greater than 100 ohms. The exact selection of the value of R2 varies with the characteristics of the load input current requirements.
3. The resistor R3 is used to improve the dynamic switching characteristics of the 4N33. This is because the diode has low input impedance and does not switch off cleanly after it has been driven on for an extended period of time. A value of 390 ohms was used in the present design. Note that if the value of R3 is too large, the forward current of the diode is diminished below the switch-on threshold.

An interesting side affect of the above circuit is that the logic is inverted. When the TTL output goes high, current is driven through the diode, turning the darlington pair on. With the transistors on, the output of the 4N33 goes low, thus turning the load off. In contrast, when the TTL output goes low, the current through R1 sinks into the TTL output, thus turning the darlington pair off. With the transistors off, the output of the 4N33 goes high, thus turning the load on.

Although the above example demonstrates the use of opto-isolation for a single output, the basic concepts of the design can be used for inputs as well. In fact, entire groups of inputs and outputs can be isolated using this technique. In the present design, every input and output is fully isolated between the I/O expansion board and the rest of the external devices.

Interfacing Stepper Motors

Two dual phase unipolar stepper motors are used on the drive line. One motor controls the engine throttle position and the other controls the CVT ring position. Each of these motors has a stepper motor driver associated with it. The two drivers are functionally identical, however, each has been fine tuned to match the dynamics of their corresponding motors.

There are many tradeoffs between hardware and software in the design of a stepper motor driver. In some systems, the stepper motor is driven with variable stepping rates in order to accelerate large loads. In other systems, a technique called micro stepping is used to improve

the accuracy of position control. In both of these cases, complete software control of the stepping sequence is required for the entire move. It is desirable, in this application, for software to play a minimal role in the process of moving the motors from one position to another. Since motor stepping rates are slow compared to the normal clocking speed of the microprocessor, constant supervision of a motor would waste valuable processing time. In addition, it would be difficult to control two motors moving at the same time using only one CPU. Therefore, a hardware system has been built and tested which requires the main control program to supply only two inputs. The program must calculate the desired number of steps and the relative direction of the move. In addition the software must enable the hardware to initiate the move. It is emphasized that the control software does not need to service the hardware at any time after the move is initiated. This allows the microprocessor to do other things while the stepper motors are moving.

Referring to Figure 6, page 31, each stepper driver consists of a timer, a clock source, a stepper driver chip, some additional logic, an optical coupler, and a high current driver section. The timer is part of the MC68230 PI/T and provides the necessary interface between the MC68000 system bus and the rest of the external hardware. The clock signal is derived from the system 1MHz system clock using decade counters. The stepper driver chip is a Motorola SAA1042 which generates the correct switching sequence logic for both full and half stepping modes. The output of the driver chip consists of four lines, one for

each coil of the stepper motor, which are first inverted and then passed through a series of 4N33 optical isolators. The outputs of the




Figure 6 Stepper Motor Driver Circuit

optical isolators drive the bases of four SK3180 NPN Darlington power transistors. These transistors switch the four motor coils to ground. The stepper motors were originally designed to be driven with 4 to 5 volts DC, however, in this application it was more suitable to use the 12 volt power supply available at the engine electrical system. To do this an external resistor was placed in series with the stepper motor. The effect of this resistor is to develop a voltage divider with the input to the motor as the center node. By adjusting the value of the external resistance, the correct current is provided through the motor. In addition, this technique has the advantage of lowering the time constant ($T = L/R$) of the motor and improving its current switching

characteristics.

The basic operation of the hardware is as follows:

1. The number of desired steps is loaded into the timer, and the relative rotational direction is established at the stepper driver logic chip.
2. The timer is started allowing the "done" signal to go high. With the "done" signal high, the "clock" signal passes through the "AND" gate. The output of the "AND" gate provides a dual function of decrementing the counter and clocking the stepper driver logic chip. Note that the timer is decremented by one count for each cycle of the "decrement" signal and the stepper driver logic advances the stepper motor one step for each cycle of its input clock.
3. The circuit continues to decrement the timer and clock the stepper driver logic until the value in the timer goes to zero or "rolls over". At this point the timer drops the "done" signal low causing the "clock" signal to be gated off. With the clock signal gated off, the stepper driver logic is effectively halted without loss of the current sequence state.

During the initial design stages of the stepper motor drivers, it was anticipated that the open loop design would provide the needed accuracy and repeatability. However, during testing, the motors would occasionally lose steps. This was because the dynamic actuator loads were

greater than first anticipated. At this point each of the actuator gear trains were modified to include an optical incremental encoder. These encoders provide the repeatability necessary for data collection and control of the motors. Note that the lack of precision in the open loop design is not caused by a problem in the stepper motor driver, but rather is due to inadequate torque capacity of the stepper motors. In a final design, the feedback encoders would not be needed.

The output of the encoders is a pair of square wave pulse trains whose phase indicates relative direction. This type of output is known as "Quadrature" output. By correct separation of the two pulse trains, a suitable up/down counter can be used to keep track of the absolute position of the encoders. In addition, some reference must be established for the "home" or zero point of the counters. Two 20-bit counters were available (Spaulding, 1985) which correctly read quadrature output. These counters were added to the I/O expansion board and require seven control lines in order to multiplex the data to an 8-bit data bus. To accommodate the requirements of these devices, an 8-bit external data bus and an 8-bit external control bus were developed using one of the two off-board PI/Ts. The hardware specifications for the counters and the external buses are given in Appendix C (pages 99 to 103). The software specifications of the external buses are given in Appendix D (pages 142 and 143).

Software Details

As previously mentioned, software has been developed for the

MC68000ECB to support the hardware extensions. During the development of this software, a number of facilities were established in order to provide a suitable software development environment. Although the single board computer provides software development tools, some of these were found to be inadequate. The major deficiencies were program storage and program documentation.

The MC68000ECB provides a cassette recorder interface for program storage and retrieval, however, it is difficult to use and reliability is questionable. A more suitable solution was to use the hard disk storage on the ADAC 1000. Since the hardware communication was already established between the MC68000ECB and the ADAC 1000, all that was needed was the software support to upload and download programs across the serial communications line. Fortunately, the operating system for the MC68000ECB contains the necessary primitives to upload either S-records or memory dumps to a host computer and to download S-records from a host computer. With the available facilities, the only missing software was a communications handler for the ADAC 1000. This program, named "transfer", was relatively easy to write and has worked well. A complete listing of the transfer program is presented in Appendix E.

The other major deficiency, i.e. program documentation, was not so easily solved. The primary reason why documentation is so difficult on the MC68000ECB is that it is impossible to include comments in the source code written on the single board computer. This problem is best avoided by the use of a 68000 cross-assembler, unfortunately, they are expensive and none were locally available at the time. For this

application, the following procedure was used.

1. Type in the software on the MC68000ECB console using the single line assembler and keep accurate notes on paper.
2. Save the program segments in S-record format on the ADAC 1000 hard disk for future use.
3. Combine program segments into modules after each segment was debugged and save the modules in both S-record format and disassembled format on the ADAC 1000 hard disk.
4. Add comments to the disassembled modules from the development notes using an editor on the ADAC 1000.

In order to facilitate the last item above, a small comment editor was written. This line editor has the capability of appending long comments over many lines of assembly code and is intelligent about page formats. A complete listing of the comment editor is also included in Appendix E.

Although the above procedure has been used successfully to create all of the MC68000ECB software, one difficulty still exists. There is no way to automatically update a change in the documentation whenever a change is made in the source code. The only way to successfully modify the current software is to first make the changes on the MC68000ECB and accurately record those changes on scratch paper. Then upload the modification to the ADAC 1000 in S-record format for permanent storage. Finally, edit the original commented file and make the changes recorded on scratch paper. This can be a very difficult procedure which requires

the utmost attention to detail.

Once a procedure was established for development and documentation of software, attention was focused on the specific algorithms to be developed. As was previously discussed, there are four primary blocks of code; normal sequential execution, software interrupt processing, and hardware interrupt processing, all surrounded by a common data structure.

The normal sequential execution block consists of a main routine and two subroutines, getdata and compute. The main routine provides the control for all normal sequential program execution, and currently executes an interactive environment (not real time) by which the user can manipulate the drive train. This configuration is useful for data mapping and system debugging. In its final form, the main routine will provide the real time control of the system. The getdata subroutine is called once each time through the main routine. The purpose of the getdata subroutine is to gather all necessary inputs and establish the current state of the drive line. The compute subroutine is also called once each time through the main routine. The purpose of the compute subroutine is to examine the current state of the drive line and compute a new desired state. In the current version, the compute subroutine is fully interactive so that the user inputs the new desired state. In its final form, the compute subroutine will implement the optimization algorithm. It should be noted that throughout the main routine and getdata subroutine, numerous software interrupts are generated in order to initialize and communicate with all system hardware. This creates an

advantage in software development since the hardware dependencies are all grouped together in the software interrupt processing block.

The hardware interrupt processing block is the least developed of the four primary blocks. In its final form, this block will be responsible for handling interrupts from three sources: ADAC 1000, real-time timer, and system shutdown requests. Currently only the ADAC 1000 interrupt is supported. The reason for not developing the additional facilities is that they are features of the final implementation and are not needed for data collection and debugging. Only one routine, HOST-INT, currently resides in the hardware interrupt processing block. Host-int provides the interrupt handler for all MC68000ECB to ADAC 1000 communications. In its final form, this routine will control communications in both directions. Currently, the routine only provides for data to be passed from the MC68000ECB to the ADAC 1000. This has proved sufficient for drive line mapping. Once the implementation of the control algorithm is in place, bi-directional data flow will be needed.

The software interrupt processing block provides the hardware interface to both other software blocks. This group of software has been fully developed in parallel with hardware developments and has been extensively tested. Following is a brief description of each routine in the software interrupt processing block.

1. P-INIT.

P-init initializes the peripherals which are contained on the MC68000ECB.

2. E-INIT.

E-init initializes the peripherals which are contained on the I/O expansion bus.

3. SET-UP.

Set-up provides an interactive mode of initializing the physical engine and transmissions. This procedure is executed only once and must be preformed after all computer hardware has been initialized.

4. MOVE-TH.

Move-th provides the software interface to the stepper motor driver associated with the engine throttle.

5. MOVE-CVT.

Move-cvt provides the software interface to the stepper motor driver associated with the CVT transmission.

6. SET-GEAR.

Set-gear provides the software interface to the hardware associated with the Power Shift transmission.

7. TEST-STABLE.

Test-stable insures that the drive line actuators are stable before releasing control back to normal sequential execution.

8. READ-RACK.

Read-rack provides the software interface to the absolute encoder which is mechanically attached to the CAT diesel injector pump.

9. READ-THSTP.

Read-thstp provides the software interface to the incremental encoder which is mechanically attached to the throttle stepper motor.

10. READ-FBSTP.

Read-fbstp provides the software interface to the incremental encoder which is mechanically attached to the CVT ring drive.

11. REG-SAVE.

Reg-save saves all CPU internal registers not saved as a part of normal context switching.

12. REG-RESTORE.

Reg-restore restores all CPU internal registers which were saved by reg-save.

The above software package is fully documented in Appendix D. Each of the routines is presented along with general discussions about common data, argument passing, and hardware specifications. Although all of the software is in assembly code, it is relatively easy to read since the code is filled with comments. In order to supplement Appendix D, a memory map (Table 1, page 40) has been specified. These memory specifications establish allocated space for all user software. The total memory available on the system is 32 Kbytes. The operating system (TUTOR) requires 1280 bytes of scratch and the RAM vector table requires 1024 bytes. Therefore a total of 30,464 bytes are available for user programs.

Table 1 MC68000ECB User Memory Allocation

Description	Address Range	# of 8ytes Available	# of 8ytes Used
Normal Sequential Execution			
Common Data	\$0900 - \$0DFF	1280	208
Main Routine			
Data	\$0E00 - \$0FFF	512	147
Text	\$1000 - \$11FF	512	289
Getdata Subroutine			
Data	\$1200 - \$12FF	256	0
Text	\$1300 - \$14FF	512	71
Compute Subroutine			
Data	\$1500 - \$1FFF	2816	49
Text	\$2000 - \$4FFF	12288	165
Software Interrupt Processing			
Common Data	\$5000 - \$507F	128	81
Local Data	\$5080 - \$57FF	1920	385
Text	\$6000 - \$6FFF	4096	1584
Hardware Interrupt Processing			
Local Data	\$5800 - \$5FFF	2048	45
Text	\$7000 - \$7FFF	4096	273
	Totals	30464	3297

In summary, the purpose of this chapter is to discuss the work completed on the MC68000ECB. This work includes both hardware expansions and software developments. A general overview was presented to give perspective to the entire system development, after which the hardware and software were discussed in more detail. During these discussions a number of appendices were cited which give specific details and comments about the hardware and software of the MC68000ECB.

SUMMARY

The objective of this study is to develop and test a computer control system for optimizing the performance of a diesel engine and a continuously variable transmission as applied in an agricultural tractor. In order to meet the objective, a number of tasks were defined.

1. Develop laboratory facilities for the study of drive line efficiency.
2. Collect and analyze data to determine performance relationships.
3. Develop an optimization and control algorithm for the drive line.
4. Evaluate dynamic considerations of the algorithm.
5. Test and evaluate the performance of the algorithm.

This project is on-going with the test facility completed, the performance data collected, and the basic optimization algorithm outlined. Plans for future work include: analyzing the collected data to establish relationships between control inputs and drive line outputs, and developing a computer simulation of the optimization algorithm in order to evaluate dynamic and performance considerations.

This thesis has presented the work completed on the development of computer facilities for implementation of data acquisition and control algorithms as related to the above study. In order to fulfill the

project's computer needs, two systems were developed. One system uses an ADAC 1000 data acquisition computer and is responsible for the supervisory functions, data recording, sub-system controls, and conversion of all analog data into digital forms. The other system uses a Motorola MC68000ECB single board computer and is responsible for drive line control and optimization.

The work completed on the ADAC 1000 falls into two main categories; a complete system upgrade, and development of a large software package. The structure of the software package is based upon concepts used in concurrent programming in order to preserve real time capabilities.

The work completed on the MC68000ECB includes both hardware and software developments. The hardware developments include bus expansion buffering, I/O expansion, optical isolation, and digital interfacing to external devices. The software developments provide the framework for all future developments. Currently, the software executes a fully interactive environment which is useful for drive line mapping.

REFERENCES

- "Berkeley Unix Programmer's Manual," PDP-11 Version 2.9, Seventh Edition, Volume 1, Berkeley Software Division, Berkeley, CA, 1983.
- Bourne, F. R., "The Unix System," Addison-Wesley Publishing, 1983.
- Chancellor, W. J., and Thai, N. C., "Automatic Control of Tractor Engine Speed and Transmission Ratio," ASAE Paper No. 83-1061, Presented at ASAE Summer Meeting, Montana State University, Bozeman, June 1983.
- Hancock, L., and Krieger, M., "The C Primer", 2nd ed., McGraw-Hill, New York, 1985.
- Horowitz, P., and Hill, W., "The Art of Electronics," 3rd ed., Cambridge University Press, 1980.
- Kelly-Bootle, S., and Fowler, B., "68000, 68010, and 68020 Primer," 1st ed., Howard W. Sams & Co., Inc., Indianapolis, Indiana, 1985.
- Kernighan, B. W., and Ritchie, D. M., "The C Programming Language," Prentice-Hall, Inc., Englewood Cliffs, NJ, 1978.
- "MC68000 16-Bit Microprocessor, Advanced Information," Motorola Inc., Publication ADI-814-R4, April 1983.
- "MC68000 16-Bit Microprocessor, User's Manual," Motorola Inc., Third Edition, 1982.
- "MC68000 Educational Computer Board, User's Manual," Motorola Inc., July 1982.
- "MC68230 Parallel Interface/Timer, Advanced Information," Motorola Inc., Publication ADI-860-R2, Dec. 1983.
- Meiring, P. and Lyne, P. W., "Power Demand Mapping of Tractor Operations," ASAE Paper No. 85-1050, Presented at ASAE Summer Meeting, Michigan State University, East Lansing, June 1985.
- Meiring, P. and Rail, M. G., "An Operator Assist System to Optimize Tractor Efficiency," ASAE Paper No. 79-1048, Presented at the Summer Meeting of ASAE and CSAE, University of Manitoba, Winnipeg, Canada, June 1979.

- Morris, D. A., et. al., "Potential Fuel Savings Using a Tractor-Operator Feedback System," ASAE Paper No. 84-1077, Presented at ASAE Summer Meeting, University of Tennessee, Knoxville, June 1984.
- Morris, W., editor, "The American Heritage Dictionary of the English Language," Houghton Mifflin Company, Boston, MA, 1976.
- "Motorola Microprocessors Data Manual," Motorola Inc., Publication DL-120, 1981.
- Schrock, M. D., Matteson, D. K., and Thompson, J. G., "A Gear Selection Aid for Agricultural Tractors," ASAE Paper No. 82-5515, Presented at ASAE Winter Meeting, Palmer House, Chicago, IL., Dec. 1982.
- Smith, R. J., "Circuits, Devices, and Systems," 3rd ed., Wiley, New York, 1976.
- Spaulding, G., "Instrumentation and Modification of the IRI/M50 Robot for Automatic Control Research," (unpubl M.S. Thesis, Kansas State University, 1985).
- "The TTL Data Book for Design Engineers," 2nd ed., Texas Instruments Inc., 1976.

APPENDIX A
DRIVE LINE PARAMETERS

Primary Engine Parameters

1. Output Torque.

The engine output torque is measured by a Lebow Model 1228-10k in-line torque cell with a maximum rating of 10000 inch-pounds. The output signal is a millivolt level analog signal which is amplified and filtered by a Daytronic Model 3270 strain gage conditioner to achieve a 0 to 5 volt analog signal with 2 Hz. low pass characteristics. This signal is then digitized at the 1014 A/D board to give a final resolution of .975 ft-lb/bit.

2. Output Speed.

The engine output speed is measured by a 60-tooth gear in conjunction with a magnetic induction coil both of which are mounted to the above torque transducer. The output signal is a millivolt level analog signal which is amplified and filtered by a Daytronic Model 3240 frequency conditioner to achieve a 0 to 5 volt analog signal with 2 Hz. low pass characteristics. This signal is then digitized on the 1014 A/D board to give a final resolution of 4.859 rpm/bit.

3. Governor Position.

The engine injector pump has been modified to accept a Litton 7NB10-5-S-1 absolute position encoder. The encoder converts the rotary motion of the pump "rack" to a standard TTL digital signal. Although the encoder gives 10 bits output, less than 90 degrees of rotation are achieved over the range of rack motion. Therefore, only eight bits are actually read by the control computer. The final resolution of the rack signal is 176 levels over the operating range of the rack.

4. Throttle Position.

The engine throttle position is controlled by a Sigma Model 20-2235D-28175 stepper motor. Control of the stepper motor is achieved through hardware on the MC68000ECB. In addition, a BEI Model L25G-100-ABZ-7400R-S incremental encoder has been incorporated into the throttle drive to give feedback of throttle position. The output of the encoder is in TTL digital quadrature format which is decoded through hardware on the MC68000ECB. Total control resolution of the throttle position is 1980 steps with a total of 3960 feedback levels over the range of throttle movement.

5. Throttle Home.

A single bit resolution on/off switch is also provided as part of the above throttle controller. The purpose of this switch is to initialize the "home" or zero position of both the stepper motor and the feedback encoder.

6. Fuel Flow.

Engine fuel flow is measured gravimetrically. The fuel scale consists of an eight liter container suspended from an Amteck 8A-25-L8

load cell. The load cell is powered and conditioned to a high level analog signal by a Calex 166 bridge sensor. This signal is then digitized on the 1014 A/O board to give a final resolution of .008924 lbs-fuel/bit.

Secondary Engine Parameters

1. Oil Pressure. Engine oil pressure is measured by an Omega model PX-242-100G-5V pressure transducer. This signal is digitized on the 1014 A/O board to give a final resolution of .0977 psi/bit.
2. Exhaust Gas Temperature. Engine exhaust gas temperature is measured by an Iron/Con type thermocouple.
3. Engine Coolant, Oil, and Ambient Air Temperatures. These temperatures are measured by Copper/Con type thermocouples.
4. Fuel Temperature and API Number. The engine fuel temperature is measured with an ordinary thermometer in degrees fahrenheit. The standard fuel API number is also collected by hand using a gravimetric buib. This data is needed to convert fuel mass flow to volumetric flow. The data is entered into the data acquisition structure through the terminal keyboard.
5. Emergency Shut Off. To provide for immediate system shut down in the case of catastrophic drive line failure, a throttle plate was installed in the engine intake system. Control of the emergency shut off is provide by a manual flip switch to a 110 VAC solenoid.

Primary CVT Parameters

1. Output Torque. The CVT output torque is measured by a Lebow Model 1228-10K in-line torque cell with a maximum rating of 10000 inch-pounds. The output signal is a millivolt level analog signal which is amplified and filtered by a Daytronic Model 3270 strain gage conditioner to achieve a 0 to 5 volt analog signal with 2 Hz. low pass characteristics. This signal is then digitized at the 1014 A/O board to give a final resolution of .9735 ft-lb/bit.
2. Output Speed. The CVT output speed is measured by a 60-tooth gear in conjunction with a magnetic induction coil both of which are mounted to the above torque transducer. The output signal is a millivolt level analog signal which is amplified and filtered by a Daytronic Model 3240 frequency conditioner to achieve a 0 to 5 volt analog signal with 2 Hz. low pass characteristics. This signal is then digitized on the 1014 A/O board to give a final resolution of 4.8818 rpm/bit.

3. Ring Position.

The CVT ring position is controlled by a Sigma Model 21-4270D-200F03 stepper motor. Control of the stepper motor is achieved through hardware on the MC68000ECB. In addition, a BEI Model L25G-100-ABZ-7400R-S incremental encoder has been incorporated into the CVT ring drive to give feedback of ring position. The output of the encoder is in TTL digital quadrature format which is decoded through hardware on the MC68000ECB. Total control resolution of the ring position is 3400 steps with a total of 18891 feedback levels over the range of ring movement.

4. Ring Home.

A single bit resolution on/off switch is also provided as part of the above CVT ring controller. The purpose of this switch is to initialize the "home" or zero position of both the stepper motor and the feedback encoder.

Secondary CVT Parameters

1. Oil Temperature Controller Inputs.

The CVT input oil temperature controller has a number of inputs. The following temperatures are measured:

- a. Input oil temperature.
- b. Exit oil temperature.
- c. Reservoir oil temperature.
- d. Heat exchanger oil input temperature.
- e. Tap water temperature.
- f. Heat exchanger water input temperature.
- g. Heat exchanger water exit temperature.

All of these temperatures are measured by Copper/Con type thermocouples. In addition to the temperatures, the controller also requires an input oil temperature set point which is entered at the terminal keyboard.

2. Oil Temperature Controller Outputs.

The controller has two outputs, each which sets the status of the water heater elements. The first element is controlled digitally as on/off, and the second element is controlled by the 1021 D/A board and a Johnson Model DQ-4100 solid state electric heat control unit. Total control output resolution is 2.44141 W/bit.

3. Oil Flow and Pressure.

The oil flow and pressure are monitored to both branches of the oil loop. Pressure is measured by a standard dial pressure gauge, and flow is measured by two magnetic induction vane type flow meters. The flow meters output is a millivolt level analog signal. This signal is preconditioned to be read by the 1018 pulse counter board. The signal pulse trains are averaged over a one second time base. Conversion is then made to oil flow in gal/min.

Primary Power Shift Parameter

The power shift gear ratio is selected by appropriate engagement of six 12 VDC electro-hydraulic solenoids. Control of these solenoids is accomplished through a digital interface to the MC68000ECB. Software access of the current gear ratio is made through the communications link to the MC68000ECB.

Secondary Power Shift Parameters

1. Oil Pressure.
Oil pressure is measured by a standard oil pressure dial gauge.
2. Oil Temperature.
Oil temperature is measured by a Copper/Con type thermocouple.

Primary Dynamometer Parameters

1. Input Torque.
The dynamometer input torque is measured by a Transducers Model T63H-200-C205 dual bridge load cell attached to 15.756 inch lever arm. One output of the load cell is used as feedback for the dynamometer controller. The other output is amplified and filtered by a Daytronic Model 3270 strain gage conditioner to achieve a 0 to 5 volt analog signal with 2 Hz. low pass characteristics. This signal is then digitized at the 1014 A/D board to give a final resolution of .6339 ft-lb/bit.
2. Input Speed.
The dynamometer input speed is measured by a 60-tooth gear in conjunction with two magnetic induction coils. One of the pickups is used as feedback for the dynamometer controller. The other pickup is amplified and filtered by a Daytronic Model 3240 frequency conditioner to achieve a 0 to 5 volt analog signal with 2 Hz. low pass characteristics. This signal is then digitized on the 1013 A/D board to give a final resolution of 4.859 rpm/bit.

Secondary Dynamometer Parameters.

Both the input and output cooling water temperatures are measured using Copper/Con type thermocouples. These temperatures are used to provide dynamometer overloading protection.

Temperature Conversion Notes.

All of the above thermocouple outputs are digitized on the 1022 A/D board. Three types of thermocouple types are supported in the test lab. They are type T (Copper/Con), type J (Iron/Con), and type K (Chromel/Alumel). The following table has been established for temperature conversions.

Table 2 Temperature Conversions

TYPE	Sensitivity mv/bit	Regression Equation Temp(C)= (.....) (R^2= .9999+)	Valid Range deg C
T	0.00976	$((.007727 \text{mv} - .436) \text{mv} + 24.91) \text{mv}$	0 to 400
J	0.0244	$((-.0003982 \text{mv} - .0008997) \text{mv} + 18.52) \text{mv}$	0 to 750
K	0.0488	$((.001582 \text{mv} - .09563) \text{mv} + 25.5) \text{mv}$	0 to 1360

APPENDIX B

ADAC 1000 SUPERVISOR SOFTWARE LISTINGS

```

*****
*
*
*   SUPPLEMENTAL LISTING FOR AOAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- SUPERVISOR
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT O. FUNK
*   OATE:        4/5/85
*   FILE:        Makefile
*
*****

#This file contains the rules necessary to create
#   a program by the name "cvt".
#
#In order to run the program:
# --> kmon cvt

# define global substitution variables
CC1= cc -c
CC2= cc -O -o
OBJECTS= main.o define.o keyboard.o doalarm.o mon.o cvtlinear.o
LIB= -ladac -lm

# define rules and dependencies for creation of object files
define.o : define.c control.h
    $(CC1) define.c
main.o : main.c control.h
    $(CC1) main.c
keyboard.o : keyboard.c control.h
    $(CC1) keyboard.c
doalarm.o : doalarm.c control.h
    $(CC1) doalarm.c
mon.o : mon.c control.h
    $(CC1) mon.c
cvtlinear.o : cvtlinear.c control.h
    $(CC1) cvtlinear.c

# define rules and dependencies for executables
cvt : $(OBJECTS)
    $(CC2) cvt $(OBJECTS) $(LIB)

```



```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- SUPERVISOR
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   OATE:        4/5/85
*   FILE:        control.h
*
*****

/* Oeclare global variables used in main by other functions          */
#define NO68K
int sigalarm();
int sigkbdreq();
int kbdfldflag, alarmflag;
int fd68k;

/* definitions of attribute in sprintf function                      */
#define NORM      0
#define UNDERLINE 1
#define REVERSE   2

/* set up data file definitions                                      */
FILE *dfp, *fopen();
char dfname[10];

/* set up structures for gman routine                                */
struct gv { /* real variables */
    char gvname[7];
    double *gvad;
} gvs[];
struct flg { /* integer variables */
    char flgname[7];
    int *flgad;
} flags[];

/* set up structure for high level data acquisition                  */
struct hlda {
    char parm[7];
    int chan, gain;
    double off, calcon;
    int a, b;
} hldax[];

/* set up structure for temperature data acquisition                */
struct tmpda {
    char parm[7];

```

```

        int chan, type;
        int c, d;
    } tmpdax[];

/* set up structure for pulse card data acquisition */
struct pulse {
    char parm[7];
    int chan;
    double tbase, const1, const2;
    int e, f;
} pulsex[];

/* set up structure for monitor subroutine limits */
struct limits {
    double *max, *warn;
} hl_lim[], tmp_lim[], pul_lim[];

/* set up space for command line */
char keyword[5];
char name[10];
double data;

/* global variables declared */
/* engine parameters */
double ewtpmx; /* engine water temp max */
double ewtpwn; /* engine water temp warning */
double eegtmx; /* exhaust gas temp max */
double eegtwn; /* exhaust gas temp warning */
double erpmmx; /* engine rpm max */
double erpmwn; /* engine rpm warning */
double etrkmx; /* eng tork max */
double etrkwn; /* eng tork warning */
double enopmn; /* engine oil pressure min */
double enopwn; /* engine oil pressure warning */
double enotwn; /* engine oil temp warning */
double enotmx; /* engine oil temp max */
double enffmn; /* wt of fuel in bucket > 2 lbs */
double api; /* fuel api number */
double ftmp; /* fuel temperature */
char point[10]; /* engine map reference point */

/* cvt parameters */
double tcvtmx; /* cvt oil temp exit mx used by monitor */
double tcvtwn; /* cvt oil temp exit warn used by monitor */
double toomx; /* cvt oil temp in max used by monitor */
double toomn; /* cvt oil temp in min used by monitor */
double twimx; /* max tmp of water in hx */
double twiwn; /* warning tmp of water in hx */
double offmn; /* cvt oil flow front min */
double offmx; /* cvt oil flow front max */
double ofrmn; /* cvt oil flow rear min */

```

```

double ofrmx;      /* cvt oil flow rear max */
double trpmmx;     /* cvt-pwrshift rpm max */
double trpmwn;     /* cvt-pwrshift rpm warning */

/* pwr-shift parameters */
double ttrkmx;     /* cvt-pwrshift tork max */
double ttrkwn;     /* cvt-pwrshift tork warning */
double psotmx;     /* pwr shift oil temp max */
double psotwn;     /* pwr shift oil temp warning */

/* final drive parameters */
double fdotmx;     /* final drive oil temp max */
double fdotwn;     /* final drive oil temp warning */

/* dyno parameters */
double dwotmx;     /* dynamoter water temp out max */
double dwotwn;     /* dyno water temp out warning */
double drpmmx;     /* dyno rpm max */
double drpmwn;     /* dyno rpm warning */
double dtrkmx;     /* dyno trk max */
double dtrkwn;     /* dyno trk warn */

/* ambient parameters */
double alrthl;     /* ambient air temp hi */
double airtlo;     /* ambient air temp lo */

/* program control flags */
int timint;        /* alarm interrupt time (sec) */
int montim;        /* monitor loop time (sec) */
int dyctim;        /* dyno loop time (sec) */
int hrctlm;        /* heater control loop time (sec) */
int dattim;        /* data collection loop time (sec) */
int datmax;        /* data collection interval (number of samples) */
int monflg;        /* monitor enable */
int dycflg;        /* dyno enable */
int hrcflg;        /* heater enable */
int datflg;        /* data loop enable */
int orphan;        /* kmon exiting flag */
int online;        /* m68k online flag */
int waitmx;        /* wait state for request call on 68k */
int daval;         /* temporary value for D/A in heater */
int ttlval;        /* temporary value for TTL in heater */

/* m68k variables */
int req;           /* control flag for request */
int rack;          /* rack reading */
int thstp;         /* throttle step reading */
int rgstp;         /* ring step reading */
int gear;          /* PS gear */
int fbstp;         /* cvt feedback reading */

/* heater control input */
double hset;       /* cvt oil temp in as set point for heater control

```

```

*****
*
*
* C-SOURCE LISTING FOR ADAC 1000 COMPUTER
* CVT -- ENGINE PROJECT -- SUPERVISOR
*
* DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
* AUTHOR: KENT D. FUNK
* DATE: 4/5/85
* FILE: define.c
*
*****

/* This file contains all complete definitions of global variables */
#include <stdio.h>
#include "control.h"
#include <adac.h>

/* define data file default */
char dfname[10] = "d.tmp";

/* global variables initialized */
/* engine parameters */
double ewtpmx= 105.0; /* engine water temp max */
double ewtpwn= 93.0; /* engine water temp warning */
double eegtmx= 705.0; /* exhaust gas temp max */
double eegtwn= 650.0; /* exhaust gas temp warning */
double erpmmx= 2500.0; /* engine rpm max */
double erpmwn= 2300.0; /* engine rpm warning */
double etrkmx= 240.0; /* eng tork max */
double etrkwn= 260.0; /* eng tork warning */
double enopmn= 30.0; /* engine oil pressure min */
double enopwn= 40.0; /* engine oil pressure warning */
double enotwn= 93.0; /* engine oil temp warn */
double enotmx= 105.0; /* engine oil temp max */
double enffmn= 5.0; /* minimum fuel in the fuel bucket */

/* cvt parameters */
double tcvtmx= 75.0; /* cvt oil temp exit mx used by monitor */
double tcvtwn= 65.0; /* cvt oil temp exit warn used by monitor */
double toomx= 2.0; /* cvt oil temp in cvt, max used by monitor */
double toomn= 2.0; /* cvt oil temp in cvt, min used by monitor */
double twimx= 65.0; /* water temp in max */
double twiwn= 60.0; /* warning water in tmp */
double offmn= 4.5; /* cvt oil flow front min */
double offmx= 5.5; /* cvt oil flow front max */
double ofrmn= 4.5; /* cvt oil flow rear min */
double ofrmx= 5.5; /* cvt oil flow rear max */
double trpmmx= 1750.0; /* cvt-pwrshift rpm max */

```

```

double trpmwn= 1610.0; /* cvt-pwrshift rpm warning */

/* pwr-shift parameters */
double ttrkmx= 667.0; /* cvt-pwrshift tork max */
double ttrkwn= 615.0; /* cvt-pwrshift tork warning */
double psotmx= 100.0; /* pwr shift oil temp max */
double psotwn= 90.0; /* pwr shift oil temp warning */

/* final drive parameters */
double fdotmx= 100.0; /* final drive oil temp max */
double fdotwn= 90.0; /* final drive oil temp warning */

/* dyno parameters */
double dwotmx= 45.0; /* dynamoter water temp out max */
double dwotwn= 40.0; /* dyno water temp out warning */
double drpmmx= 4000.0; /* dyno rpm max */
double drpmwn= 3800.0; /* dyno rpm warning */
double dtrkmx= 190.0; /* dyno trk max */
double dtrkwn= 175.0; /* dyno trk warn */

/* ambient parameters */
double airthi= 32.0; /* ambient air temp hi */
double airtlo= 22.0; /* ambient air temp lo */

/* program control flags */
int timint= 1; /* number of seconds between interrupts */
int montim= 10; /* monitor loop time in seconds */
int dyctim= 10; /* dyno loop time in seconds */
int hrctim= 5; /* heater loop time in seconds */
int dattim= 10; /* data collection loop time in seconds */
int datmax= 18; /* maximum number of data sets */
int monflg= 1; /* monitor loop enable */
int dycflg= 0; /* dyno loop enable */
int hrcflg= 0; /* heater loop enable */
int datflg= 0; /* data loop enable */
int daval= 0; /* heater D/A value */
int ttlval= 0; /* heater TTL value */
int orphan= 0; /* flag set when CVT is backgrounded */
int online= 0; /* initially m86k is offline */
int waitmx= 2; /* wait state for data request on 68k */

/* initialize the structure gv */
struct gv gvs[] {
    "ewtpmx", &ewtpmx, /* real variable name and storage address */
    "ewtpwn", &ewtpwn,
    "eegtmx", &eegtmx,
    "eegtwn", &eegtwn,
    "erpmmx", &erpmmx,
    "erpwmwn", &erpwmwn,
    "etrkmx", &etrkmx,

```

```

    "etrkwn", &etrkwn,
    "enogmn", &enopmn,
    "enopwn", &enopwn,
    "enotwn", &enotwn,
    "enotmx", &enotmx,
    "enffmn", &enffmn,
    "tcvtmx", &tcvtmx,
    "tcvtwn", &tcvtwn,
    "toomx", &toomx,
    "toomn", &toomn,
    "hset", &hset,
    "twimx", &twimx,
    "twiwn", &twiwn,
    "offmn", &offmn,
    "offmx", &offmx,
    "ofrmn", &ofrmn,
    "ofrmx", &ofrmx,
    "trpmmx", &trpmmx,
    "trpmwn", &trpmwn,
    "ttrkmx", &ttrkmx,
    "ttrkwn", &ttrkwn,
    "psotmx", &psotmx,
    "psotwn", &psotwn,
    "fdotmx", &fdotmx,
    "fdotwn", &fdotwn,
    "dwotmx", &dwotmx,
    "dwotwn", &dwotwn,
    "drpmmx", &drpmmx,
    "drpmwn", &drpmwn,
    "dtrkmx", &dtrkmx,
    "dtrkwn", &dtrkwn,
    "airthi", &airthi,
    "airtlo", &airtlo,
    "",
}; /* error check at end of structure */

/* Initialize the integer variable structure */
struct flg flags[] {
    "timint", &timint, /* int variable name and address */
    "montim", &montim,
    "dyctim", &dyctim,
    "hrctim", &hrctim,
    "dattim", &dattim,
    "datmax", &datmax,
    "monflg", &monflg,
    "dycflg", &dycflg,
    "hrcflg", &hrcflg,
    "datflg", &datflg,
    "daval", &daval,
    "ttlval", &ttlval,
};

```

```

        "online", &online,
        "waitmx", &waitmx,
        ""
    };

/* Initialize high level data acquisition structure */
struct hlda hidax[] {
    "erpm", 26, 1, -2.0, 4.859086, 8, 4, /* engine rpm */
    "etrk", 28, 1, 1.0, 0.975161, 8, 5, /* engine tork */
    "trpm", 27, 1, 1.0, 4.881813, 23, 4, /* cvt-trans rpm */
    "ttrk", 29, 1, 1.0, 0.973510, 23, 5, /* cvt-trans tork */
    "drpm", 34, 1, -1.0, 4.859086, 55, 4, /* dyno rpm */
    "dtrk", 32, 1, -2.0, 0.482775, 55, 5, /* dyno tork */
    "enop", 16, 1, 209.0, 0.097704, 8, 10, /* engine oil pressure */
    "enff", 25, 1, 277.0, 0.008924, 8, 6, /* engine fuel flow */
    "", /* error check at end of structure */
};

/* initialize temp data acquisition structure */
struct tmpda tmpdax[] {
    "ewtp", 20, 3, 8, 8, /* engine water tmp */
    "eegt", 30, 0, 8, 7, /* engine exhaust gas tmp */
    "enot", 21, 3, 8, 9, /* engine oil tmp */
    "tcvt", 26, 3, 23, 8, /* cvt oil tmp exit */
    "twi", 29, 3, 23, 6, /* water temp of hx loop */
    "psot", 23, 3, 39, 4, /* pwr shift oil tmp */
    "fdot", 22, 3, 39, 5, /* final drive oil tmp */
    "dwot", 17, 3, 55, 7, /* dyno water outlet temp */
    "too", 27, 3, 23, 7, /* cvt oil tmp in */
    "airt", 19, 3, 39, 7, /* ambient air tmp */
    "ttnk", 25, 3, 23, 9, /* cvt oil tmp @ tank */
    "toi", 24, 3, 23, 10, /* cvt oil tmp at hx */
    "dwit", 18, 3, 55, 6, /* dynot water inlet temp */
    "two", 28, 3, 23, 11, /* cvt water temp exit */
    "", /* error checking at end of structure */
};

/* initialize pulse card data acquisition structure */
struct pulse pulsex[] {
    "off", 0, 1.0, 1.414, 5.572, 23, 12, /* cvt oil flow front */
    "ofr", 1, 1.0, 1.05, 7.777, 23, 13, /* cvt oil flow rear */
    "", /* error check at end of structure */
};

/* initialize monitor limits structure */
struct llimits hl_lim[] {
    &erpmmx, &erpmwn, /* max-warn storage addresses => struct hlda */
    &etrkmx, &etrkwn,

```

```

        &trpmmx, &trpmwn,
        &trrkmx, &trrkwn,
        &drpmmx, &drpmwn,
        &dtrkmx, &dtrkwn,
        &enopmn, &enopwn,
    };

    struct limits tmp_lim[] {
        &ewtpmx, &ewtpwn, /* max-warn storage addresses => tmpda */
        &eegtmx, &eegtwn,
        &enotmx, &enotwn,
        &tcvtmx, &tcvtwn,
        &twimx, &twiwn,
        &psotmx, &psotwn,
        &fdotmx, &fdotwn,
        &dwotmx, &dwotwn,
        &toomx, &toomn,
        &airthi, &airtlo,
    };

    struct limits pul_lim[] {
        &offmx, &offmn, /* max-min storage addresses => struct pulse */
        &ofrmx, &ofrmn,
    };

    /* initialize m68k variables */
    int req= 0;
    int rack= 0;
    int thstp= 0;
    int rgstp= 0;
    int gear= 0;
    int fbstp= 0;

    /* heater control input */
    double hset= 65.0; /* cvt oil temp-in set point for heater control */

```



```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- SUPERVISOR
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        4/5/85
*   FILE:        main.c
*
*****

#include <signal.h>
#include <stdio.h>
#include "control.h"
#include <adac.h>

/* this function is used to handle unix alarm interupts */
sigalarm() {
    signal(SIGALRM, sigalarm);
    alarm(timint);
    alarmflag++;
}

/* this function handles the keyboard process interupt */
sigkbdreq() {
    signal(SIGINT, sigkbdreq);
    kbdflag++;
}

/*****                                MAIN()                                *****/
main(argc, argv)
int  argc;
char **argv;
{
    int err;

    signal(SIGQUIT,SIG_IGN);
    signal(SIGALRM, sigalarm);
    signal(SIGINT,sigkbdreq);

    /* open up the 68k line here */
    if ((fd68k = open("/dev/ttyd0", 2)) < 0) {
        fprintf(stderr, "cannot open 68k line\n");
        fprintf(stderr, "   cvt exiting\n");
        exit(1);
    }
}

```

```

    alarm(timint);
    adacinit();
    paint();

loop:
    err= do68k(1, 0);
    while(alarmflag > 0)
        doalarm();
    if(kbdflag)
        keyboard();
    goto loop;
}

```

```

/*****                                68k handler                                *****/
do68k(entry, option)
int entry, option;
{
    static int first= 0;
    int error, ret, num;
    char rdbuf[80];
    char *lptr;

    if (first == 0) {
        *rdbuf= ' ';
        ret= 0;
        first= 1;
    }

    error= 0;
    if (online == 0) {
        error= 1; /* 68k is not here now */
        goto not_here;
    }

    switch(entry) {
        case 1: /* entry point for main */
            ret= read(fd68k, rdbuf, 80);
            if (ret > 0) {
                rdbuf[ret]= ' ';

                switch(*rdbuf) {
                    case 'R':
                        service();
                        break;
                    case 'S':
                        break;
                    default:
                        ;
                }
            }
        }
    }
}

```

```

        *rdbuf= ' ';
        ret= 0;
    }
    break;

case 2:          /* entry point for monitor */
    if (req) {
        goto not_here;
    }
    if (option == 1) {
        write(fd68k, "R", 1);
        break;
    }
    if (option == 2) {
        ret= read(fd68k, rdbuf, 80);
        if (ret > 0) {
            rdbuf[ret]= ' ';
scprintf(1, 1, 0, "
                                scprintf(1, 1, 0, "%s", rdbuf);
                                moveto(99,99);
                                if (*rdbuf != 'S') {
                                    error= 5;
                                    break;
                                }
                                lptr= rdbuf + 1;
                                num= sscanf(lptr, "%d %d %d %d",
                                                &rack, &thstp,
                                                &rgstp, &fbstp,
                                                &gear);
                                if (num != 5) {
                                    error= 4;
                                }
                                *rdbuf= ' ';
                                ret= 0;
                                break;
                            }
            error= 3;
        }
        break;

case 3:          /* entry point for data routines */
    if (option == 1) {
        write(fd68k, "R", 1);
        break;
    }
    if (option == 2) {
        ret= read(fd68k, rdbuf, 80);
        if (ret > 0) {
            rdbuf[ret]= ' ';
scprintf(1, 1, 0, "
                                scprintf(1, 1, 0, "%s", rdbuf);
                                ");

```

```

        moveto(99,99);
        if (*rdbuf != 'S') {
            error= 5;
            break;
        }
        lptr= rdbuf + 1;
        num= sscanf(lptr, "%d %d %d %d %d",
                    &rack, &thstp,
                    &rgstp, &fbstp,
                    &gear);
        if (num != 5) {
            error= 4;
        }
        *rdbuf= ' ';
        ret= 0;
        break;
    }
    error= 3;
}
break;

default:
    error= 2;
}

not_here:
    return(error);
)

/*****                                Handle a 68k request                                *****/
service()
{
    /* provide 68k data services here */
    /* Not Developed */
    ;
}

/*
do68k() error handling.

general:
0 == normal
1 == 68k not here
2 == entry option error for do68k call

specific by entry and option:
1 x
    none

```

```
2 1
   none
2 2
   3= new line not here yet (data not current)
   4= wrong number of arguments in new line.
   5= 'S' tag missing on new line.
3 1
   none
3 2
   3= new line not here yet (data not current)
   4= wrong number of arguments in new line.
   5= 'S' tag missing on new line.
*/
```

```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*   CVT -- ENGINE PROJECT -- SUPERVISOR
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        4/5/85
*   FILE:        keyboard.c
*
*****

```

```

#include <stdio.h>
#include "control.h"

```

```

/*****                                Keyboard()                                *****/
/*
Keyboard service routine.
    Purpose: Interpret the first letter of the keyword and direct
             program control to the proper routine. */
keyboard()
{
    char line[80];
    char *ptr;
    char *nptr;
    int n;

    kbdflag--;          /* negates calling condition */
    fgets(line, 80, stdin);
    if (feof(stdin))
    {
        printf("exiting gracefully\n");
        exit(0);
    }
    if (strcmp(line, "!STOP\n") == 0)          /* Kmon leaving */
    {
        orphan= 1;
        return;
    }
    if (strcmp(line, "!CONT\n") == 0)          /* Kmon is back */
    {
        orphan=0;
        paint();
        return;
    }
    stdin->_cnt= 0;          /* purge the stdin */
    n= sscanf(line, "%s %s %f", &keyword, &name, &data);
    if (n==0)

```

```

        {
            sprintf(2, 20, 0, "trivial input line");
            goto end;
        }
    ptr= &keyword[0];
    switch(*ptr)
    {
    case 'f':
        flag(); /* control flag manipulator */
        break;
    case 'g':
        gman(); /* global variable manipulator */
        break;
    case 'i':
        init(); /* data acquisition initializer */
        break;
    case 'm':
        mon(); /* temporary, used to call monitor */
        break;
    case 'c':
        cleanup(); /* write current status of variables to file */
        break;
    case 'd':
        if (datflg)
        {
            sprintf(2, 20, 0, "Data collection in progress.");
            break;
        }
        if (*name)
        {
            strcpy(dfname, name);
        }
        dfptr= fopen(dfname, "a");
        datflg= 1; /* opens path in doalarm() for data acq. */
        sprintf(2, 19, 0, "Data Sample Initiated.");
        sprintf(27, 19, 0, "file= %s", dfname);
        moveto(99, 99);
        break;
    case 'p':
        paint(); /* re-paint the screen */
        break;
    case 'h':
        heat(); /* temporary used to initialize heater */
        break;
    case 'e':
        eng(); /* set api, ftmp, and point */
        break;
    default:
        sprintf(2, 20, 0, "First character invalid in keyword.");
    }
}
end:

```

```

*keyword= ' ';
*name= ' ';
data = 0;

clear();
moveto(99, 99);
}

```

```

/*****                                *****/
/*                                *****/
gman is the funtion which manipulates global variables.
Input to the function is provided by keyboard().
Variables are either read or written based on the
strings: keyword[], name[], data. */

gman()
{
    char *ptr;      /* ptr to keyword string */
    char *nptr;     /* ptr to name string */
    struct gv *gvptr; /* ptr to global variable names and addre */
    int match= 1;
    ptr= &keyword[2];
    nptr= name;
    gvptr= gvs;

    if (*name == 0)
    {
        sprintf(2, 20, 0, "Must have a variahle name.");
        goto varerr;
    }

    while (match)
    {
        /* check if we ran through the list without a match */
        if (*gvptr->gvname == 0)
        {
            sprintf(2, 20, 0, "Variable undefined.");
            goto varerr;
        }
        /* a match will yeild a '0' */
        match= strcmp(name, gvptr->gvname);
        gvptr++;
    }
    gvptr--;

    if (*ptr == 'r')
        sprintf(2, 20, 0, "%s %f", gvptr->gvname, *(gvptr->gvad));
    else if (*ptr == 'w')
    {

```



```

        *(gvptr->gvad)= data;
        sprintf(2, 20, 0, "%s %f", gvptr->gvname, *(gvptr->gvad));
    }
    else
        sprintf(2, 20, 0, "Global variable must be read or write.");
varerr:
    ;
}

```

```

/*****                                FLAG()                                *****/
/*
flag is the function which manipulates control flags.
Input to the function is provided by keyboard().
Flags are either read or written based on the
strings: keyword[], name[], data. */

flag()
{
    char *ptr;      /* ptr to keyword string */
    char *nptr;     /* ptr to name string */
    struct flg *flgptr; /* ptr to control flag names and addre */
    int match= 1;
    ptr= &keyword[2];
    nptr= name;
    flgptr= flags;

    if (*name == 0)
    {
        sprintf(2, 20, 0, "Must have a flag name.");
        goto varerr;
    }
    while (match)
    {
        /* check if we ran through the list without a match */
        if (*flgptr->flgname == 0)
        {
            sprintf(2, 20, 0, "Flag undefined.");
            goto varerr;
        }
        /* a match will yeild a '0' */
        match= strcmp(name, flgptr->flgname);
        flgptr++;
    }
    flgptr--;

    if (*ptr == 'r')
        sprintf(2, 20, 0, "%s %d", flgptr->flgname, *(flgptr->flgad));
    else if (*ptr == 'w')
    {

```

```

        *(flgptr->flgad)= data;
        sprintf(2, 20, 0, "%s %d", flgptr->flgname, *(flgptr->flgad));
    }
    else
        sprintf(2, 20, 0, "Flag variable must be read or write.");
varerr:
    ;
}

```

```

/*****                               INIT()                               *****/
/* init routine.
Purpose: This routine is called by the keyboard service
routine. It interprets the second letter of the keyword
when the first letter was a 'i'. The routines called
by init are used to initialize the adac cards
to the real world sensors. */

init()
{
    char *ptr;      /*ptr to keyword */
    ptr= &keyword[1];
    switch(*ptr)
    {
    case 'h':
        inhl();      /* high level initialization routine */
        break;
    case 't':
        intmp();      /* temp initialization routine */
        break;
    case 'p':
        intpul();      /* pulse card initialization */
        break;
    default:
        sprintf(2, 20, 0, "Second letter invalid in keyword.");
    }
}

```

```

/*****                               INHL()                               *****/
/* inhl routine.
Purpose: High level data acquisition initialization
routine. By calling, the user can assign channel
numbers, internal gains, offsets, and calibration constants
to the fixed high level parameters.
The routine uses the high level data acquisition structure
and an option is available to print the status of
the structure given the parameter name. */

```

```

inhl()
{
    char *ptr;      /* ptr to keyword */
    struct hlda *hlptr; /* ptr to high level structure */
    int match= 1;
    hlptr= hldax;
    ptr= &keyword[2];

    if (*name == 0)
    {
        sprintf(2, 20, 0, "Must have a parameter name.");
        goto parerr;
    }

    /* find the desired parameter in name */
    while (match)
    {
        if (*hlptr->parm == 0)
        {
            sprintf(2, 20, 0, "High level parameter undefined.");
            goto parerr;
        }
        match= strcmp(name, hlptr->parm);
        hlptr++;
    }
    hlptr--;
    /* find out what to do with this parameter */
    switch(*ptr)
    {
        case 'n':
            (hlptr->chan)= data;      /* assign channel */
            break;
        case 'g':
            (hlptr->gain)= data;      /* assign gain */
            break;
        case 'o':
            /* take 9 readings and assign mean to offset */
            (hlptr->off)= admean(hlptr->chan, hlptr->gain, 9);
            break;
        case 'c':
            /* take the mean of 9 readings and the data to form calcon */
            (hlptr->calcon)= data/((admean(hlptr->chan, hlptr->gain, 9))
                - hlptr->off);
            break;
        case 'p':
            /* print the status of the parameter */
            sprintf(2, 20, 0, "%s %d %d %f %f", hlptr->parm, hlptr->chan,
                hlptr->gain, hlptr->off, hlptr->calcon);
            break;
        default:
            sprintf(2, 20, 0, "Third letter in keyword not defined.");
    }
}

```

```

    }
parerr:
    ;
}

```

```

/*****                                INTMP()                                *****/
/* intmp routine.
   Purpose: Temperature data acquisition initialization
   routine. By calling, the user can assign channel
   numbers, and thermocouple types to the fixed
   temperature parameters. The routine uses the
   temperature data acquisition structure
   and an option is available to print the status
   of the structure given the parameter name. */

intmp()
{
    char *ptr;          /* ptr to keyword */
    struct tmpda *tmptr; /* ptr to temp structure */
    int match= 1;
    tmptr= tmpdax;
    ptr= &keyword[2];

    if (*name == 0)
    {
        sprintf(2, 20, 0, "Must have a parameter name.");
        goto parerr;
    }

    /* find the desired parameter in name */
    while (match)
    {
        if (*tmptr->parm == 0)
        {
            sprintf(2, 20, 0, "Temperature parameter undefined.");
            goto parerr;
        }
        match= strcmp(name, tmptr->parm);
        tmptr++;
    }
    tmptr--;
    /* find out what to do with this parameter */
    switch(*ptr)
    {
    case 'n':
        (tmptr->chan)= data;    /* assign channel */
        break;
    case 't':
        (tmptr->type)= data;    /* assign type */
        break;
    }
}

```

```

    case 'p':
        /* print status of the parameter */
        sprintf(2, 20, 0, "%s %d %d", tmptr->parm, tmptr->chan,
            tmptr->type);
        break;
    default:
        sprintf(2, 20, 0, "Third letter in keyword not defined.");
    }
    parerr:
    ;
}

```

```

/*****                                INTPUL()                                *****/
/*
intpul routine.
    Purpose: Pulse card data acquisition initialization
    routine. By calling the user can assign channel numbers,
    time base, and the intercept and first order slope
    term to transform pulse data to real world units.
    The routine uses the pulse data acquisition structure
    and an option is available to print the status
    of the structure given the parameter name. */

intpul()
{
    char *ptr;          /* ptr to keyword */
    struct pulse *pulptr; /* ptr to pulse data structure */
    int match= 1;
    pulptr= pulscx;
    ptr= &keyword[2];

    if (*name == 0)
    {
        sprintf(2, 20, 0, "Must have a parameter name.");
        goto parerr;
    }
    /* find the desired parameter in name */
    while (match)
    {
        if (*pulptr->parm == 0)
        {
            sprintf(2, 20, 0, "Pulse card parameter undefined.");
            goto parerr;
        }
        match= strcmp(name, pulptr->parm);
        pulptr++;
    }
    pulptr--;
    /* find out what to do with the parameter */

```

```

switch(*ptr)
{
case 'n':
    (pulptr->chan)= data;    /* assign channel */
    break;
case 't':
    (pulptr->tbase)= data;   /* assign time base */
    break;
case 'o':
    (pulptr->const1)= data;  /* assign intercept */
    break;
case 'c':
    (pulptr->const2)= data;  /* assign F.O. slope */
    break;
case 'p':
    /* print status of the parameter */
    sprintf(2, 20, 0, "%s %d %f %f %f", pulptr->parm,
            pulptr->chan, pulptr->tbase, pulptr->const1,
            pulptr->const2);
    break;
default:
    sprintf(2, 20, 0, "Third letter in keyword undefined.");
}
parerr:
;
}

```

```

/*****                                ENG()                                *****/
/*
Eng routine.
    This routine allows the user to set the fuel temp and API
    number. In addition a label can be attached to the data
    collection sequence. */

eng()
{
    char *nptr;

    nptr = name;
    switch(*nptr)
    {
        case 'p':
            nptr++;
            strcpy(point, nptr);
            sprintf(2, 20, 0, "point = %s", point);
            break;
        case 'a':
            if (data) {
                api = data;
            }
    }
}

```

```

        scprintf(2, 20, 0, "api = %f", api);
    }
    else {
        scprintf(2, 20, 0, "Data must have value");
    }
    break;
case 'f':
    if (data) {
        ftmp = data;
        scprintf(2, 20, 0, "ftmp = %f", ftmp);
    }
    else {
        scprintf(2, 20, 0, "Data must have value");
    }
    break;
default:
    scprintf(2, 20, 0, "eng variable undefined");
}
}

```

```

/*****

```

```

    PAINT()

```

```

*****/

```

```

/*

```

```

Paint Routine:

```

```

    This routine paints or re-paints the static screen layout. */

```

```

paint()
{
    scprintf( 2, 2, 1, "ENGINE ");
    scprintf( 2, 4, 0, "ERPM= ");
    scprintf( 2, 5, 0, "ETRK= ");
    scprintf( 2, 6, 0, "ENFF= ");
    scprintf( 2, 7, 0, "EEGT= ");
    scprintf( 2, 8, 0, "EWTTP= ");
    scprintf( 2, 9, 0, "ENOT= ");
    scprintf( 2, 10, 0, "ENOP= ");
    scprintf( 2, 11, 0, "THST= ");
    scprintf( 2, 12, 0, "RACK= ");
    scprintf( 2, 13, 0, "PNT = ");
    scprintf( 2, 14, 0, "MT = ");
    scprintf( 2, 15, 0, "FTMP= ");
    scprintf(18, 2, 1, "CVT ");
    scprintf(17, 4, 0, "TRPM= ");
    scprintf(17, 5, 0, "TTRK= ");
    scprintf(17, 6, 0, "TWI = ");
    scprintf(17, 7, 0, "TOO = ");
    scprintf(17, 8, 0, "TCVT= ");
    scprintf(17, 9, 0, "TTNK= ");
    scprintf(17, 10, 0, "TOI = ");
    scprintf(17, 11, 0, "TWO = ");
}

```

```

    scprint(17, 12, 0, "OFF = ");
    scprint(17, 13, 0, "OFR = ");
    scprint(17, 14, 0, "RGST= ");
    scprint(17, 15, 0, "HSET= ");
    scprint(17, 16, 0, "FBST= ");
    scprint(34, 2, 1, "TRANS ");
    scprint(33, 4, 0, "PSOT= ");
    scprint(33, 5, 0, "FOOT= ");
    scprint(33, 6, 0, "GEAR= ");
    scprint(49, 2, 1, "DYNO ");
    scprint(49, 4, 0, "ORPM= ");
    scprint(49, 5, 0, "DTRK= ");
    scprint(49, 6, 0, "OWIT= ");
    scprint(49, 7, 0, "OWOT= ");
    scprint(33, 7, 0, "AIRT= ");
    scprint(66, 4, 0, "EPWR= ");
    scprint(66, 5, 0, "TPWR= ");
    scprint(66, 6, 0, "OPWR= ");
    scprint(66, 7, 0, "TEFF= ");
    scprint(33, 9, 1, "
    ");
    scprint(46, 10, 1, "PROGRAM CONTROL ");
    scprint(33, 12, 0, "TIMINT= ");
    scprint(33, 13, 0, "MONTIM= ");
    scprint(33, 14, 0, "DYCTIM= ");
    scprint(33, 15, 0, "HRCTIM= ");
    scprint(33, 16, 0, "OATTIM= ");
    scprint(33, 17, 0, "OATMAX= ");
    scprint(46, 12, 0, "MONFLG= ");
    scprint(46, 13, 0, "OYCFLG= ");
    scprint(46, 14, 0, "HRCFLG= ");
    scprint(46, 15, 0, "OATFLG= ");
    scprint(46, 16, 0, "ONLINE= ");
    scprint(60, 12, 1, "HTCONO ");
    scprint(63, 13, 0, "TTL= ");
    scprint(63, 14, 0, "O/A= ");
    scprint(60, 15, 1, "DYCOND ");

    moveto(99, 99);
}

```

```

/*****                                CLEANUP()                                *****/
/*
Cleanup Routine:
    This routine allows the user to write the entire contents
    of the common data structure to an external file for later
    examination. */

cleanup()
{
    FILE *fp, *fopen();

```



```

struct gv *gvptr;
struct hlda *hlptr;
struct tmpda *tmptr;
struct pulse *pulptr;

fp= fopen("Clean_up", "w");
gvptr= gvs;
hlptr= hldax;
tmptr= tmpdax;
pulptr= pulsex;

fprintf(fp, "Global variables.\n");
while(*gvptr->gvname)
{
    fprintf(fp, "%s %f\n", gvptr->gvname,
            *(gvptr->gvad));
    gvptr++;
}
fprintf(fp, "High level parameters.\n");
while(*hlptr->parm)
{
    fprintf(fp, "%s %d %d %f %f\n", hlptr->parm,
            hlptr->chan, hlptr->gain,
            hlptr->off, hlptr->calcon);
    hlptr++;
}
fprintf(fp, "Temperature parameters.\n");
while(*tmptr->parm)
{
    fprintf(fp, "%s %d %d\n", tmptr->parm, tmptr->chan,
            tmptr->type);
    tmptr++;
}
fprintf(fp, "Pulse card parameters.\n");
while(*pulptr->parm)
{
    fprintf(fp, "%s %d %f %f %f\n", pulptr->parm,
            pulptr->chan, pulptr->tbase,
            pulptr->const1, pulptr->const2);
    pulptr++;
}
fclose(fp);
}

```

```

/*****

```

```

    SPRINT()

```

```

*****/

```

```

/*

```

```

Scprint Routine:

```

```

    This routine is a modified version of the one which appears in
    kmon. */

```

```
/*VARARGS4*/
sprintf(x, y, att, fmt, args)
int x, y, att;
char *fmt;
{
    if (orphan) /* Kmon not here */
    {
        if (att) /* monitor is in trouble */
        {
            printf(" 7 7");
        }
        return;
    }
    movea(x, y, att);
    _doprnt(fmt, &args, stdout);
    attrib(0);
}
```

```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- SUPERVISOR
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        4/5/85
*   FILE:        doalarm.c
*
*****

```

```

#include <stdio.h>
#include <math.h>
#include <adac.h>
#include "control.h"

```

```

/*****                                DOALARM()                                *****/
/*

```

Doalarm Routine.

Doalarm provides the control allocation algorithms for all real time loops. This routine will be called any time that the UNIX system alarm goes off. */

```

doalarm()
{
    static dyfirst= 1;
    static htfirst= 1;
    static dtfirst= 1;
    static mnfirst= 1;
    static dyncnt= 1;
    static heatcnt= 1;
    static datcnt= 1;
    static moncnt= 1;

    alarmflag--;
    if (dyfirst && dycflg) {
        dyfirst= 0;
        dyn();
    }
    if (htfirst && hrcflg) {
        htfirst= 0;
        hcontrol(1);
    }
    if (dtfirst && datflg) {
        dtfirst= 0;
        dat();
    }
    if (mnfirst && monflg) {

```

```

        mnfirst= 0;
        mon();
    )
    if ((dyncnt*timint) == dyctim) && dycflg) {
        dyncnt= 0;
        dyn();
    }
    if ((heatcnt*timint) == hrctim) && hrcflg) {
        heatcnt= 0;
        hcontrol(0);
    }
    if ((datcnt*timint) == dattim) && datflg) {
        datcnt= 0;
        dat();
    }
    if ((moncnt*timint) == montim) && monflg) {
        moncnt= 0;
        mon();
    }
    if (dycflg == 0) {
        dyfirst= 1;
        dyncnt= 0;
    }
    if (hrcflg == 0) {
        htfirst= 1;
        heatcnt= 0;
    }
    if (datflg == 0) {
        dtfirst= 1;
        datcnt= 0;
    }
    if (monflg == 0) {
        mnfirst= 1;
        moncnt= 0;
    }

    dyncnt++;
    heatcnt++;
    datcnt++;
    moncnt++;
}

```

```

/*****
/*

```

DYN()

```

*****/

```

Dyn Routine.

The dyn routine provides the real time control for the dynamometer. At present this routine has not been completely developed. */

```

dyn()
{
    static int cnt= 0;

/* UNDEVELOPED */
    if (cnt == 0) {
        cnt = 1;
        sprintf(2, 17, 0, "dyno loop *");
        goto end;
    }

    if (cnt == 1) {
        cnt = 0;
        sprintf(2, 17, 0, "dyno loop* *");
    }
end:
    ;
}

/*****                                HCONTROL()                                *****/
/*
hcontrol Routine.
    The hcontrol routine provides the real time control
    for the cvt oll heater. This routine is fully developed. */

hcontrol(reset)
int reset;
{
    int out;
    static double told;
    double too, tcvt, ttnk, toi, ttap, control;
    double tmpmean();
    struct tmpda *tmptr;

    tmptr= &tmpdax[3];
    tcvt= tmpmean(tmptr->chan, tmptr->type, 3);
    tmptr= &tmpdax[8];
    too= tmpmean(tmptr->chan, tmptr->type, 3);
    tmptr= &tmpdax[10];
    ttnk= tmpmean(tmptr->chan, tmptr->type, 3);
    tmptr= &tmpdax[11];
    toi= tmpmean(tmptr->chan, tmptr->type, 3);
    tmptr= &tmpdax[12];
    ttap= tmpmean(tmptr->chan, tmptr->type, 3);

    if (reset) {
        told= too;
    }
}

```

```

control= 619.976*hset -210.098*too +467.982*told
        -749.86*(toi-ttnk) - 719.866*tcvt -125.0*ttap;
told= too;

sprintf(67, 12, 0, "%8.2f", control);
moveto(99,99);

out= ceil(control);
if (out <= 0) {
    out= 0;
}
if (out >= 4095) {
    out= 4095;
}
if (out < 2048) {
    ttlval= 0;
    daval= out;
}
if (out >= 2048) {
    ttlval= 1;
    daval= out -2048;
}

heat();
}

```

```

/*****                                HEAT()                                *****/
/*
Heat Routine.
Heat sets the outputs of the heaters. */

heat()
{
    dtoa(0, daval);
    ttlwb(2, ttlval);
}

```

```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- SUPERVISOR
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        4/5/85
*   FILE:        mon.c
*
*****

#include <stdio.h>
#include <adac.h>
#include "control.h"

/*****                                MON()                                *****/
/*
Mon Routine:
    Mon() is one of the real time loops. It collects all necessary
    data and analyzes it. Then it prints all data along with
    warnings to the static screen. */

mon()
{
    int  tf[2];
    char *p;
    double tempf();
    double tmpmean();
    struct hlda *hlptr;
    struct tmpda *tmptr;
    struct pulse *pulptr;
    struct limits *hllptr;
    struct limits *tmplptr;
    struct limits *pullptr;
    int i, dat, att, err;
    double value, oiltemp, flow;
    double epwr, tpwr, dpwr, teff, mt;

    scprintf(1, 21, 0, "

/* make request for data */
    err= do68k(2, 1);

    hlptr= hldax;
    tmptr= tmpdax;
    pulptr= pulsex;
    hllptr= hl_lim;
    tmplptr= tmp_lim;

```

```

pullptr= pul_lim;

/* the following checks erpm, etrk, trpm, ttrk, drpm, dtrk */
att= NORM;
time(t);
p= ctime(t);
sprint(50, 1, 0, "%s", p);
for (i=0; i<6; i++)
{
    dat= atodi(hlptr->chan, hlptr->gain);
    value= (dat - hlptr->off)*(hlptr->calcon);
    if (value >= *(hlptr->warn))
    {
        if (value >= *(hlptr->max))
            att= REVERSE;
        else
            att= UNDERLINE;
    }
    sprint(hlptr->a, hlptr->b, att, "%8.1f", value);
    att= NORM;
    hlptr++;
    hlptr++;
}

/* check engine oil pressure */
dat= atodi(hlptr->chan, hlptr->gain);
value= (dat - hlptr->off)*(hlptr->calcon);
if (value <= *(hlptr->warn))
{
    if (value <= *(hlptr->max))
        att= REVERSE;
    else
        att= UNDERLINE;
}
sprint(hlptr->a, hlptr->b, att, "%8.1f", value);
att=NORM;
hlptr++;

/* check fuel bucket (enff) */
dat= atodi(hlptr->chan, hlptr->gain);
value= (dat - hlptr->off)*(hlptr->calcon);
if (value <= enffmn) {
    att= REVERSE;
}

sprint(hlptr->a, hlptr->b, att, "%8.1f", value);
att= NORM;

```



```

/* check ewtp, eegt, enot, tcvt, twi, psot, fdot, dwot */
for (i=0; i<8; i++)
{
    value= tmpf(tmptr->chan, tmptr->type);
    if (value >= *(tmppltr->warn))
    {
        if (value >= *(tmppltr->max))
            att= REVERSE;
        else
            att= UNDERLINE;
    }
    sprintf(tmptr->c, tmptr->d, att, "%8.1f", value);
    att= NORM;
    tmptr++;
    tmppltr++;
}

/* check cvt oil in {too} */
value= tmpf(tmptr->chan, tmptr->type);
oiltemp= 67.8 -.63*value;
if ((value-hset) >= *(tmppltr->max))
    att= REVERSE;
if ((hset-value) >= *(tmppltr->warn))
    att= UNDERLINE;
sprintf(tmptr->c, tmptr->d, att, "%8.1f", value);
att= NORM;

/* find MT for cvt temp map */
tmptr= &tmpdax[8];
value= tmpmean(tmptr->chan, tmptr->type, 5);
tmptr= &tmpdax[3];
mt= tmpmean(tmptr->chan, tmptr->type, 5);
mt= (mt+value)/2.0;
sprintf(8, 14, att, "%8.1f", mt);

/* check ambient air temp */
tmptr= &tmpdax[9];
tmppltr++;
value= tmpmean(tmptr->chan, tmptr->type, 5);
if (value >= *(tmppltr->max))
    att= REVERSE;
if (value<= *(tmppltr->warn))
    att= UNDERLINE;
sprintf(tmptr->c, tmptr->d, att, "%8.1f", value);
att= NORM;

/* check cvt oll flows */
for(i=0; i<2; i++)
{

```

```

        value= (pul(pulptr->chan))/(pulptr->base);
        flow= value/((pulptr->const1)*(pow(value/oiltemp, 0.5))
            + (pulptr->const2));
        if (flow >= *(pulptr->max))
            att= REVERSE;
        if (flow<= *(pulptr->warn))
            att= UNDERLINE;
        sprintf(pulptr->e, pulptr->f, att, "%8.1f", flow);
        att= NORM;
        pulptr++;
        pulptr++;
    )

/* update dwit, tol, ttnk */
    tmptr= &tmpdax[12];
    value= tempf(tmptr->chan, tmptr->type);
    sprintf(tmptr->c, tmptr->d, 0, "%8.1f", value);

    tmptr= &tmpdax[11];
    value= tempf(tmptr->chan, tmptr->type);
    sprintf(tmptr->c, tmptr->d, 0, "%8.1f", value);

    tmptr= &tmpdax[10];
    value= tempf(tmptr->chan, tmptr->type);
    sprintf(tmptr->c, tmptr->d, 0, "%8.1f", value);

    tmptr= &tmpdax[13];
    value= tempf(tmptr->chan, tmptr->type);
    sprintf(tmptr->c, tmptr->d, 0, "%8.1f", value);

/* compute power and efficiency stats */
    hlptr= &hldax[0];
    dat= admean(hlptr->chan, hlptr->gain, 5);
    epwr= (dat -hlptr->off)*(hlptr->calcon);
    hlptr++;
    dat= admean(hlptr->chan, hlptr->gain, 5);
    value= (dat -hlptr->off)*(hlptr->calcon);
    epwr= epwr*value/5252.1131;

    hlptr++;
    dat= admean(hlptr->chan, hlptr->gain, 5);
    tpwr= (dat -hlptr->off)*(hlptr->calcon);
    hlptr++;
    dat= admean(hlptr->chan, hlptr->gain, 5);
    value= (dat -hlptr->off)*(hlptr->calcon);
    tpwr= tpwr*value/5252.1131;

    hlptr++;
    dat= admean(hlptr->chan, hlptr->gain, 5);
    dpwr= (dat -hlptr->off)*(hlptr->calcon);

```

```

hlpctr++;
dat= admean(hlpctr->chan, hlpctr->gain, 5);
value= (dat -hlpctr->off)*(hlpctr->calcon);
dpwr= dpwr*value/4000.00;

scprintf(72,4,0, "%6.1f", epwr);
scprintf(72,5,0, "%6.1f", tpwr);
scprintf(72,6,0, "%6.1f", dpwr);

if (epwr > 1) {
    teff= tpwr/epwr*100.0;
    att= NORM;
    if (teff < 75 ) {
        att = REVERSE;
    }
    scprintf(72,7,att, "%6.1f", teff);
}

/* update 68k table */
err= do68k(2, 2);
if (err == 3)
    scprintf(2, 21, 0, "68000 not responding");
if (err == 4)
    scprintf(2, 21, 0, "wrong number of arguments in 68000");
if (err == 5)
    scprintf(2, 21, 0, "S flag missing in 68000");

scprintf( 8, 12, 0, "%8d", rack);
scprintf( 8, 11, 0, "%8d", thstp);
scprintf(23, 14, 0, "%8d", rgstp);
scprintf(23, 16, 0, "%8d", fbstp);
scprintf(39, 6, 0, "%8d", gear);

/* update the program control flags */
scprintf(40, 12, 0, "%4d", timint);
scprintf(40, 13, 0, "%4d", montim);
scprintf(40, 14, 0, "%4d", dyctim);
scprintf(40, 15, 0, "%4d", hrcrim);
scprintf(40, 16, 0, "%4d", dattim);
scprintf(40, 17, 0, "%4d", datmax);
scprintf(53, 12, 0, "%2d", monflg);
scprintf(53, 13, 0, "%2d", dyeflg);
scprintf(53, 14, 0, "%2d", hrcflg);
scprintf(53, 15, 0, "%2d", datflg);
scprintf(53, 16, 0, "%2d", online);
scprintf(67, 13, 0, "%6d", ttlval);
scprintf(67, 14, 0, "%6d", daval);

```

```
/* update heater control setpoint */  
    scprint(23, 15, 0, "%8.1f", hset);  
    scprint( 8, 13, 0, "%s  ", point);  
    scprint( 8, 14, 0, "%8.1f", api);  
    scprint( 8, 15, 0, "%8.1f", ftmp);  
  
    moveto(99,99);  
}
```

```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- SUPERVISOR
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   OATE:        4/5/85
*   FILE:        cvtlinear.c
*
*****

```

```

#include <stdio.h>
#include <adac.h>
#include "control.h"

```

```

/*****                                DAT()                                *****/
/*

```

Dat Routine.

The dat routine provides the data recording procedures.
 There are numerous versions of this routine used for
 different tests. This particular version was used to collect
 the CVT data. */

```

dat()
{
    int t[2];
    char *p;
    struct hlda *hlptr;
    struct tmpda *tmptr;
    double tmpmean();
    int dat, err, errcnt, num, wait;
    static cnt=0;
    double enot, atmp, enop, cnwt, eegt, erpm, etrk, enff;
    double trpm, ttrk, tcvt, too;

    sprintf(1,22,0,"                                ");

    num = cnt + 1;

    if (cnt == 0) {
        time(t);
        p= ctime(t);
        fprintf(dfptr, "%s", p);
        fprintf(dfptr, "%s %10.3f %10.3f\n", point, api, ftmp);

        tmptr= &tmpdax[0];
        enwt= tmpmean(tmptr->chan, tmptr->type, 9);
        tmptr++;
    }
}

```

```

    eegt= tmpmean(tmptr->chan, tmptr->type, 9);
    tmptr++;
    enot= tmpmean(tmptr->chan, tmptr->type, 9);
    tmptr++;
    tcvt= tmpmean(tmptr->chan, tmptr->type, 9);
    tmptr= &tmpdax[8];
    too= tmpmean(tmptr->chan, tmptr->type, 9);
    tmptr= &tmpdax[9];
    atmp= tmpmean(tmptr->chan, tmptr->type, 9);
    hlptr= &hldax[6];
    dat= admean(hlptr->chan, hlptr->gain, 9);
    enop= (dat - hlptr->off) * hlptr->calcon;

    fprintf(dfptr, "%9.3f %9.3f %9.3f %9.3f %9.3f %9.3f %9.3f\n",
            enot, enop, enwt, eegt, tcvt, too, atmp);

    req= 1;
    sprintf(50, 19, 0, "DATCNT= ");
}

sprintf(58, 19, 0, "%5d", num);
err= do68k(3, 1);

hlptr= &hldax[0];
dat= admean(hlptr->chan, hlptr->gain, 9);
erom= (dat - hlptr->off) * hlptr->calcon;
hlptr++;
dat= admean(hlptr->chan, hlptr->gain, 9);
etrk= (dat - hlptr->off) * hlptr->calcon;
hlptr++;
dat= admean(hlptr->chan, hlptr->gain, 9);
trpm= (dat - hlptr->off) * hlptr->calcon;
hlptr++;
dat= admean(hlptr->chan, hlptr->gain, 9);
trrk= (dat - hlptr->off) * hlptr->calcon;
hlptr= &hldax[7];
dat= admean(hlptr->chan, hlptr->gain, 9);
enff= (dat - hlptr->off) * hlptr->calcon;

errcnt= 0;
while (errcnt < 1000) {
    errcnt++;
    wait= 0;
    while (wait < waitmx) {
        wait++;
    }
}

err= do68k(3, 2);
if (err == 1) {
    fprintf(dfptr, "***Error 68k Not Here\n");
}

```

```

if (err == 3) {
    fprintf(dfptr, "***Error 68k Not Responding\n");
    scprint(2, 22, 0, "Error 68k Not Responding");
}
if (err == 4) {
    fprintf(dfptr, "***Error 68k Argument Error\n");
    scprint(2, 22, 0, "Error 68k Argument Error");
}
if (err == 5) {
    fprintf(dfptr, "***Error 68k Format Error\n");
    scprint(2, 22, 0, "Error 68k Format Error");
}

fprintf(dfptr, "%9.3f %9.3f %9.3f %8d %8d %8d %9.3f %9.3f\n",
        erpm, etrk, enff, thstp, rack, fbstp, trpm, ttrk);

cnt++;
if (cnt >= datmax)
{
    datflg= 0;
    cnt= 0;
    req= 0;
    fprintf(dfptr, "\n");
    fclose(dfptr);
    scprint( 2, 19, 0, " ");
    scprint(50, 19, 0, " ");
    scprint(1,22,0," ");
}

moveto(99,99);
}

```

APPENDIX C

MC68000ECB HARDWARE




Figure 7 MC68000 Educational Computer Board

Table 3 Bus Expansion Buffer: Parts List

REFERENCE DESIGNATION	DESCRIPTION	
R1, R2, R4	Resistor, film, 270 ohm, 5%, 1/4 W	
R3	Resistor, film, 180 ohm, 5%, 1/4 W	
R5, R6	Resistor, film, 3.3k ohm, 5%, 1/4 W	
U1	I.C. SN74LS245N	Octal Bus Transceiver
U2, U3, U4	I.C. SN74LS244N	Octal Bus Buffer
U5	I.C. SN74LS07N	Hex Buffer
U6	I.C. SN74LS11N	Triple Three AND Gates
U7	I.C. SN74LS04N	Hex Inverter




Figure 9 Bus Expansion Buffer: Board Layout

Table 4 I/O Expansion: Parts List

REFERENCE DESIGNATION	DESCRIPTION
R1, R2	Resistor, film, 68k ohm, 5%, 1/4 W
R3, R5, R7, R9, R11, R13, R15, R17, R29, R32, R33, R35, R37, R39, R41, R43, R51, R53, R55, R57, R59, R61, R63, R65	Resistor, film, 220 ohm, 5%, 1/4 W
R4, R6, R8, R10, R12, R14, R16, R18, R30, R31, R34, R36, R38, R40, R42, R44, R52, R54, R56, R58, R60, R62, R64, R66	Resistor, film, 390 ohm, 5%, 1/4 W
R19, R20, R67, R68, R69, R70, R71, R72, R73, R74	Resistor, film, 4.7k ohm, 5%, 1/4 W
R21, R22, R23, R24, R25, R26, R27, R28	Resistor, film, 1k ohm, 5%, 1/4 W
R45, R46, R47, R48, R49, R50	Resistor, film, 2.2k ohm, 5%, 1/4 W
U1	I.C. SN74LS260N Dual 5-input NOR
U2	I.C. SN74LS138N 3-to-8 Line Decoder
U3, U4	I.C. MC68230L8 PI/T
U5, U6, U7, U8, U9	I.C. SN74LS90N Decade Counter

Table 4 --cont.

REFERENCE DESIGNATION	DESCRIPTION	
U10	I.C. SN74LS08N	Quad 2-Input AND
U11, U12	I.C. SAA1042	Stepper Motor Driver
U13, U14, U25, U32, U33	I.C. SN74LS05N	OC Hex Inverter
U15, U16, U17, U18, U19, U20, U21, U22, U23, U24, U26, U27, U28, U29, U30, U31, U34, U35, U36, U37, U38, U39, U40, U41	I.C. 4N33	Opto-Isolator
U42, U43	Spaulding's Incremental Encoder Counters	




Figure 11 I/O Expansion: Schematic





Figure 11 --cont.






Figure 11 --cont.




Figure 12 Digital Inputs: Schematic

MEYER/DIGITAL INPUTS
SHEET 1 OF 1
KENT D. FUNK 12-7-85

Table 5 High Current Outputs: Parts List

REFERENCE DESIGNATION	DESCRIPTION
D1, D2, D3, D4, D5, D6, D7, D8, D9, D10, D11, D12, D13, D14	SK5040 Silicon Fast Recovery Rectifier
R1, R2	Resistor, power, 2.6 ohm, 10%, 20 W
R3, R4	Resistor, power, 1.1 ohm, 10%, 65 W
T1, T2, T3, T4, T5, T6, T7, T8, T9, T10, T11, T12, T13, T14	SK3180 NPN Si AF Darlington Transistor




Figure 13 High Current Outputs: Schematic




Figure 13 --cont.




Figure 13 --cont.




Figure 13 --cont.

APPENDIX D

MC68000ECB SOFTWARE LISTINGS

```

*****
*
*
* SUPPLEMENTAL LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
* CVT -- ENGINE PROJECT -- CONTROLLER
*
* DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
* AUTHOR: KENT O. FUNK
* DATE: 8/17/85
* FILE: screenlayout
*
*****

```

CONSOLE SCREEN LAYOUT

```

P-INIT
E-INIT
  SET ENABLES ON
    CONTINUE? <ret>
  START ENGINE
    CONTINUE? <ret>

```

```

CVT CONTROLLER
  CREATEO BY K FUNK

```

```

CURRENT STATUS:
RACK= XXXXXXXX
THSTP= XXXXXXXX
RGSTP= XXXXXXXX
FBSTP= XXXXXXXX
GEAR= XXXXXXXX

```

```

ENTER NEW OATA:
THSTP ? <user response>
RGSTP ? <user response>
GEAR ? <user response>

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*   CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        B/17/85
*   FILE:        global.s
*   TYPE:        Common Data Structures -- global
*
*****

```

DATA STRUCTURES:

GLOBAL PROGRAM SCOPE...

global program data allocation (\$900 to \$DFF)

```

-----
000900      .
          .
          .   console buffer (80 ASCII characters)
          .
          .
0009A0----- (Console buffer End)
-----

```

```

-----
0009B0 hbyte  RACK          (current external conditions)
0009B1 lbyte
-----
0009B2 hbyte  THSTP
0009B3 lbyte
-----
0009B4 hbyte  RGSTP
0009B5 lbyte
-----
0009B6 hbyte  FBSTEP
0009B7 lbyte
-----
0009B8 hbyte  GEAR
0009B9 lbyte
-----

```

```

-----
0009C0 hbyte  THSTP          (desired external conditions)
0009C1 lbyte
-----
0009C2 hbyte  RGSTP

```

```

0009C3  lbyte

0009C4  hbyte  GEAR
0009C5  lbyte

```

```

GLOBAL TRAP #14 SCOPE...
      global trap #14 data allocation ($5000 to $507F)

```

```

005000= $00006000  (p-init)          (trap extension table)
005004= $01006100  (e-init)
005008= $02006200  (move-th)
00500C= $03006300  (move-cvt)
005010= $04006400  (set-gear)
005014= $05006500  (read-rack)
005018= $06006600  (test-stable)
00501C= $07006700  (reg-save)
005020= $08006800  (reg-restore)
005024= $09006900  (read-thstp)
005028= $0A006A00  (setup)
00502C= $0B006950  (read-fbstp)
005030= $0C006D00  (unassigned)
005034= $0D006E00  (unassigned)
005038= $0E006F00  (unassigned)
00503C= $0F006F80  (unassigned)
005040= $00000000  (reserved for link address to ROM table)
005044-----      (extension table End)

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        8/17/85
*   FILE:        main.s
*   TYPE:        Sequential Program Execution -- main
*
*****

```

SYNOPSIS:

MAIN provides the control code for all normal sequential program execution. Throughout the main program, numerous software interrupts are generated (TRAP #14) in order to initialize and communicate with all system hardware. Currently, the main LOOP provides an interactive environment (not real time controlled) by which the user can manipulate the drive train. This configuration is useful for data mapping and system debugging.

To Start the Program;

GO 1000

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:

PROGRAM--

current external conditions
desired external conditions

TRAP #14--

trap extension table

LOCAL MAIN SCOPE...

local data allocation (\$E00 to \$FFF)

```

-----
000E00= $0D0A          (Header String)
000E02= 'CV'
000E04= 'T '
000E06= 'CO'
000E08= 'NT'
000E0A= 'RO'
000E0C= 'LL'

```

```

000E0E= 'ER'
000E10= $0DOA
000E12= $2020
000E14= $2020
000E16= 'CR'
000E18= 'EA'
000E1A= 'TE'
000E1C= 'D '
000E1E= 'BY'
000E20= ' K'
000E22= ' F'
000E24= 'UN'
000E26= 'K '
000E28= $0DOA
000E2A= $0A0A
000E2C= 'CU'
000E2E= 'RR'
000E30= 'EN'
000E32= 'T '
000E34= 'ST'
000E36= 'AT'
000E38= 'US'
000E3A= ':' '
000E3C= $0DOA
000E3E----- (Header String End)

```

```

-----
000E40= 'RA' (Data String)
000E42= 'CK'
000E44= '= '
000E46= $2020 (Rack-Start= $E46)
000E48= $2020
000E4A= $2020
000E4C= $2020
000E4E= $000A

000E50= 'TH'
000E52= 'ST'
000E54= 'P='
000E56= $2020 (TH-Start= $E56)
000E58= $2020
000E5A= $2020
000E5C= $2020
000E5E= $0DOA

000E60= 'RG'
000E62= 'ST'
000E64= 'P='
000E66= $2020 (RG-Start= $E66)
000E68= $2020

```

```

000E6A= $2020
000E6C= $2020
000E6E= $0D0A

000E70= 'PB'
000E72= 'ST'
000E74= 'P='
000E76= $2020 (F8-Start= $E76)
000E78= $2020
000E7A= $2020
000E7C= $2020
000E7E= $0D0A

000E80= 'GE'
000E82= 'AR'
000E84= '='
000E86= $2020 (Gear-Start= $E86)
000E88= $2020
000E8A= $2020
000E8C= $2020
000E8E= $0D0A
000E90= $0A0A
000E92----- (Data String End)
-----

```

MAIN:

```

Link Trap #14 extension table to ROM table
001000 207C00005000 MOVE.L #20480,A0 define starting
table address
call LINKIT

001006 1E3C00FD MOVE.B #253,D7
00100A 4E4E TRAP #14
00100C 21C85040 MOVE.L A0,$00005040 move linking
pointer to end of
trap extension
table (points to
standard ROM table)
call p-init

001010 1E3C0000 MOVE.B #0,D7
001014 4E4E TRAP #14
001016 1E3C0001 MOVE.B #1,D7 call e-init
00101A 4E4E TRAP #14

```

BEGIN LOOP:

```

Write Header String to Console
00101C 2A7C00000E00 MOVE.L #3584,A5 starting address
001022 2C7C00000E3E MOVE.L #3646,A6 ending address
001028 1E3C00F3 MOVE.B #243,D7 call OUTPUT
00102C 4E4E TRAP #14

```

Blank out old values in Data String with spaces

```
00102E 21FC202020200E46 MOVE.L #538976288,$00000E46
001036 21FC202020200E4A MOVE.L #538976288,$00000E4A
00103E 21FC202020200E56 MOVE.L #538976288,$00000E56
001046 21FC202020200E5A MOVE.L #538976288,$00000E5A
00104E 21FC202020200E66 MOVE.L #538976288,$00000E66
001056 21FC202020200E6A MOVE.L #538976288,$00000E6A
00105E 21FC202020200E76 MOVE.L #538976288,$00000E76
001066 21FC202020200E7A MOVE.L #538976288,$00000E7A
00106E 21FC202020200E86 MOVE.L #538976288,$00000E86
001076 21FC202020200EBA MOVE.L #538976288,$00000E8A
```

Call subroutine GETOATA:

```
00107E 4EBB1300 JSR.S $00001300
```

Prepare Oata String by converting hex data to decimal
and then storing results at their appropriate
position in Data String.

RACK;

```
0010B2 4280 CLR.L 00
0010B4 303B09B0 MOVE.W $000009B0,00      get hex value of
                                         rack from current
                                         conditions
                                         structure
0010B8 2C7C00000E46 MOVE.L #3654,A6      get Rack-Start in
                                         Data String
0010BE 1E3C00EC MOVE.B #236,07      call HEX2OEC
001092 4E4E TRAP #14
```

THSTP;

```
001094 42B0 CLR.L D0
001096 303B09B2 MOVE.W $000009B2,00      get hex value of
                                         thstp from current
                                         conditions
                                         structure
00109A 2C7C00000E56 MOVE.L #3670,A6      get TH-Start in
                                         Oata String
0010A0 1E3C00EC MOVE.B #236,07      call HEX2OEC
0010A4 4E4E TRAP #14
```

RGSTP;

```
0010A6 4280 CLR.L 00
0010A8 303B0984 MOVE.W $000009B4,00      get hex value of
                                         rgstp from current
                                         conditions
                                         structure
0010AC 2C7C00000E66 MOVE.L #3686,A6      get RG-Start in
                                         Data String
0010B2 1E3C00EC MOVE.B #236,07      call HEX2OEC
0010B6 4E4E TRAP #14
```



```

                                FBSTP;
0010B8 4280                    CLR.L  D0
0010BA 303809B6                MOVE.W $000009B6,D0      get hex value of
                                                           fbstp from current
                                                           conditions
                                                           structure
0010BE 2C7C00000E76            MOVE.L #3702,A6          get FB-Start in
                                                           Data String
0010C4 1E3C00EC                MOVE.B #236,D7          call HEX2DEC
0010C8 4E4E                    TRAP  #14
                                GEAR;
0010CA 4280                    CLR.L  00
0010CC 303809B8                MOVE.W $000009B8,D0      get hex value of
                                                           gear from current
                                                           conditions
                                                           structure
0010D0 2C7C00000E86            MOVE.L #3718,A6          get Gear-Start in
                                                           Data String
0010D6 1E3C00EC                MOVE.B #236,D7          call HEX2DEC
0010DA 4E4E                    TRAP  #14
                                Write Data String to Console
0010DC 2A7C00000E40            MOVE.L #3648,A5          starting address
0010E2 2C7C00000E92            MOVE.L #3730,A6          ending address
0010E8 1E3C00F3                MOVE.B #243,D7          call OUTPUT
0010EC 4E4E                    TRAP  #14

                                Call COMPUTE (new desired position) subroutine
0010EE 4EB82000                JSR.S  $00002000
                                Set new outputs
0010F2 1E3C0002                MOVE.B #2,D7            call move-throttle
0010F6 4E4E                    TRAP  #14
0010F8 1E3C0003                MOVE.B #3,D7            call move-cvt
0010FC 4E4E                    TRAP  #14
0010FE 1E3C0004                MOVE.B #4,D7            call set-gear
001102 4E4E                    TRAP  #14
001104 1E3C0006                MOVE.B #6,D7            call test-stable
001108 4E4E                    TRAP  #14

                                Update data structures
                                Current == Desired
00110A 4E71                    NOP
00110C 4E71                    NOP
00110E 4E71                    NOP
001110 31F809C209B4            MOVE.W $000009C2,$000009B4 rgstp
001116 31F809C409B8            MOVE.W $000009C4,$000009B8 gear
                                Jump to LOOP
00111C 4EF8101C                JMP.S  $0000101C
ENO LOOP:
END MAIN= $1120

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT O. FUNK
*   OATE:        8/17/85
*   FILE:        getdat.sub.s
*   TYPE:        Sequential Program Execution -- subroutine
*
*****

```

SYNOPSIS:

GETDAT is a subroutine called by MAIN. The purpose of the subroutine is to collect all data needed by the program. This data consists of the digital inputs under direct control of the MC68000, and the Analog inputs under the AOAC 1000 control.

Currently only the digital inputs are read, since the desired outputs are determined by interactive user responses.

To Call;
JSR \$1300

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:
current external conditions

LOCAL GETDATA SCOPE...
local data allocation (\$1200 to \$12FF)

GETDATA:

```

    Read external data under direct access of controller
001300 1E3C0005      MOVE.B #5,07          call read-rack
001304 4E4E         TRAP    #14

001306 1E3C0009      MOVE.B #9,07          call read-thstp
00130A 4E4E         TRAP    #14

00130C 1E3C000B      MOVE.B #11,07         call read-fbstp
001310 4E4E         TRAP    #14
001312 4E75         RTS
ENO GETDATA= $1314

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        8/17/85
*   FILE:        compute.sub.s
*   TYPE:        Sequential Program Execution -- subroutine
*
*****

```

SYNOPSIS:

COMPUTE is a subroutine called by MAIN. The purpose of this subroutine is to compute the new desired outputs based upon the current operating state of the drive line.

Currently, the subroutine interactively communicates with the user to determine what the new desired operating state should be. In it's final form, this subroutine will implement the optimization algorithm. All inputs to the subroutine will be obtained by the GETDAT subroutine.

To Call;
JSR \$2000

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:
console buffer
desired external conditions

LOCAL COMPUTE SCOPE...
local data allocation (\$1500 to \$1FFF)

```

-----
001500= 'EN'                (String #1)
001502= 'TE'
001504= 'R '
001506= 'NE'
001508= 'W '
00150A= 'DA'
00150C= 'TA'
00150E= ': '
001510= $0DOA
001512----- (String #1 End)
-----

```

```

-----
001514= 'TH'                (String #2)
001516= 'ST'
001518= 'P '
00151A= '? '
00151C----- (String #2 End)
-----

```

```

-----
00151E= 'RG'                (String #3)
001520= 'ST'
001522= 'P '
001524= '? '
001526----- (String #3 End)
-----

```

```

-----
001528= 'GE'                (String #4)
00152A= 'AR'
00152C= ' ? '
00152E= $0020
001530----- (String #4 End)
-----

```

COMPUTE:

Write String #1 to Console

002000	2A7C00001500	MOVE.L #5376,A5	starting address
002006	2C7C00001512	MOVE.L #5394,A6	ending address
00200C	1E3C00F3	MOVE.B #243,D7	call OUTPUT
002010	4E4E	TRAP #14	

Write String #2 to Console

002012	2A7C00001514	MOVE.L #5396,A5	starting address
002018	2C7C0000151C	MOVE.L #5404,A6	ending address
00201E	1E3C00F3	MOVE.B #243,D7	call OUTPUT
002022	4E4E	TRAP #14	

Get a string from the Console

002024	2A7C00000900	MOVE.L #2304,A5	console buffer
			starting address
00202A	2C4D	MOVE.L A5,A6	
00202C	1E3C00F1	MOVE.B #241,D7	call PORTIN1
002030	4E4E	TRAP #14	

Convert console buffer string to hex and store result in Desired Condition Structure

002032	4280	CLR.L D0	
002034	BDCD	CMP.L A5,A6	skip if null

```

002036 670A          BEQ.S  $002042          line
002038 1E3C00E1      MOVE.B  #225,07        call GETNUMD
00203C 4E4E          TRAP   #14
00203E 31C009C0      MOVE.W  00,$000009C0    store at Oesired
                                           THSTP

    Write String #3 to Console
002042 2A7C0000151E    MOVE.L  #5406,A5        starting address
002048 2C7C00001526    MOVE.L  #5414,A6        ending address
00204E 1E3C00F3      MOVE.B  #243,07        call OUTPUT
002052 4E4E          TRAP   #14

    Get a string from the Console
002054 2A7C00000900    MOVE.L  #2304,A5        console buffer
                                           starting address
00205A 2C40          MOVE.L  A5,A6
00205C 1E3C00F1      MOVE.B  #241,D7        call PORTIN1
002060 4E4E          TRAP   #14

    Convert console buffer string to hex and store results
    in Oesired Condition Structure
002062 4280          CLR.L  00
002064 B0C0          CMP.L  A5,A6        skip if null
002066 670A          BEQ.S  $002072          line
002068 1E3C00E1      MOVE.B  #225,07        call GETNUMD
00206C 4E4E          TRAP   #14
00206E 31C009C2      MOVE.W  00,$000009C2    store at Oesired
                                           KGSTP

    Write String #4 to Console
002072 2A7C00001528    MOVE.L  #5416,A5        starting address
002078 2C7C00001530    MOVE.L  #5424,A6        ending address
00207E 1E3C00F3      MOVE.B  #243,07        call OUTPUT
002082 4E4E          TRAP   #14

    Get a string from the Console
002084 2A7C00000900    MOVE.L  #2304,A5        console buffer
                                           starting address
00208A 2C40          MOVE.L  A5,A6
00208C 1E3C00F1      MOVE.B  #241,D7        call PORTIN1
002090 4E4E          TRAP   #14

    Convert console buffer string to hex and store result
    in Desired Condition Structure
002092 4280          CLR.L  00
002094 B0CD          CMP.L  A5,A6        skip if null
002096 670A          BEQ.S  $0020A2          line
002098 1E3C00E1      MOVE.B  #225,07        call GETNUMD
00209C 4E4E          TRAP   #14
00209E 31C009C4      MOVE.W  D0,$000009C4    store at Desired
                                           GEAR
0020A2 4E75          RTS
END COMPUTE= $20A4

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        8/17/85
*   FILE:        ginit.s
*   TYPE:        Software Interrupt Processing -- level 0
*
*****

```

SYNOPSIS:

P-INIT initializes the peripherals which are contained on the 68000 ECB. Configurations are set for the host ACIA the system real time interrupts and the normal shut down interrupt. Auto Vector interrupts are established for these devices and the CPU is set to Supervisory Mode. In addition the short message "P-INIT" is displayed on the Console indicating successful initialization.

```

TO CALL:
        MOVE.B #00,D7
        TRAP   #14

```

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:
none

LOCAL P-INIT SCOPE...

```

-----
005080= 'P-'           (pinit string)
005082= 'IN'
005084= 'IT'
005086= $0DOA
005088=----- (pinit string End)
-----

```

P-INIT:

```

        Initialize Auto Vector Interrupts
        Host Interrupt Vector= $7000
006000 21FC000070000078 MOVE.L #28672,$00000078      host interrupt

```

```

        Configure Host ACIA #2
006008 123900010041      MOVE.B $00010041,D1      dumb read on
                                                    receive register
00600E 123900010043      MOVE.B $00010043,D1      dumb read on
                                                    transmit register
006014 13FC009500010041 MOVE.B #149,$00010041     set control
                                                    register format

        Write "P-INIT" string to Console
00601C 2A7C00005080      MOVE.L #20608,A5          starting address
006022 2C7C00005088      MOVE.L #20616,A6          ending address
006028 1E3C00F3          MOVE.B #243,D7            call OUTPUT
00602C 4E4E              TRAP    #14

        Set CPU to Supervisory Mode
00602E 46FC2000          MOVE.W #8192,SR
006032 4E75              RTS
END PINIT= $6034

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*   CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:       8/17/85
*   FILE:       einit.s
*   TYPE:       Software Interrupt Processing -- level 1
*
*****

```

SYNOPSIS:

E-INIT initializes the peripherals which are contained on the expansion bus. Configurations are set for both off board PI/T's to be used for bit I/O and stepper motor controllers. Finally E-INIT calls SETUP which conducts an interactive mode of initializing the physical engine and transmissions.

```

TO CALL;
      MOVE.B #01,D7
      TRAP   #14

```

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:
none

LOCAL E-INIT SCOPE...

```

-----
0050C8= 'E-'                (einit string #1)
0050CA= 'IN'
0050CC= 'IT'
0050CE= $0D0A
0050D0----- (einit string #1 End)
-----

```

```

-----
00508A= $2020                (einit string #2)
00508C= $2020
00508E= 'SE'
005090= 'T '
005092= 'EN'
005094= 'AB'
005096= 'LE'

```



```

005098= 'S '
00509A= 'ON'
00509C= $000A
00509E----- (einit string #2 End)
-----

```

E-INIT:

```

      Write einit string #1 to Console
006100 2A7C000050C8      MOVE.L #206B0,A5      starting address
006106 2C7C000050D0      MOVE.L #206BB,A6      ending address
00610C 1E3C00F3          MOVE.B #243,07      call OUTPUT
006110 4E4E              TRAP #14

      Initialize PI/T #1 Base Address= $20000
006112 13FC000000020001 MOVE.B #0,$00020001      Port General
                                                    Control Register
00611A 13FC000000020003 MOVE.B #0,$00020003      Port Service
                                                    Request Register
006122 13FC008000020000 MOVE.B #12B,$0002000D      Port A Control
                                                    Register
00612A 13FC00FF00020005 MOVE.B #255,$00020005      Port A Oata
                                                    Oirection Register
006132 13FC000000020011 MOVE.B #0,$00020011      Port A Data
                                                    Register
00613A 13FC00800002000F MOVE.B #128,$0002000F      Port B Control
                                                    Register
006142 13FC000000020007 MOVE.B #0,$00020007      Port B Oata
                                                    Oirection Register
00614A 13FC000300020009 MOVE.B #3,$00020009      Port C Oata
                                                    Oirection Register
006152 13FC000000020027 MOVE.B #0,$00020027      Counter Preload
                                                    Register High
00615A 13FC000000020029 MOVE.B #0,$00020029      Counter Preload
                                                    Register Mid
006162 13FC00010002002B MOVE.B #1,$0002002B      Counter Preload
                                                    Register Low
00616A 13FC00A700020021 MOVE.B #167,$00020021      Timer Control
                                                    Register

      Initialize PI/T #2 Base Address= $20200
006172 13FC000000020201 MOVE.B #0,$00020201      Port General
                                                    Control Register
00617A 13FC000000020203 MOVE.B #0,$00020203      Port Service
                                                    Request Register
0061B2 13FC000300020209 MOVE.B #3,$00020209      Port C Oata
                                                    Direction Register
00618A 13FC000000020227 MOVE.B #0,$00020227      Counter Preload
                                                    Register High
006192 13FC000000020229 MOVE.B #0,$00020229      Counter Preload
                                                    Register Mid
00619A 13FC00010002022B MOVE.B #1,$0002022B      Counter Preload

```

0061A2	13FC00A700020221	MOVE.B #167,\$00020221	Register Low
			Timer Control
0061AA	13FC000000020205	MOVE.B #0,\$00020205	Register
			Port A Data
006182	13FC00800002020D	MOVE.B #128,\$0002020D	Direction Register
			Port A Control
0061BA	13FC00FF00020207	MOVE.B #255,\$00020207	Register
			Port B Data
0061C2	13FC00B00002020F	MOVE.B #128,\$0002020F	Direction Register
			Port B Control
			Register
0061CA	13FC001C00020213	MOVE.B #28,\$00020213	Port B Data
			Register

Write einit string #2 to Console

prompts user to switch external power "on"

0061D2	2A7C000050BA	MOVE.L #20618,A5	starting address
0061D8	2C7C0000509E	MOVE.L #20638,A6	ending address
0061DE	1E3C00F3	MOVE.B #243,D7	call OUTPUT
0061E2	4E4E	TRAP #14	

Complete physical system initialization

0061E4	1E3C000A	MOVE.B #10,D7	call setup
0061EB	4E4E	TRAP #14	
0061EA	4E75	RTS	
END E-INIT= \$61EC			

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTROR:      KENT D. FUNK
*   DATE:        8/17/85
*   FILE:        thmove.s
*   TYPE:        Software Interrupt Processing -- level 2
*
*****

```

SYNOPSIS:

MOVE-TR provides the software interface to the stepper motor driver associated with the engine throttle. The associated hardware requires the following inputs:

- 1) Direction control (PI/T #1 portC-1)
 - CW (active low)
 - CCW (active high)
- 2) Step size (PI/T #1 portC-0)
 - For the throttle stepper motor Step Size = RALF (active high)
- 3) Clock pulse control (PI/T #1 timer)
 - One clock pulse per step

MOVE-TR determines the relative number of steps to be moved in a particular direction by knowledge of the Current TRSTP and the Desired THSTP by the following description.

```

    if (desired > actual) {
        move (desired - actual) half steps in CW direction;
    }
    else if ( actual > desired) {
        move (actual - desired) half steps in CCW direction;
    }
    else if ( actual == desired) {
        do nothing;
    }

```

TO CALL;

```

    MOVE.B #02,D7
    TRAP   #14

```

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:

Program:

current external conditions
desired external conditions

LOCAL MOVE-TH SCOPE...

```
-----
005150                                (temporary)
005151      (4 consecutive bytes for temporary allocation
005152      for use in byte addressing of final results)
005153
-----
```

MOVE-TH:

```
006200 42B0      CLR.L  D0
006202 42B1      CLR.L  01
006204 303809C0  MOVE.W  $000009C0,D0      get desired THSTP
00620B 323B09B2  MOVE.W  $000009B2,01      get current THSTP
00620C B041      CMP.W   D1,D0              check (00-01) or
                                           (desired -actual)
00620E 6E1A      BGT.S   $00622A           branch if (desired
                                           > actual)
006210 674C      BEQ.S   $00625E           branch if (desired
                                           == actual)
006212 4E71      NOP
006214 4E71      NOP

      Set conditions for actual > desired
006216 92B0      SUB.L   00,01              compute actual -
                                           desired (01-00 to
                                           D1)
00621B 21C15150  MOVE.L  01,$00005150      store results in
                                           temporary local
                                           structure
00621C 13FC000300020019  MOVE.B  #3,$00020019  set half step, CCW
                                           direction at port C
006224 6016      BRA.S   $00623C
006226 4E71      NOP
00622B 4E71      NOP

      Set conditions for desired > actual
00622A 9081      SUB.L   01,00              compute desired -
                                           actual (00-01 to
                                           00)
00622C 21C05150  MOVE.L  00,$00005150      store results in
                                           temporary local
                                           structure
```

```

006230 13FC000100020019 MOVE.B #1,$00020019      set half step, CW
                                                    direction at port C
006238 4E71                      NOP
00623A 4E71                      NOP
           Move temporary structure to timer
00623C 13F8515100020027 MOVE.B $00005151,$00020027 store temporary
                                                    2nd byte in timer
                                                    preload register
                                                    (high)
006244 13F8515200020029 MOVE.B $00005152,$00020029 store temporary
                                                    3rd byte in timer
                                                    preload register
                                                    (mid)
00624C 13F851530002002B MOVE.B $00005153,$00020028 store temporary
                                                    4th byte in timer
                                                    preload register
                                                    (low)
006254 13FC000100020035 MOVE.B #1,$00020035      start timer
00625C 4E71                      NOP
00625E 4E75                      RTS
END MOVE-TH= $6260

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        8/17/85
*   FILE:        cvtmov.s
*   TYPE:        Software Interrupt Processing -- level 3
*
*****

```

SYNOPSIS:

MOVE-CVT provides the software interface to the stepper motor driver associated with the CVT transmission. The associated hardware requires the following inputs:

- 1) Direction control (PI/T #2 portC-1)
 - CW (active low)
 - CCW (active high)
- 2) Step size (PI/T #2 portC-0)
 - For the CVT stepper motor Step Size = HALF (active high)
- 3) Clock pulse control (PI/T #2 timer)
 - One clock pulse per step

MOVE-CVT determines the relative number of steps to be moved in a particular direction by knowledge of the Current RGSTP and the Desired RGSTP by the following description.

```

if (desired > actual) {
    move (desired - actual) half steps in CW direction;
}
else if ( actual > desired) {
    move (actual - desired) half steps in CCW direction;
}
else if ( actual == desired) {
    do nothing;
}

```

TO CALL;

```

MOVE.B #03,D7
TRAP   #14

```

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:

Program:

current external conditions

desired external conditions

LOCAL MOVE-CVT SCOPE...

```

005150             (temporary)
005151 (4 consecutive bytes for temporary allocation
005152     for use in byte addressing of final results)
005153

```

MOVE-CVT:

006300	42B0	CLR.L	D0	
006302	4281	CLR.L	D1	
006304	303809C2	MOVE.W	\$000009C2,D0	get desired RGSTP
00630B	323B09B4	MOVE.W	\$000009B4,D1	get current RGSTP
00630C	B041	CMP.W	D1,D0	check (D0-D1) or (desired-actual)
00630E	6E12	BGT.S	\$006322	branch if (desired > actual)
006310	673E	BEQ.S	\$006350	branch if (desired == actual)
Set conditions for actual > desired				
006312	92B0	SUB.L	D0,D1	compute (actual -- desired) or (D1 -D0 to D1)
006314	21C15150	MOVE.L	01,\$00005150	store results in temporary structure
006318	13FC000300020219	MOVE.B	#3,\$00020219	set half step, CCW direction at port C
006320	600E	8RA.S	\$006330	
Set conditions for desired > actual				
006322	90B1	SUB.L	D1,D0	compute (desired - actual) or (D0 -D1 to 00)
006324	21C05150	MOVE.L	D0,\$00005150	store results in temporary structure
006328	13FC000100020219	MOVE.B	#1,\$00020219	set half step, CW direction at port C

```

Move temporary storage to timer one byte at a time
006330 13F8515100020227 MOVE.B $00005151,$00020227 store temporary
                                                    2nd byte in timer
                                                    preload register
                                                    (high)
006338 13F8515200020229 MOVE.B $00005152,$00020229 store temporary
                                                    3rd byte in timer
                                                    preload register
                                                    (mid)
006340 13F8515300020228 MOVE.B $00005153,$00020228 store temporary
                                                    4th byte in timer
                                                    preload register
                                                    (low)
006348 13FC000100020235 MOVE.B #1,$00020235 start timer
006350 4E75 RTS
END MOVE-CVT= $6352

```



```

*****
*
*
* ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*   CVT -- ENGINE PROJECT -- CONTROLLER
*
* DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
* AUTHOR:      KENT D. FUNK
* OATE:       8/17/85
* FILE:       setgear.s
* TYPE:       Software Interrupt Processing -- level 4
*
*****

```

SYNOPSIS:

SET-GEAR provides the software interface to the hardware controller for the Power/Shift transmission. The associated hardware consists of six bit manipulated external control lines via PI/T #1 Port A. The Power/Shift transmission can be shifted from one gear to another by actuation of the appropriate solenoids mounted on the transmission. The following specifications have been established.

Port A assignment:

```

PA0 == SOL#1
PA1 == SOL#2
PA2 == SOL#3
PA3 == SOL#4
PA4 == SOL#5
PA5 == SOL#6

```

GEAR SELECTION;

GEAR	SOL#1	SOL#2	SOL#3	SOL#4	SOL#5	SOL#6
NEUTRAL	0	0	0	0	0	0
1ST	1	0	0	0	0	1
2ND	1	0	0	0	1	0
3RD	0	1	0	0	0	1
4TH	0	1	0	0	1	0
5TH	0	0	1	0	0	1
6TH	0	0	1	0	1	0
R1	1	0	0	1	0	0
R2	0	1	0	1	0	0
R3	0	0	1	1	0	0

In addition, a lookup table has been established (see below) which contains the hex representations of Port A for the above listed gears. SET-GEAR determines the appropriate port bit pattern by using the desired gear as the offset in the lookup table, and then writes the pattern to Port A.

TO CALL;

MOVE.B #04,07

TRAP #14

OATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:

Program;

desired external conditions

LOCAL SET-GEAR SCOPE...

```
-----
005144= $00      (N offset= 00)      (pwr/shift lookup table)
005145= $21      (1st offset= 01)
005146= $11      (2nd offset= 02)
005147= $22      (3rd offset= 03)
005148= $12      (4th offset= 04)
005149= $24      (5th offset= 05)
00514A= $14      (6th offset= 06)
00514B= $09      (R1 offset= 07)
00514C= $0A      (R2 offset= 08)
00514D= $0C      (R3 offset= 09)
00514E----- (lookup table End)
-----
```

SET-GEAR:

006400 4281	CLR.L D1	
006402 323809C4	MOVE.W \$000009C4,01	get desired gear
006406 227C00005144	MOVE.L #20804,A1	get base address of pwr/shift lookup table
00640C 03C1	AOD.L 01,A1	add desired gear (offset) to base address, store
00640E 130100020011	MOVE.B (A1),\$00020011	results in A1 move the byte stored at the address in A1 to PI/T #1 Port A Oata Register
006414 4E75	RTS	
ENO SET-GEAR= \$6416		

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*   CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT O. FUNK
*   DATE:       8/17/85
*   FILE:       readrack.s
*   TYPE:       Software Interrupt Processing -- level 5
*
*****

```

SYNOPSIS:

REAO-RACK provides the software interface to the 10-bit absolute encoder (Litton 76NB10-5-S-1) which is mechanically attached to the CAT diesel injector pump "rack". Only 8-bits of resolution are achieved, however, due to mechanical linkage. These eight external data lines are accessible via PI/T #1 Port B.

```

    TO CALL;
        MOVE.B #05,D7
        TRAP   #14

```

DATA STRUCTURES:

```

GLOBAL STRUCTURES AFFECTED:
    Program;
        current external conditions

```

```

LOCAL REAO-RACK SCOPE...
    none

```

```

REAO-RACK:
006500 4280          CLR.L 00
006502 103900020013 MOVE.B $00020013,D0      get data a PI/T #1
                                                Port B Data
                                                Register
006508 31C009E0      MOVE.W 00,$000009B0      store data at RACK
                                                in current external
                                                conditions
                                                structure.
00650C 4E75          RTS
ENO READ-RACK= $650E

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHDR:      KENT D. FUNK
*   DATE:        6/17/85
*   FILE:        teststable.s
*   TYPE:        Software Interrupt Processing -- level 6
*
*****

```

SYNOPSIS:

TEST-STABLE insures that the drive line actuators are stable before releasing control back to sequential execution.

Due to the slow dynamics of the controller actuators compared to the high speed of the CPU, it is necessary to wait until all actuators have stopped before continuing with the loop. TEST-STABLE checks each of the outputs to determine if they are stopped, thus insuring that the drive line actuators are stable. This does not insure that the drive line is stable, however, since the dynamics of drive line response will lag the actuators.

To Call;

```

        MOVE.B #6,D7
        TRAP   #14

```

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:
none

LOCAL TEST-STABLE SCOPE...
none

TEST-STABLE:

```

        Wait until throttle stepper motor stops
006600 4280          CLR.L D0
006602 103900020035  MOVE.B $00020035,D0      get PI/T #1 timer
                                                status byte
006608 028000000001  AND.L #1,D0              isolate timer
                                                empty bit
C0660E 67F2          BEQ.S $006602            branch up if zero

```

```

        Wait until CVT stepper motor stops
006610 4280          CLR.L  D0
006612 103900020235  MOVE.B $00020235,D0      get PI/T #2 timer
                                                status byte
006618 028000000001  AND.L  #1,D0             isolate timer
                                                empty bit
00661E 67F2          BEQ.S  $006612           branch up if zero
006620 4E75          RTS
END TEST-STABLE= $6622

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT O. FUNK
*   DATE:        8/17/85
*   FILE:        regsave.s
*   TYPE:        Software Interrupt Processing -- level 7
*
*****

```

SYNOPSIS:

REG-SAVE saves all CPU internal data registers not saved as a part of normal context switching. It is intended to be used as the first procedure to be executed as part of an interrupt handler. Since interrupts occur asynchronously, this mechanism provides appropriate safeguards against loss of critical data during interrupt exception processing.

```

    TO CALL:
        MOVE.L 07,$511C
        MOVE.B #07,07
        TRAP   #14

```

WARNING:

In order to insure that ALL data remains secure, register 07 must be individually saved before calling this routine. This can be accomplished by the above code. In addition, the appropriate Motorola M68000 manuals should be consulted regarding exception context switching before using this call. It should also be noted that this procedure does not protect against multiple nested interrupts. If this were to occur, critical data will be lost. For the present time, this is acceptable, however, in the future a moving interrupt stack will be used.

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:
none

LOCAL REG-SAVE SCOPE...

005100 (00) (context save)

```

005104      (D1)
005108      (D2)
00510C      (D3)
005110      (D4)
005114      (D5)
005118      (D6)
00511C      (D7)
005120      (A0)
005124      (A1)
005128      (A2)
00512C      (A3)
005130      (A4)
005134      (A5)
005138      (A6)
00513C      (SR)   WORD ONLY
00513C----- (context save End)
-----

```

REG-SAVE:

```

006700 21C05100      MOVE.L D0,$00005100      save D0
006704 21C15104      MOVE.L D1,$00005104      save D1
006708 21C25108      MOVE.L D2,$00005108      save D2
00670C 21C3510C      MOVE.L D3,$0000510C      save D3
006710 21C45110      MOVE.L D4,$00005110      save D4
006714 21C55114      MOVE.L D5,$00005114      save D5
006718 21C65118      MOVE.L D6,$00005118      save D6
00671C 21C85120      MOVE.L A0,$00005120      save A0
006720 21C95124      MOVE.L A1,$00005124      save A1
006724 21CA5128      MOVE.L A2,$00005128      save A2
006728 21CB512C      MOVE.L A3,$0000512C      save A3
00672C 21CC5130      MOVE.L A4,$00005130      save A4
006730 21CD5134      MOVE.L A5,$00005134      save A5
006734 21CE5138      MOVE.L A6,$00005138      save A6
006738 40F8513C      MOVE.W SR,$0000513C      save SR
00673C 4E75          RTS
END REG-SAVE= $673E

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*   CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT O. FUNK
*   DATE:       8/17/85
*   FILE:       regrestore.s
*   TYPE:       Software Interrupt Processing -- level 8
*
*****

```

SYNOPSIS:

REG-RESTORE restores all CPU internal data registers which were saved by REG-SAVE. It is intended to be used as the last procedure to be executed as part of an interrupt handler. This mechanism, in conjunction with REG-SAVE provides appropriate safeguards against loss of critical data during interrupt exception processing.

```

    TO CALL;
        MOVE.B #08,D7
        TRAP   #14

```

WARNING:

In order for this routine to work correctly there must be a correctly installed REG-SAVE preceding it.

DATA STRUCTURES:

```

GLOBAL STRUCTURES AFFECTED:
    none

```

```

LOCAL REG-RESTORE SCOPE...

```

```

-----
005100    (00)                (context restore)
005104    (D1)
005108    (02)
00510C    (D3)
005110    (04)
005114    (D5)
005118    (06)
00511C    (D7)
005120    (A0)

```



```

005124      (A1)
005128      (A2)
00512C      (A3)
005130      (A4)
005134      (A5)
005138      (A6)
00513C      (SR)  WORO ONLY
00513C----- (context restore End)
-----

```

REG-RESTORE:

```

006800 20385100      MOVE.L $00005100,00      restore D0
006804 22385104      MOVE.L $00005104,01      restore D1
006808 24385108      MOVE.L $00005108,D2      restore D2
00680C 2638510C      MOVE.L $0000510C,D3      restore D3
006810 28385110      MOVE.L $00005110,D4      restore D4
006814 2A385114      MOVE.L $00005114,05      restore D5
006818 2C385118      MOVE.L $00005118,D6      restore D6
00681C 2E38511C      MOVE.L $0000511C,D7      restore D7
006820 20785120      MOVE.L $00005120,A0      restore A0
006824 22785124      MOVE.L $00005124,A1      restore A1
006828 24785128      MOVE.L $00005128,A2      restore A2
00682C 2678512C      MOVE.L $0000512C,A3      restore A3
006830 28785130      MOVE.L $00005130,A4      restore A4
006834 2A785134      MOVE.L $00005134,A5      restore A5
006838 2C785138      MOVE.L $00005138,A6      restore A6
00683C 46F8513C      MOVE.W $0000513C,SR      restore SR
006840 4E75          RTS
ENO REG-RESTORE= $6842

```

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BDARO COMPUTER
*       CVT -- ENGINE PROJECT -- CDNTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHDR:      KENT D. FUNK
*   DATE:        8/17/85
*   FILE:        readthstp.s
*   TYPE:        Software Interrupt Processing -- level 9
*
*****

```

GENERAL:

In order to generate accurate feedback position control for the two stepper motors, incremental encoders have been used. One of the encoders has been mechanically attached to the throttle stepper motor, and the other encoder has been attached to the CVT ring drive. Although this closed loop design would probably not be used in a production unit, it provides the needed repeatability when using experimental open loop actuators.

The output of the encoders is a pair of square wave pulse trains whose phase indicates relative direction. By correct separation of the two pulse trains, a suitable up/down counter can be driven to give 400 counts/rev resolution. Two 20-bit counters were available (see Spaulding 1985) which correctly read quadrature output. These counters were incorporated in the 68000 off-board bus structure. The counters have suitable controls to multiplex the data to an 8-bit data bus. In addition seven control lines must be supplied. To accommodate the requirements of these devices and others which may be included, an 8-bit external data bus is available at PI/T #2 Port A and an 8-bit external control bus is available at PI/T #2 Port B.

The following external bus definitions apply to the 20-bit up/down counters.

```

PortA;      (external data bus)
    PA0 == O0
    PA1 == D1
    PA2 == O2
    PA3 == D3
    PA4 == D4
    PA5 == D5
    PA6 == O6
    PA7 == D7
PortB;      (external control bus)
    PBO == CLEAR COUNTER#1    (active high)

```

```

PB1 == INHIBIT COUNTER#1  (active low)
PB2 == A1
PB3 == A2
PB4 == A3
PB5 == CLEAR COUNTER#2   (active high)
PB6 == INHIBIT COUNTER#2 (active low)

```

Control of an individual counter is as follows:

Initialization:

- 1) CLEAR COUNTER and INHIBIT COUNTER lines are brought low.
- 2) The encoder is driven to "HOME" reference.
- 3) CLEAR COUNTER is driven high and then low.
- 4) INHIBIT COUNTER is driven high.

It should be noted that all initialization of both counters is done in the setup routine.

Normal Operation:

Reading the current counter values is accomplished by enabling the desired byte (high, mid, low) and then reading the available data at Port A. Proper enables are accomplished by the following bit map.

Byte Enabled	PB6 INH2	PB5 CL2	PB4 A3	PB3 A2	PB2 A1	PB1 INH1	PB0 CL1	HEX
Counter #1								
low byte	1	0	1	0	0	1	0	\$52
mid byte	1	0	1	0	1	1	0	\$56
high byte	1	0	1	1	0	1	0	\$5A
Counter #2								
low byte	1	0	0	0	0	1	0	\$42
mid byte	1	0	0	0	1	1	0	\$46
high byte	1	0	0	1	0	1	0	\$4A
Disabled	1	0	1	1	1	1	0	\$5E

SYNOPSIS:

READ-THSTP provides the software interface to the 100 cycles/rev incremental encoder (BEI L25G-100-ABZ-7400R-S-) which is mechanically attached to the throttle stepper motor. A gear ratio of 2:1 was established between the throttle and encoder and the resolution of the throttle stepper is 400 steps/rev. Therefore, if the counter value is divided by two, the throttle step position is determined. The technique of dividing by two compensates for any backlash in the gear train.

In addition, mechanical considerations indicate that the maximum expected counter value would be less than a 16 bit representation. Therefore, READ-THSTP only reads the low 16 bits of the 20 bit counter.

```

TO CALL;
      MOVE.B #09,D7
      TRAP   #14

```

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:

```

Program;
      current external conditions

```

LOCAL READ-THSTP SCOPE...

```

      none

```

READ-THSTP:

006900 13FC004200020213	MOVE.B #66,\$00020213	enable counter low byte at Port 8 data register
006908 4280	CLR.L D0	
00690A 103900020211	MOVE.B \$00020211,D0	read counter low byte at Port A data register
006910 13FC004600020213	MOVE.B #70,\$00020213	enable counter mid byte at Port 8 data register
006918 4281	CLR.L D1	
00691A 123900020211	MOVE.B \$00020211,D1	read counter mid byte at Port A data register
006920 E199	ROL.L #B,D1	align bytes to form correct word
006922 D081	ADD.L D1,D0	
006924 E28B	LSR.L #1,D0	divide results by 2
006926 0800000E	BTST #14,D0	if counter rolled under, then set D0
00692A 6702	8EQ.S \$00692E	to zero.
00692C 4280	CLR.L D0	
00692E 31C009B2	MOVE.W D0,\$000009B2	store THSTP in current conditions structure
006932 13FC005E00020213	MOVE.B #94,\$00020213	disable all drivers on external data bus
00693A 4E75	RTS	
END READ-THSTP= \$693C		

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*       CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT O. FUNK
*   DATE:        B/17/B5
*   FILE:        readfbstp.s
*   TYPE:        Software Interrupt Processing -- level 11
*
*****

```

GENERAL:

See REAO-THSTP for general incremental counter considerations.

SYNOPSIS:

READ-FBSTP provides the software interface to the 100 cycles/rev incremental encoder (BEI L25G-100-ABZ-7400R-S-) which is mechanically attached to the CVT ring drive. Currently, no exact relation is known between the encoder and the CVT stepper motor. This is due to the tentative development of the ring drive actuator.

Mechanical considerations indicate that the maximum expected counter value would be less than a 16 bit representation. Therefore, READ-FBSTP only reads the low 16 bits of the 20 bit counter.

```

TO CALL;
        MOVE.B #11,07
        TRAP   #14

```

OATA STRUCTURES:

```

GLOBAL STRUCTURES AFFECTED:
    Program;
        current external conditions

```

```

LOCAL REAO-FBSTP SCOPE...
    none

```

REAO-FBSTP:

```
006950 13FC005200020213 MOVE.B #B2,$00020213
```

enable counter low
byte at Port B data
register

006958 4280	CLR.L D0	
00695A 103900020211	MOVE.B \$00020211,D0	read counter low byte at Port A data register
006960 13FC005600020213	MOVE.B #86,\$00020213	enable counter mid byte at Port B data register
006918 4281	CLR.L D1	
00696A 123900020211	MOVE.B \$00020211,D1	read counter mid byte at Port A data register
006970 E199	ROL.L #8,D1	align bytes to form correct word
006972 D081	ADD.L D1,D0	
006974 4E71	NOP	
006976 0800000E	BTST #14,D0	if counter rolled
00697A 6702	BEQ.S \$00697E	under, then set D0
00697C 4280	CLR.L D0	to zero.
00697E 31C009B6	MOVE.W D0,\$000009B6	store FBSTP in current conditions structure
006982 13FC005E00020213	MOVE.B #94,\$00020213	disable all drivers on external data bus
00698A 4E75	RTS	
END READ-FBSTP= \$698C		

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*   CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        6/17/85
*   FILE:        setup.s
*   TYPE:        Software Interrupt Processing -- level 10
*
*****

```

SYNOPSIS:

SETUP conducts an interactive mode of initializing the physical engine and transmissions. This procedure is executed only once and must be performed after all computer hardware has been initialized (p-init and e-init).

To Call;

```

MOVE.B #10,07
TRAP   #14

```

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:

```

Program:
    console buffer
    current external conditions
    desired external conditions

```

LOCAL SETUP SCOPE...

```

-----
50A0= $20202020                      (setup string #1)
50A4= $20202020
50AB= 'CO'
50AA= 'NT'
50AC= 'IN'
50AE= 'UE'
50B0= '?'
50B2----- (setup string #1 end)
-----

```

```

-----
50B4= $20202020                      (setup string #2)
50BB= 'ST'

```

```

50BA= 'AR'
50BC= 'T '
50BE= 'EN'
50C0= 'GI'
50C2= 'NE'
50C4= $0D0A
50C6----- (setup string #2 end)
-----

```

SETUP:

```

      Write setup string #1 to Console
006A00 2A7C000050A0      MOVE.L #20640,A5      starting address
006A06 2C7C000050B2      MOVE.L #2065B,A6      ending address
006A0C 1E3C00F3          MOVE.B #243,D7      call OUTPUT
006A10 4E4E              TRAP #14

      Wait for user Response
006A12 2A7C00000900      MOVE.L #2304,A5      console buffer
                                           starting address

006A1B 2C4D              MOVE.L A5,A6
006A1A 1E3C00F1          MOVE.B #241,07      call PORTIN1
006A1E 4E4E              TRAP #14

      Move throttle 500 steps up
006A20 13FC000100020019 MOVE.B #1,$00020019      select half steps.
                                           CW rotate at PI/T#1
006A2B 13FC000000020027 MOVE.B #0,$00020027      timer high
006A30 13FC000100020029 MOVE.B #1,$00020029      timer mid
006A3B 13FC00F40002002B MOVE.B #244,$0002002B      timer low
006A40 13FC000100020035 MOVE.B #1,$00020035      start timer
      Wait till throttle stops
006A4B 103900020035      MOVE.B $00020035,00      timer status byte
006A4E 02B000000001      AND.L #1,00          isolate time out
                                           bit
006A54 67F2              BEQ.S $006A4B          branch up if zero

      Search down the throttle 2 steps at a time.
      After every two steps check for home switch detect.
      Insure switch reading by 4 consecutive positive reads.
006A56 13FC000300020019 MOVE.B #3,$00020019      select half step.
                                           CCW rotate at PI/T#1
006A5E 13FC000000020027 MOVE.B #0,$00020027      timer high
006A66 13FC000000020029 MOVE.B #0,$00020029      timer mid
006A6E 13FC00020002002B MOVE.B #2,$0002002B      timer low
006A76 13FC000100020035 MOVE.B #1,$00020035      start timer
006A7E 123C0000          MOVE.B #0,01          D1 is event
                                           detection counter
006AB2 103900020035      MOVE.B $00020035,00      get timer status
006ABB 02B000000001      AND.L #1,D0          isolate time out
                                           bit

```


006A8E 67F2	BEQ.S \$006AB2	branch up if zero
006A90 363CFFFF	MOVE.W #-1,D3	PAUSE for
006A94 57CBFFFE	DBEQ.L D3,\$006A94	a moment
006A9B 103900020019	MOVE.B \$00020019,D0	get home detect
		input
006A9E 028000000010	AND.L #16,D0	isolate throttle
		home bit
006AA4 67B0	BEQ.S \$006A56	branch up if zero
006AA6 363CFFFF	MDVE.W #-1,D3	pause for a while
006AAA 57CBFFFE	DBEQ.L D3,\$006AAA	to let home
006AAE 363CFFFF	MOVE.W #-1,D3	switch debounce.
006AB2 57CBFFFE	DBEQ.L D3,\$006AB2	
006AB6 06010001	ADD.B #1,D1	increment event
		detection counter
006ABA 0C010004	CMP.B #4,D1	check if we have
		four consecutive
		reads
006ABE 66D8	BNE.S \$006A98	branch up if not

Throttle is now at home position

Now reset 20-bit throttle position counter to zero

006AC0 13FC001D00020213	MOVE.B #29,\$00020213	set CLEAR COUNTER
		high
006ACB 13FC001C00020213	MOVE.B #28,\$00020213	set CLEAR CDUNTER
		low
006AD0 13FC001E00020213	MDVE.B #30,\$00020213	enable counter

Move throttle up 900 steps

006AD8 13FC000100020019	MDVE.B #1,\$00020019	select half step,
		CW rotation @ PI/T#1
006AE0 13FC000000020027	MDVE.B #0,\$00020027	timer high
006AE8 13FC000400020029	MDVE.B #4,\$00020029	timer mid
006AF0 13FC004C0002002B	MDVE.B #76,\$0002002B	timer low
006AF8 13FC000100020035	MOVE.B #1,\$00020035	start timer
006B00 4E71	NDP	
006B02 4E71	NDP	
006B04 4E71	NDP	
006B06 31FC044C09C0	MOVE.W #1100,\$000009C0	update desired
		position structure
		THSTP

Write setup string #2 to Console

006B0C 2A7C000050B4	MOVE.L #20660,A5	starting address
006B12 2C7C000050C6	MDVE.L #2067B,A6	ending address
006B18 1E3C00F3	MOVE.B #243,D7	call OUTPUT
006B1C 4E4E	TRAP #14	

Write setup string #1 to Console

006B1E 2A7C000050A0	MOVE.L #20640,A5	starting address
006B24 2C7C000050B2	MOVE.L #2065B,A6	ending address

```

006B2A 1E3C00F3      MOVE.B #243,D7      call DUTPUT
006B2E 4E4E          TRAP #14

    Wait for user Response
006B30 2A7C00000900    MOVE.L #2304,A5      console buffer
                                         starting address
006B36 2C4D          MDVE.L A5,A6
006B3B 1E3C00F1      MOVE.B #241,D7      call PORTIN1
006B3C 4E4E          TRAP #14

    Move Ring Position 500 steps up
006B3E 13FC000100020219 MDVE.B #1,$00020219    select half steps,
                                         CW rotate at PI/T#2
006B46 13FC000000020227 MDVE.B #0,$00020227    timer high
006B4E 13FC000100020229 MOVE.B #1,$00020229    timer mid
006B56 13FC00F40002022B MDVE.B #244,$0002022B    timer low
006B5E 13FC000100020235 MOVE.B #1,$00020235    start timer

    Wait till Ring stops
006B66 103900020235    MOVE.B $00020235,D0      timer status byte
006B6C 0280000000001    AND.L #1,D0      isolate time out
                                         bit
006B72 67F2          BEQ.S $006B66      branch up if zero

    Search down the ring travel 2 steps at a time.
    After every two steps check for home switch detect.
    Insure switch reading by 4 consecutive positive reads.
006B74 13FC000300020219 MOVE.B #3,$00020219    select half step,
                                         CCW rotate at PI/T#2
006B7C 13FC000000020227 MDVE.B #0,$00020227    timer high
006B84 13FC000000020229 MOVE.B #0,$00020229    timer mid
006B8C 13FC00020002022B MDVE.B #2,$0002022B    timer low
006B94 13FC000100020235 MDVE.B #1,$00020235    start timer
006B9C 123C0000      MDVE.B #0,D1      D1 is event
                                         detection counter
006BA0 103900020235    MDVE.B $00020235,D0      get timer status
                                         byte
006BA6 02B0000000001    AND.L #1,D0      isolate time out
                                         bit
006BAC 67F2          BEQ.S $006BA0      branch up if zero
006BAE 363CFFFF      MDVE.W #-1,03      PAUSE for
006BB2 57CBFFFE      DBEQ.L D3,$006BB2    a moment
006BB6 103900020219    MOVE.B $00020219,D0      get home detect
                                         input
006BBC 02B0000000010    ANO.L #16,D0      isolate ring home
                                         bit
006BC2 67B0          BEQ.S $006B74      branch up if zero
006BC4 363CFFFF      MOVE.W #-1,D3      pause for awhile to
006BC8 57CBFFFE      DBEQ.L $006BCB    let home switch
006BCC 363CFFFF      MOVE.W #-1,03      debounce.
006BD0 57CBFFFE      DBEQ.L $006BD0

```

006B04 06010001	A00.B #1,01	increment event
006B08 0C010004	CMP.B #4,01	detection counter
		check if we have
		four consecutive
		reads
006B0C 66D8	BNE.S \$006BB6	branch up if not

CVT rings are now at home position

Reset and initialize fb-stp counter.

006BDE 13FC003E00020213	MOVE.B #62,\$00020213
006BE6 13FC001E00020213	MOVE.B #30,\$00020213
006BEE 13FC005E00020213	MOVE.B #94,\$00020213

Update the rest of the global data structures

006BF6 31FC000009B4	MOVE.W #0,\$000009B4	current RGSTP
006BFC 31FC000009C2	MOVE.W #0,\$000009C2	desired RGSTP
006C02 31FC000009BB	MOVE.W #0,\$000009B8	current gear
006C08 31FC000009C4	MOVE.W #0,\$000009C4	desired gear
006C0E 31FC000009B6	MOVE.W #0,\$000009B6	current FBSTP
006C14 4E75	RTS	
END SETUP= \$6C16		

```

*****
*
*
*   ASSEMBLY LISTING FOR MOTOROLA M68000 ECB SINGLE BOARD COMPUTER
*   CVT -- ENGINE PROJECT -- CONTROLLER
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        6/17/85
*   FILE:        hostint.s
*   TYPE:        Hardware Interrupt Processing -- ADAC 1000
*
*****

```

SYNOPSIS:

HOST-INT provides the interrupt handler for all MC68000 to ADAC communications. In it's final form, this routine will control communications in both directions. Currently, however, the routine only provides for data to be passed from the MC68000 to the ADAC. This has proved sufficient for drive line mapping. Once the implementation of the control algorithm is in place, bi-directional data flow will be needed.

Control of data flow is accomplished by message passing. If the ADAC desires updated information from the MC68000, it writes a 'R' for request to ACIA #2. When the character is caught, a priority 6 hardware interrupt is generated. The existence of this interrupt prompts the MC68000 to enter exception processing using HOST-INT as the handler. Once it has been determined that a valid request has been made, HOST-INT updates the current conditions structure and proceeds to form an ASCII string from the data. Notice that a tag 'S' is placed at the beginning of the string. This allows the ADAC to know that the MC68000 is "sending" data to a valid request. These tags, ie 'S' and 'R', allow for adequate error checking and prevents handling spurious interrupts.

DATA STRUCTURES:

GLOBAL STRUCTURES AFFECTED:

```

    Program;
        current external conditions

```

LOCAL HOST-INT SCOPE...

```

-----
5800= 'S '      (host response string)
5802= $2020 (rack-start)

```

```

5804= $2020
5806= $2020
5808= $2020
580A= $2020 (thstp-start)
580C= $2020
580E= $2020
5810= $2020
5812= $2020 (rgstp-start)
5814= $2020
5816= $2020
5818= $2020
581A= $2020 (fbstp-start)
581C= $2020
581E= $2020
5820= $2020
5822= $2020 (gear-start)
5824= $2020
5826= $2020
5828= $2020
582A= $000A
582C----- (host response string end)
-----

```

HOST-INT:

```

007000 13FC001500010041  MOVE.B #21,$00010041      shut off ACIA
                                                    interrupt bit
007008 21C7511C           MOVE.L D7,$0000511C      save register D7
00700C 1E3C0007           MOVE.B #7,D7             call SAVE-REG
007010 4E4E               TRAP #14
007012 1A3900010041      MOVE.B $00010041,D5        dumb read on
                                                    status register

007018 4285               CLR.L D5
00701A 1A3900010043      MOVE.B $00010043,D5        get a character
007020 0205007F          AND.B #127,D5             mask high bit
007024 0C050052          CMP.B #82,D5              is it an 'R'
007028 6704              BEQ.S $00702E              branch to REQUEST:
00702A 4EF870EC          JMP.S $000070EC            jump to CLEAR:

```

REQUEST:

```

      blank out host response string
00702E 207C00005800      MOVE.L #22528,A0          base address
007034 30FC5320          MOVE.W #21280,(A0)+        'S '
007038 20FC20202020      MOVE.L #538976288,(A0)+    spaces
00703E 20FC20202020      MOVE.L #538976288,(A0)+    spaces
007044 20FC20202020      MOVE.L #538976288,(A0)+    spaces
00704A 20FC20202020      MOVE.L #538976288,(A0)+    spaces
007050 20FC20202020      MOVE.L #538976288,(A0)+    spaces
007056 20FC20202020      MOVE.L #538976288,(A0)+    spaces
00705C 20FC20202020      MOVE.L #538976288,(A0)+    spaces
007062 20FC20202020      MOVE.L #538976288,(A0)+    spaces

```

```

007068 20FC20202020 MDVE.L #538976288,(A0)+ spaces
00706E 20FC20202020 MDVE.L #538976288,(A0)+ spaces
007074 30FC200A MOVE.W #8202,(A0)+ space-LF

    Update current conditions structure
007078 1E3C0005 MOVE.8 #5,D7 call READ-RACK
00707C 4E4E TRAP #14
00707E 1E3C0009 MOVE.8 #9,D7 call READ-THSTP
007082 4E4E TRAP #14
007084 1E3C0008 MDVE.8 #11,D7 call REAO-F8STP
007088 4E4E TRAP #14

    Get RACK reading, convert, and store in host response string.
00708A 303809B0 MOVE.W $00000980,D0 rack reading
00708E 2C7C00005802 MDVE.L #22530,A6 position in host
                                string
007094 1E3C00EC MDVE.8 #236,D7 call HEX2DEC
007098 4E4E TRAP #14

    Get TH-STP reading, convert, and store in host response string.
00709A 30380982 MDVE.W $00000982,D0 th-stp reading
00709E 2C7C0000580A MOVE.L #22538,A6 position in host
                                string
0070A4 1E3C00EC MOVE.8 #236,D7 call HEX2DEC
0070A8 4E4E TRAP #14

    Get RG-STP reading, convert, and store in host response string.
0070AA 30380984 MDVE.W $00000984,D0 rg-stp reading
0070AE 2C7C00005812 MDVE.L #22546,A6 position in host
                                string
0070B4 1E3C00EC MDVE.8 #236,D7 call HEX2DEC
0070B8 4E4E TRAP #14

    Get F8-STP reading, convert, and store in host response string.
0070BA 30380986 MDVE.W $00000986,D0 fb-stp reading
0070BE 2C7C0000581A MDVE.L #22554,A6 position in host
                                string
0070C4 1E3C00EC MDVE.8 #236,D7 call HEX2DEC
0070C8 4E4E TRAP #14

    Get GEAR reading, convert, and store in host response string.
0070CA 303809B8 MOVE.W $00000988,D0 gear reading
0070CE 2C7C00005822 MOVE.L #22562,A6 position in host
                                string
0070D4 1E3C00EC MDVE.8 #236,D7 call HEX2DEC
0070D8 4E4E TRAP #14

    Write host response string out to ACIA.
0070DA 2A7C00005800 MOVE.L #22528,A5 string starting
                                address

```

0070E0 2C7C0000582C	MOVE.L #22572,A6	string ending address + 1
0070E6 1E3C00F2	MOVE.B #242,07	call OUTPUT21
0070EA 4E4E	TRAP #14	
CLEAR:		
0070EC 103900010041	MOVE.B \$00010041,00	dumb read on ACIA status register clears interrupt conditions
0070F2 08000000	BTST #0,D0	test if clear
0070F6 6708	BEQ.S \$007100	branch on clear to OONE:
0070F8 1A3900010043	MOVE.B \$00010043,D5	dumb read on receive register.
0070FE 60EC	BRA.S \$0070EC	branch to CLEAR:
DONE:		
007100 1E3C0008	MOVE.B #8,D7	call REG-RESTORE
007104 4E4E	TRAP #14	
007106 13FC009500010041	MOVE.B #149,\$00010041	enable ACIA interrupts
00710E 4E73	RTE	return from exception
END HOST-INT= \$7110		

APPENDIX E

ADAC 1000 HOST DEVELOPMENT SOFTWARE LISTINGS


```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- MC68000 DEVELOPMENT
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        4/5/85
*   FILE:        transfer.c
*
*****

```

```

/* This file contains a program to upload or download programs
between a UNIX machine and the MC68000 ECB. Both S-records and
listings can be handled this way. */

```

```

/* Too complile and link:  --> cc transfer.c
   Too run:  --> transfer      */

```

```

#include <stdio.h>

```

```

FILE *fp, *fopen();
char line[80];

```

```

/*****                                MAIN()                                *****/
main()
{
    char file[20];
    int direct;

    printf("Enter filename --> ");
    fflush(stdout);
    fgets(line, 80, stdin);
    sscanf(line, "%s", file);

    printf("\nEnter option.\n");
    printf("Dump=1, Load=2\n");
    fgets(line, 80, stdin);
    sscanf(line, "%d", &direct);

    if (direct == 1) {
exit:
        printf("Waiting for your exit.\n");
        fgets(line, 80, stdin);
        /* exiting character sent by tutor= $01 */
        if (*line != 1)
            goto exit;
    }
}

```

```

        dump(file);
        fclose(fp);
        return;
    )

    if (direct == 2) {
        printf("Waiting for your exit.\n");
start:
        fgets(line, 80, stdin);
        /* Tutor uses "VE2 :=READY" or
           "L02 :=READY" to verify
           and load S-Record Format */
        if (*line != 'R')
            goto start;
        load(file);
        fclose(fp);
        return;
    }
    printf("Incorrect option specified.\n\n");
}

```

```

/*****                                DUMP()                                *****/
/*
Dump Routine.
    The dump routine reads the standard input and writes
    out to the named file. */

dump(fname)
char *fname;
{
    fp= fopen(fname, "w");
loop:
    fgets(line, 80, stdin);
    if (*line == 0)
        goto loop;
    /* To stop input, return to shell and type "x" */
    if (*line == 'x')
        return;
    fprintf(fp, "%s", line);
    goto loop;
}

```

```

/*****                                LOAD()                                *****/
/*
Load Routine.
    The load routine reads from the named file and writes
    to the standard output. */

```

```

load(fname)
char *fname;
{
    fp= fopen(fname, "r");
loop:
    fgets(line, 80, fp);
    if (feof(fp))
        return;
    printf("%s", line);
    goto loop;
}

```

/* NOTICE: For these routines to work properly, the tutor escape character must be ^A (default). and the trailing character must be \$0A,<lf>. The line feed must be specified in the initialization procedures as follows:

```

TUTOR 1.3 > MM 4EA
0004EA 18 ?0A.<cr>
*/

```

```

*****
*
*
*   C-SOURCE LISTING FOR ADAC 1000 COMPUTER
*       CVT -- ENGINE PROJECT -- MC68000 DEVELOPMENT
*
*   DEPARTMENTS OF MECHANICAL AND AGRICULTURAL ENGINEERING
*
*   AUTHOR:      KENT D. FUNK
*   DATE:        4/5/85
*   FILE:        comment.c
*
*****

/* This file contains a program to comment MC68000 programs which
have been dumped onto a UNIX system using "transfer" */

/* Too compile and link:  --> cc -o comment comment.c */

/* In order to use this comment editor, the assembly listings
MUST first be packed.  This can be done by creating two files:

FILE #1:  pack
x $1 <pedit

FILE #2:  pedit
g/      /s// /
g/      /s// /
w
q

Then the source files may be packed by:
--> pack <filename>

Then the source files may be commented by:
--> comment <filename>
*/

#include <stdio.h>
#include <ctype.h>

FILE *r, *w, *fopen();

/*****                                *****/
main(argc, argv)
int argc;
char **argv;
{
    char buff[200], blank[80];

```

```

char line1[200], line2[200], line3[200], file[20];
char *ptr1, *ptr2, *ptr3, *ptr4;
int len1, len2, spaces, index;

if (argc != 2) {
    fprintf(stderr, "Usage:  comment <filename>.\n");
    exit(1);
}
strcpy(file, argv[1]);
spaces= 57;
ptr3= &blank[0];
while (spaces) {
    *ptr3= ' ';
    ptr3++;
    spaces--;
}

restart:
    r= fopen(file, "r");      /* open file for read
                               at top of file */

    w= fopen("comment.edt", "w"); /* opens writing file */
loop:
    ptr1= line1;
    ptr3= line3;
    index= 200;
    while (index) {
        *ptr1= 0;
        *ptr3= 0;
        ptr1++;
        ptr3++;
        index--;
    }

    strcpy(line3, blank);
    fgets(line1, 150, r);      /* get a line from the opened file */
    if (feof(r))
        printf("End of File\n");

tryagain:
    ptr2= line2;
    index= 200;
    while (index) {
        *ptr2= 0;
        ptr2++;
        index--;
    }

    printf("%s", line1);
    printf("?> ");
    fflush(stdout);

```



```

        ptr1++;
        ptr2++;
    )
    fprintf(w, "%s", line1);
    goto loop;
}
ptr3= &line3[57];
ptr2= &line2[20];
while (isspace(*ptr2) == 0) {
    ptr2--;
}
ptr4= &line2[0];
while (ptr4 < ptr2) {
    *ptr1= *ptr4;
    ptr4++;
    ptr1++;
}
*ptr1= '\n';
fprintf(w, "%s", line1);
while (*ptr2) {
    *ptr3= *ptr2;
    ptr3++;
    ptr2++;
}

addon:

ptr1= line1;
index = 200;
while (index) {
    *ptr1= 0;
    ptr1++;
    index--;
}
strcpy(line1, line3);
len1= strlen(line1);
if (len1 <= 77) {
    fprintf(w, "%s", line1);
    goto loop;
}
ptr3= line3;
index= 200;
while (index) {
    *ptr3= 0;
    ptr3++;
    index--;
}
strcpy(line3, blank);
ptr1= &line1[77];
ptr3= &line3[57];
while (isspace(*ptr1) == 0) {
    ptr1--;
}

```

```

        ptr4= ptr1;
        while (*ptr1) {
            *ptr3= *ptr1;
            ptr3++;
            ptr1++;
        }
        *ptr4= '\n';
        ptr4++;
        *ptr4= 0;
        fprintf(w, "%s", line1);
        goto addon;

    case 'w':
        while (feof(r) == 0) {
            fprintf(w, "%s", line1);
            fgets(line1, 150, r);
        }
        fclose(w);
        fclose(r);
        w= fopen(file, "w");
        r= fopen("comment.edt", "r");

writback:
        fgets(line1, 150, r);
        if (feof(r) == 0) {
            fprintf(w, "%s", line1);
            goto writback;
        }
        fclose(w);
        fclose(r);
        goto restart;
        break;

    case 'q':
        fclose(w);
        fclose(r);
        unlink("comment.edt");
        printf("Comment Exiting\n");
        exit();
        break;

    default:
        printf("Editor options (i a d w q <ret> ?) \n");
        goto tryagain;
    }
    goto loop;
}

```


APPENDIX F

DATA SHEETS


SK3180

263

**NPN Si AF
Darlington Transistor**

P_T	65 W
I_C	10 A
V_{CB0}	80 V
V_{CE0}	80 V
V_{EB0}	5 V
h_{FE}	20,000
f_T	20 MHz

1




Made in Malaysia

SK5040

Silicon Fast Recovery Rectifier

$V_{RRM}(PRV)$	1000 V
$I_{d}(FAV)$	3 A
I_{FSM}	300 A
V_F	1.4 V
t_{rr}	250 ns



MADE IN MALAYSIA



NPN PHOTOTRANSISTOR AND PN INFRARED EMITTING DIODE

... Gallium Arsenide LED optically coupled to a Silicon Photo Darlington Transistor designed for applications requiring electrical isolation, high-current transfer ratios, small package size and low cost; such as interfacing and coupling systems, phase and feedback controls, solid-state relays and general-purpose switching circuits.

- High Isolation Voltage
 $V_{ISO} = 7500 \text{ V (Min)}$
- High Collector Output Current
 $I_C = 50 \text{ mA (Min)} - 4N32, 33$
 $10 \text{ mA (Min)} - 4N39, 30$
 $5.0 \text{ mA (Min)} - 4N31$
- Excellent Frequency Response —
 30 kHz (Typ)
- Fast Switching Times @ $I_C = 50 \text{ mA}$
 $t_{on} = 0.6 \mu\text{s (Typ)}$
 $t_{off} = 17 \mu\text{s (Typ)} - 4N29, 35, 31$
 $45 \mu\text{s (Typ)} - 4N32, 33$
- 4N29A, 4N32A are UL Recognized —
File Number E54915
- Economical, Compact,
Dual-In-Line Package

MAXIMUM RATINGS @ $T_A = 25^\circ\text{C}$ unless otherwise noted

Rating	Symbol	Value	Units
INFRARED-EMITTING DIODE MAXIMUM RATINGS			
Reverse Voltage	V_R	20	Volts
Forward Current — Continuous	I_F	10	mA
Forward Current — Peak (Pulse Width = 300 μs , 20% Duty Cycle)	I_{FP}	30	Amps
Total Power Dissipation @ $T_A = 25^\circ\text{C}$ Derate above 25°C	P_D	150	mW
		70	mW/ $^\circ\text{C}$

PHOTOTRANSISTOR MAXIMUM RATINGS

Collector-Emitter Voltage	V_{CE0}	50	Volts
Emitter-Collector Voltage	V_{EC0}	50	Volts
Collector-Base Voltage	V_{CB0}	25	Volts
Total Power Dissipation @ $T_A = 25^\circ\text{C}$ Derate above 25°C	P_D	150	mW
		70	mW/ $^\circ\text{C}$

TOTAL DEVICE RATINGS

Total Device Dissipation @ $T_A = 25^\circ\text{C}$ Equal Power Dissipation in Each Element Derate above 25°C	P_D	250	mW
		125	mW/ $^\circ\text{C}$
Operating Junction Temperature Range	T_J	$-55^\circ\text{C} \text{ to } 100^\circ\text{C}$	$^\circ\text{C}$
Storage Temperature Range	T_{stg}	$-55^\circ\text{C} \text{ to } 150^\circ\text{C}$	$^\circ\text{C}$
Soldering Temperature (10 s)		250	$^\circ\text{C}$

FIGURE 1 — MAXIMUM POWER DISSIPATION





Figure 1 is based upon using —
1. ambient in the junction
 $T_J = T_A + R_{JA}(P_D + P_{LED})$
where
 T_J = junction temperature (100°C)
 T_A = ambient temperature
 R_{JA} = junction to ambient thermal
resistance (150°C/W)
 P_D = Power Dissipation in LED Chip
 P_{LED} = Power Dissipation in Driver Chip
 G = Thermal Coupling Coefficient
(100%)
Example:
With $P_D = 93 \text{ mW}$ in the LED
at $T_A = 50^\circ\text{C}$ the Junction
 $P_D(P_{LED})$ must be less than 13 mW

4N30
4N31
4N32, 4N32A
4N33

INFRARED LIGHT-EMITTING DIODE PHOTO DARLINGTON TRANSISTOR COUPLED PAIR



STYLE 1
PIN 1: ANODE
2: CATHODE
3: IC
4: EMITTER
5: COLLECTOR
6: BASE



1. LEADS FORMED TO 0.010 INCH DIAMETER OF HOLE POSITION AT SEATING TONGS AT MAXIMUM WATER WASH CONDITION
2. DIMENSIONS MAY VARY TO 0.010 INCH LEADS WHEN FORMED PARTIAL

DIMENSIONS	
UNIT	INCHES
1	0.010
2	0.010
3	0.010
4	0.010
5	0.010
6	0.010
7	0.010
8	0.010
9	0.010
10	0.010
11	0.010
12	0.010
13	0.010
14	0.010
15	0.010
16	0.010
17	0.010
18	0.010
19	0.010
20	0.010
21	0.010
22	0.010
23	0.010
24	0.010
25	0.010
26	0.010
27	0.010
28	0.010
29	0.010
30	0.010
31	0.010
32	0.010
33	0.010
34	0.010
35	0.010
36	0.010
37	0.010
38	0.010
39	0.010
40	0.010
41	0.010
42	0.010
43	0.010
44	0.010
45	0.010
46	0.010
47	0.010
48	0.010
49	0.010
50	0.010
51	0.010
52	0.010
53	0.010
54	0.010
55	0.010
56	0.010
57	0.010
58	0.010
59	0.010
60	0.010
61	0.010
62	0.010
63	0.010
64	0.010
65	0.010
66	0.010
67	0.010
68	0.010
69	0.010
70	0.010
71	0.010
72	0.010
73	0.010
74	0.010
75	0.010
76	0.010
77	0.010
78	0.010
79	0.010
80	0.010
81	0.010
82	0.010
83	0.010
84	0.010
85	0.010
86	0.010
87	0.010
88	0.010
89	0.010
90	0.010
91	0.010
92	0.010
93	0.010
94	0.010
95	0.010
96	0.010
97	0.010
98	0.010
99	0.010
100	0.010

DATE 10/81

Characteristic	Symbol	Min	Typ	Max	Unit
*Reverse Leakage Current ($V_R = 3.0 \text{ V}$, $R_L = 1.0 \text{ M ohms}$)	I_R	—	0.05	100	μA
*Forward Voltage ($I_F = 50 \text{ mA}$)	V_F	—	1.2	1.5	Volts
Capacitance ($V_R = 0 \text{ V}$, $f = 1.0 \text{ MHz}$)	C	—	150	—	pF

PHOTOTRANSISTOR CHARACTERISTICS ($T_A = 25^\circ\text{C}$ and $I_F = 0$ unless otherwise noted)

Characteristic	Symbol	Min	Typ	Max	Unit
*Collector-Emitter Dark Current ($V_{CE} = 10 \text{ V}$, Base Open)	I_{CEO}	—	—	100	nA
*Collector-Base Breakdown Voltage ($I_C = 100 \mu\text{A}$, $I_E = 0$)	BV_{CBO}	30	—	—	Volts
*Collector-Emitter Breakdown Voltage ($I_C = 100 \mu\text{A}$, $I_E = 0$)	BV_{CEO}	30	—	—	Volts
*Emitter-Collector Breakdown Voltage ($I_E = 100 \mu\text{A}$, $I_B = 0$)	BV_{ECO}	5.0	—	—	Volts
DC Current Gain ($V_{CE} = 5.0 \text{ V}$, $I_C = 500 \mu\text{A}$)	h_{FE}	—	5000	—	—

COUPLED CHARACTERISTICS ($T_A = 25^\circ\text{C}$ unless otherwise noted)

Characteristic	Symbol	Min	Typ	Max	Unit
*Collector Output Current (1) ($V_{CE} = 10 \text{ V}$, $I_F = \text{mA}$, $I_B = 0$)	I_C	50 10 5.0	— — —	— — —	mA
Isolation Surge Voltage (2, 3) (60 Hz ac Peak, 5 Seconds)	V_{ISO}	7500 2500 1500	— — —	— — —	Volts
Isolation Resistance (2) ($V = 500 \text{ V}$)	—	—	10^{11}	—	Ohms
*Collector-Emitter Saturation Voltage (1) ($I_C = 2.0 \text{ mA}$, $I_F = 8.0 \text{ mA}$)	$V_{CE(sat)}$	—	—	1.2 1.0	Volts
Isolation Capacitance (2) ($V = 0$, $f = 1.0 \text{ MHz}$)	—	—	0.8	—	pF
Bandwidth (3) ($I_C = 2.0 \text{ mA}$, $R_L = 100 \text{ ohms}$, Figures 8 and 9)	—	—	30	—	kHz

SWITCHING CHARACTERISTICS (Figure 7 and 8), (4)

Turn-On Time ($I_C = 50 \text{ mA}$, $I_F = 200 \text{ mA}$, $V_{CE} = 10 \text{ V}$)	t_{on}	—	0.8	5.0	μs
Turn-Off Time ($I_C = 50 \text{ mA}$, $I_F = 200 \text{ mA}$, $V_{CE} = 10 \text{ V}$)	t_{off}	—	17 45	40 100	μs

*Indicates JEDEC Registered Data.

(1) Pulse Test: Pulse Width = 500 μs , Duty Cycle 4:2:0.4.

(2) For this test, LED pins 1 and 2 are common and phototransistor pins 4, 5, and 6 are common.

(3) I_F adjusted to give $I_C = 2.0 \text{ mA}$ and $I_E = 2.0 \text{ mA}$ P.P. at 10 Vrms.

(4) t_{on} and t_{off} are inversely proportional to the amplitude of I_F , and t_{on} and t_{off} are not significantly affected by I_C .

(5) Isolation Surge Voltage, V_{ISO} , is an internal device dielectric breakdown rating.

FIGURE 2 — 4N29, 4N20, 4N31
DC CURRENT TRANSFER CHARACTERISTICS





FIGURE 3 — 4N32, 4N33



TYPICAL ELECTRICAL CHARACTERISTICS (Printed Circuit Board Mounting)

FIGURE 4 - DIODE FORWARD CHARACTERISTIC




FIGURE 5 - COLLECTOR-EMITTER CUTOFF CURRENT




FIGURE 6 - FREQUENCY RESPONSE




FIGURE 7 - SWITCHING TIMES




FIGURE 8 - FREQUENCY RESPONSE TEST CIRCUIT





FIGURE 9 - SWITCHING TIME TEST CIRCUIT



MOTOROLA Semiconductor Products Inc.




Specifications and Applications Information

STEPPER MOTOR DRIVER

The SAA1042 drives a two-phase stepper motor in the bipolar mode. The device contains: three input stages, a logic section and two output stages.

- Drive Stages Designed for Motors: 6.0 V and 12 V: SAA1042
24 V: SAA1042A
- 500 mA/Coil Drive Capability
- Built-In Clamp Diodes for Overvoltage Suppression
- Wide Logic Supply Voltage Range
- Accepts Commands for CW/CCW and Half/Full Step Operation
- Inputs Compatible with Popular Logic Families: MOS, TTL, DTL
- Set Input Defined Output State
- Drive Stage Bias Adaptable to Motor Power Dissipation for Optimum Efficiency

FIGURE 1 — SAA1042 BLOCK DIAGRAM



SAA1042
SAA1042A

Possible Substitutions

ADN-29492
3P103VC UC N-4207A


STEPPER MOTOR DRIVER

SILICON MONOLITHIC
INTEGRATED CIRCUIT



PLASTIC PACKAGE
CASE 721-02

PIN ASSIGNMENT



(Top View)

Note: Case heat sink is electrically connected to ground (Pin 9) through the die substrate.

MAXIMUM RATINGS ($T_A = 25^\circ\text{C}$ unless otherwise stated)

Rating	Symbol	SAAI042	SAAI042A	Unit
Clamping Voltage (Pins 1, 3, 14 & 16)	V_{clamp}	20	30	V
Over Voltage ($V_{\text{OV}} = V_{\text{clamp}} - V_M$)	V_{OV}	5.0	—	V
Supply Voltage	V_{CC}	20	30	V
Switching or Motor Current/Coil	I_M	500	—	mA
Input Voltage (Pins 7, 8 & 10)	V_{in} clock V_{in} Full/Half V_{in} CW/CCW	V_{CC}	—	V
Power Dissipation Derate above $T_A = 25^\circ\text{C}$	P_D^*	2.0	—	W
Thermal Resistance, Junction to Air	θ_{JA}	20	—	$^\circ\text{C/W}$
Thermal Resistance, Junction to Case	θ_{JC}	50	—	$^\circ\text{C/W}$
Operating Junction Temperature Range	T_J	-30 to +125	—	$^\circ\text{C}$
Storage Temperature Range	T_{stg}	-65 to +150	—	$^\circ\text{C}$

*The power dissipation, P_D , of the circuit is given by the supply voltage, V_M and V_{CC} , and the motor current, I_M , and can be determined from Figures 3 and 5. $P_D = P_{\text{drive}} + P_{\text{logic}}$.

ELECTRICAL CHARACTERISTICS ($T_A = +25^\circ\text{C}$)

Characteristic	Pin	Symbol	V_{CC}	V_{in}	T_{yp}	Max	Unit
Supply Current	11	I_{CC}	5.0 V 20 V	— —	— —	3.5 8.5	mA
Motor Supply Current ($I_{\text{Pin 6}} = -400 \mu\text{A}$, Pins 1, 3, 14, 16 Open)	15	I_M	5.0 V 5.0 V 5.0 V 5.0 V	— — — —	25 30 40 —	— — — —	mA
Input Voltage — High State	7, 8, 10	V_{IH}	5.0 V 10 V 15 V 20 V	2.0 7.0 10 14	— — — —	— — — —	V
Input Voltage — Low State	7, 8, 10	V_{IL}	5.0 V 10 V 15 V 20 V	— — — —	— — — —	0.0 1.5 2.5 3.5	V
Input Reverse Current — High State ($V_{\text{in}} = V_{\text{CC}}$)	7, 8, 10	I_{IR}	5.0 V 10 V 15 V 20 V	— — — —	— — — —	2.0 2.0 3.0 5.0	μA
Input Forward Current — Low State ($V_{\text{in}} = \text{Gnd}$)	7, 8, 10	I_{IF}	5.0 V 10 V 15 V 20 V	-10 -23 -40 -55	— — — —	— — — —	μA
Output Voltage — High State ($V_M = 12 \text{ V}$) $I_{\text{out}} = -500 \text{ mA}$ $I_{\text{out}} = -50 \text{ mA}$	1, 3, 14, 16	V_{OH}	5.0 to 20 V	— —	$V_M - 2.0$ $V_M - 1.2$	— —	V
Output Voltage — Low State $I_{\text{out}} = 500 \text{ mA}$ $I_{\text{out}} = 50 \text{ mA}$	1, 3, 14, 16	V_{OL}	5.0 to 20 V	— —	0.7 0.2	— —	V
Output Leakage Current ($V_M = V_D = V_{\text{clamp max}}$) Pin 6: Open	1, 3, 14, 16	I_{OL}	5.0 to 20 V	-100	—	—	μA
Clamp Diode Forward Voltage (Drop at $I_M = 500 \text{ mA}$)	2	V_F	—	—	2.5	3.5	V
Clock Frequency	7	f_c	5.0 to 20 V	0	—	50	kHz
Clock Pulse Width	7	t_w	5.0 to 20 V	10	—	—	μs
Set Pulse Width	6	t_s	—	10	—	—	μs
Set Control Voltage — High State Low State	6	—	—	V_M —	— —	— 0.5	V

INPUT/OUTPUT FUNCTIONS

Jack — (Pin 7) This input is active on the positive edge of the clock pulse and accepts Logic '1' input levels dependant on the supply voltage and includes hysteresis for noise immunity.

CW/CCW — (Pin 10) This input determines the motor's rotational direction. When the input is held low, IOV, see the electrical characteristics) the motor's direction is nominally clockwise (CW). When the input is in the high state, Logic '1', the motor direction will be nominally counter clockwise (CCW), depending on the motor connections.

Full/Half Step — (Pin 8) This input determines the angular rotation of the motor for each clock pulse. In the low state the motor will make a full step for each applied clock pulse, while in the high state, the motor will make half a step.

V_D — (Pin 2) This pin is used to protect the outputs (1, 3, 14, 16) where large positive spikes occur due to switching the motor coils. The maximum allowable voltage on these pins is the clamp voltage (V_{clamp}). Motor performance is improved if a zener diode is connected between Pin 2 and Pin 15 as shown in Figure 1.

The following conditions have to be considered when selecting the zener diode:

$$V_{clamp} = V_M + 6.0 V$$

$$V_Z = V_{clamp} - V_M - V_F$$

where: V_F = clamp diodes forward voltage drop (see Figure 4)

V_{clamp} :

$$\leq 20 V \text{ for SAA1042}$$

$$\leq 30 V \text{ for SAA1042A}$$

Pins 2 and 15 can be linked, in this case $V_Z = 0 V$.

Set/Bias Input — (Pin 6) This input has two functions:

The resistor R_g adapts the drivers to the motor current.

A pulse via the resistor R_g sets the outputs (1, 3, 14, 16) to a defined state.

The resistor R_g can be determined from the graph of Figure 2 according to the motor current and voltage. Smaller values of R_g will increase the power dissipation of the circuit and larger values of R_g may increase the saturation voltage of the driver transistors.

When the "set" function is not used, terminal A of the resistor R_g must be grounded. When the set function is used, terminal A has to be connected to an open-collector (buffer) circuit. Figure 7 shows this configuration. The buffer circuit (off-state) has to sustain the motor voltage V_M . When a pulse is applied via the buffer and the bias resistor R_g :

During the pulse duration, the motor driver transistors are turned off.

tors are turned off.

After elapsing the pulse, the outputs will have defined states.

Figure 6 shows the timing diagram.

Figure 7 illustrates a typical application in which the SAA1042 drives a 12 V stepper motor with a current consumption of 200 mA/coil.

A bias resistor (R_g) of 56 k Ω is chosen according to Figure 2.

The maximum voltage permitted at the output pin is $V_M + 6.0 V$ (see the Maximum Ratings). In this application $V_M = 12 V$, therefore the maximum voltage is 18 V. The outputs are protected by the internal diodes and an external zener connected between Pins 2 and 15.

From Figure 4, it can be seen that the voltage drop across the internal diodes is about 1.7 V at 200 mA. This results in a zener voltage between Pins 2 and 15 of:

$$V_Z = 6.0 V - 1.7 V = 4.3 V.$$

To allow for production tolerances and a safety margin, a 3.9 V zener has been chosen for this example.

The clock is derived from the line frequency which is phase locked by the MC14046B and the MC14024.

The voltage on the clock input, is normally low (Logic '0'). The motor steps on the positive going transition of the clock pulse.

A Logic '0' applied to the Full/Half input, Pin 8, operates the motor in the Full Step mode. A Logic '1' or this input will result in the Half Step mode. The logic level state on the CW/CCW input, Pin 10, and the connection of the motor coils to the outputs determines the rotational direction of the motor.

These two inputs should be biased to a Logic '0' or '1' and not left floating. In the event of non-use, they should be tied to ground or the logic supply line, V_{DD} .

The output drivers can be set to a fixed operating point by use of the Set input and a bias resistor R_g . A positive pulse to this input turns the drivers off and sets the logic state of the outputs.

After the negative going transition of the Set pulse and until the first positive going transition of the clock, the outputs will be:

$$L1 = L3 = \text{high and } L2 = L4 = \text{low.}$$

(See Figure 6, the timing diagram).

The Set input can be driven by a MC14007B or a transistor whose collector resistor is R_g . If the input is not used, the "bottom" of R_g must be grounded.

The total power dissipation of the circuit can be determined from Figures 3 and 5.

$$P_D = 0.9 W + 0.03 W = 0.93 W.$$

This results in a junction to ambient temperature, without a heatsink of:

$$T_J - T_A = 50^\circ C/W \times 0.93 W = 49^\circ C.$$

or a maximum ambient temperature of 76°C. For operation at elevated temperatures a heatsink is required.


FIGURE 2 — BIAS RESISTOR R_B versus MOTOR CURRENT

FIGURE 3 — DRIVE STAGE POWER DISSIPATION




FIGURE 4 — CLAMP DIODE FORWARD CURRENT versus FORWARD VOLTAGE




FIGURE 5 — POWER DISSIPATION versus LOGIC SUPPLY VOLTAGE





FIGURE 6 — TIMING DIAGRAM



REVISIONS			
LTR	DESCRIPTION	CHECK	DATE
A	PILOT RELEASE RELEASED WP 0291	EG	7-27-79
4	INCORPORATED EO WP 0432	EG	2-4-80





20-2235
 2175 E
 C4H Sales
 alt D.H. DALEY
 COLORADO
 91107
 Casadone
 E.I. 1
 P. 1
 FLO3
 E.I. 7

PILOT RELEASE

SUPPLEMENTARY INFORMATION		DR A. BURKE 7-27-79		Dataproducts MOTOR SPECIFICATION, STEPPING MOTOR	
PART USED ON MODEL J30		CHK 30 7-27-79			
NEXT ASSEMBLY		CRG 211/211 11-11-79			
704122-100		APP 111/111 11-11-79			
DATE		SIZE	CODE IDENT NO	DRAWING NO.	
		A	19790	259124-101	

MOTOR CONFIGURATION

35-12 MIN EXPOSED LENGTH,
W/ 22 STRANDED
FIBER INSULATED



DETAIL A (ALTERNATE)
SCALE 1:1

DRAWING NO. 254799-001

VENDOR: SIGMA INSTRUMENTS, INC. - BRAINTREE, MASS. 02134
 MODEL NO: 20-22350200-E1.6 WITH MODIFIED SHAFT

GENERAL SPECIFICATIONS


TYPE: Permanent magnet rotor
 NO. OF PHASES: Two (4 or 8 step switching sequence)
 STEP ANGLE: 1.8°
 ANGULAR ACCURACY: $\pm 3\%$ of one step, no load, after any number of steps $\pm 0.54^\circ$
 AMBIENT OPERATING TEMPERATURE: -20°C to 50°C without heat sink
 MAXIMUM CASE TEMPERATURE: 100°C
 INSULATION: NEHA Class B
 INSULATION RESISTANCE: 1,000 M @ 500VDC $\pm 25^\circ\text{C}$
 DIELECTRIC STRENGTH:
 Between windings and frame: 1,000 Vrms @ 60 Hz
 Between windings: 400 Vrms @ 60 Hz
 THERMAL RESISTANCE (degrees centigrade per watt)
 a. FREE AIR MODE: T80
 b. INFINITE HEATSINK MODE: T80

PERFORMANCE SPECIFICATIONS

ITEM	PARAMETER	VALUE
1		
2	HOLDING TORQUE	120 oz-in
3	DETENT TORQUE	5.0/0.04 oz-in/11m
4	PHASE CURRENT (UNIPOLAR)	2.2 amps
5	PHASE RESISTANCE	1.6 ohms
6	PHASE INDUCTANCE	4.2 mH
7	ROTOR INERTIA	$1.1 \times 10^{-2} \text{ oz-in}^2 / 10^{-3} \text{ kgm}^2$
8	WEIGHT	2.3 lbs (1.04 kg)
9	NUMBER OF LEADS	6 (SEE CONNECTION DIAGRAM FOR COLORS)

DRAWING NO.		REV.
259799-001		1.0
SHEET 1	OF 1	SHEETS

Connection Diagram



FULL-STEP

STEP	A	B	C	D
1	1	0	0	1
2	1	0	1	0
3	0	1	1	0
4	0	1	0	1
5	1	1	0	0

B 0 1 1

HALF-STEP

STEP	A	B	C	D
1	1	0	0	1
2	1	0	0	0
3	1	0	1	0
4	0	0	1	0
5	0	1	1	0
6	0	1	0	0
7	0	1	0	1
8	0	0	0	1
9	1	1	0	0

250 @ 1.5A/winding

DRAWING NO.
259779-001


REV.



LARGE SIGMA STEPPING MOTOR, #21-4270D-28408, equivalent to Sigma P/N 21-4270D-200 FO3. Permanent magnet rotor. 8 leads. Torque @ 50 PPS - 1000 oz/in. Holding torque 1150 oz/in. Detent torque 22 oz/in. Current per phase 7.6 amps. Nominal phase resistance .3 ohm. Two phase. 1.8° steps. 200 steps per revolution. Any voltage from 3 to 80 VDC can be used with the appropriate external limiting resistor. Can be used with unipolar or bipolar type drive. Dimensions: 4.2" diameter x 7.0" long. Shaft: .624" diameter x 2.3" long. Front mounting flange 4.375" square with 4 mounting holes. Comes complete with specification sheets and wiring diagrams.

CONNECTION DIAGRAM FOR SIGMA STEPPER MOTOR
P/N 21-4270D-200F03

TERMINAL 1	BLACK
TERMINAL 6	BLACK/WHITE
TERMINAL 2	RED
TERMINAL 8	RED/WHITE
TERMINAL 3	ORANGE
TERMINAL 5	ORANGE/WHITE
TERMINAL 4	YELLOW
TERMINAL 7	YELLOW/WHITE



MODEL 76

LOW COST, OPTICAL ABSOLUTE, SHAFT POSITION ENCODER

FEATURES

- Choice of 3 Code Formats
- Solid State Illumination Source
- Simple Design • High Reliability
- Choice of 10 Resolutions
- DTL and TTL Compatible Outputs
- 2 Mounting Configurations
- 2 Shaft Sizes

APPLICATIONS

- NC Machine Tools
- Computing Scales
- Process Control
- Divider Heads
- Plotters • Printers
- Antennas
- Navigation Systems

MODEL 76 has been engineered to provide the potential user the maximum flexibility in selecting the physical and electrical characteristics dictated by the application. There is the choice of two mounting configurations with the input/output connector mounted on the end or side of the housing. Two input shaft styles, three code formats to choose from—Gray Code, Natural Binary and 8421 Binary Coded Decimal—and 10 standard resolutions. Resolutions up to 10 bits in Gray or Natural Binary and several resolutions in BCD available (example 180 and 360).

MODEL 76 only requires a single 5 VDC power supply for operation. The outputs are fully buffered to provide direct DTL and TTL compatibility.

PHYSICAL CHARACTERISTIC OPTIONS




FIGURE 1




FIGURE 2




FIGURE 3




FIGURE 4

USE THIS BLOCK DIAGRAM

TO ORDER

Standard options available are illustrated by the block nomenclature diagram below. When ordering, indicate options desired by completing Model Number with Designation from options Tables.

76



TABLES OF OPTIONS

TABLE I

CODE FORMAT OPTIONS	
FORMAT	DESIGNATION
Gray Code	GC
NATURAL BINARY	NB
	8421 BCD
	80

TABLE II

RESOLUTION OPTIONS	
These resolutions are available with Gray Code and Natural Binary Models	
RESOLUTION	DESIGNATION
64	06
128	07
256	08
512	09
1024	10

TABLE III

RESOLUTION OPTIONS	
These resolutions are available with 8421 BCD Models	
RESOLUTION	DESIGNATION
100	100
200	101
300	102
360	103
400	104
450	105
1000	1000

TABLE IV

MOUNTING CONFIGURATION OPTIONS	
CONFIGURATION	DESIGNATION
Per Fig. 1	1
Per Fig. 2	2
Per Fig. 1 with Shaft Seal	4
Per Fig. 2 with Shaft Seal	5

TABLE V

CONNECTOR LOCATION OPTIONS	
CONFIGURATION	DESIGNATION
At End of Housing	E
On Side of Housing	S

ADDITIONAL OPTIONS

The following non-standard options are available on Special Order:

- Line Drivers Outputs
- Serialized Outputs
- Extra Low Torque Bearings
- Other Shaft Configurations
- Special Code Formats
- Other Resolutions

MODEL 76

CONTINUED

GENERAL SPECIFICATIONS

MECHANICAL

PHYSICAL CHARACTERISTICS

Per Fig. 1 with optional mounting configurations per Fig. 2 or 3

WEIGHT

20 oz. maximum

MOMENT OF INERTIA

.0001 oz. in. sec.²

SHAFT LOADING

Standard Shaft: 30 lbs. maximum
Heavy Duty Shaft: 70 lbs. maximum

SHAFT ROTATION

Continuous and reversible, CW

Rotation viewing shaft end produces ascending count

ANGULAR ACCELERATION

10°/rad/sec. maximum

SLEWING SPEED

5000 RPM maximum (See note 1)

BEARING LIFE

16 x 10⁶ RPM

16 x 10⁶ hrs. minimum

STARTING TORQUE (See Note 3)

Standard Shaft — No Seal: 1.0 oz. in. max

Standard Shaft — With Seal: 1.5 oz. in. max

Heavy Duty Shaft: 8.0 oz. in. max

ELECTRICAL

CODE FORMAT

Optional — Gray Code, Natural Binary or 8421 Binary

Coded Octal

RESOLUTION

Optional — See Tables II and III

INPUT

5.0 ± 2% VCC at 300 mA maximum

OUTPUT LOGIC LEVELS

Logic 1: Vcc with 4.7 K max Ohm "source" impedance

Logic 0: 0.5 VCC max with 10 mA "sink" current (DC)

0.5 VCC max with 10 mA "sink" current (NB & BO)

ILLUMINATION SOURCE

Typical 1000 lux (100 foot candles)

Useful life: 5 years minimum

OPERATING SPEED (See Note 2)

1.2K CTS/sec. x 60 = RPM maximum

Counts per 360°

ENVIRONMENTAL

TEMPERATURE

Operating: 0°C to +71°C

Storage: -25°C to +85°C

VIBRATION

5 to 2000 Hz at 20 G's

20 to 5000 Hz at 5 G's

50 G's for 11 MS duration

NOTES:

1. Stowage speed is the maximum rate to which the encoder may be subjected without permanent degradation of performance.
2. Operating speed is the maximum rate at which the encoder may be read, where read rate is 1 full accuracy, 2 in 1 data's, where operating speed calculates to a higher rate than for a 1000 cps.
3. Operating speed is the maximum rate at which the encoder may be read, where read rate is 1 full accuracy, 2 in 1 data's, where operating speed calculates to a higher rate than for a 1000 cps.
4. Heavy duty, wet-on-oils, larger bearing bearings, and shaft per Fig. 4.
5. For count direction select, use configuration shown. Control is on Pin 4. For CTS increasing count, connect Pin 4 to ground. For CTS decreasing count, connect Pin 4 to +5.0 VCC.

INPUT/OUTPUT CONNECTIONS

CONDUCTOR		GRAY CODE		NATURAL BINARY		CONDUCTOR		GRAY CODE		NATURAL BINARY	
PIN NO	OUTPUT	PIN NO	OUTPUT	PIN NO	OUTPUT	PIN NO	OUTPUT	PIN NO	OUTPUT	PIN NO	OUTPUT
A	G0	2 ⁰	1	K	G9	2 ⁹	20	L	—	—	—
B	G1	2 ¹	2	M	—	—	21	N	—	—	—
C	G2	2 ²	4	O	—	—	22	P	—	—	—
D	G3	2 ³	8	Q	—	—	23	R	—	—	—
E	G4	2 ⁴	16	S	—	—	24	T	—	—	—
F	G5	2 ⁵	32	U	—	—	25	V	—	—	—
G	G6	2 ⁶	64	W	—	—	26	X	—	—	—
H	G7	2 ⁷	128	Y	—	—	27	Z	—	—	—
J	H0	2 ⁸	256		—	—	28	AA	—	—	—
					—	—	29	AB	—	—	—
					—	—	30	AC	—	—	—
					—	—	31	AD	—	—	—
					—	—	32	AE	—	—	—
					—	—	33	AF	—	—	—
					—	—	34	AG	—	—	—
					—	—	35	AH	—	—	—
					—	—	36	AI	—	—	—
					—	—	37	AJ	—	—	—
					—	—	38	AK	—	—	—
					—	—	39	AL	—	—	—
					—	—	40	AM	—	—	—
					—	—	41	AN	—	—	—
					—	—	42	AO	—	—	—
					—	—	43	AP	—	—	—
					—	—	44	AQ	—	—	—
					—	—	45	AR	—	—	—
					—	—	46	AS	—	—	—
					—	—	47	AT	—	—	—
					—	—	48	AU	—	—	—
					—	—	49	AV	—	—	—
					—	—	50	AW	—	—	—
					—	—	51	AX	—	—	—
					—	—	52	AY	—	—	—
					—	—	53	AZ	—	—	—
					—	—	54	BA	—	—	—
					—	—	55	BB	—	—	—
					—	—	56	BC	—	—	—
					—	—	57	BD	—	—	—
					—	—	58	BE	—	—	—
					—	—	59	BF	—	—	—
					—	—	60	BG	—	—	—
					—	—	61	BH	—	—	—
					—	—	62	BI	—	—	—
					—	—	63	BJ	—	—	—
					—	—	64	BK	—	—	—
					—	—	65	BL	—	—	—
					—	—	66	BM	—	—	—
					—	—	67	BN	—	—	—
					—	—	68	BO	—	—	—
					—	—	69	BP	—	—	—
					—	—	70	BQ	—	—	—
					—	—	71	BR	—	—	—
					—	—	72	BS	—	—	—
					—	—	73	BT	—	—	—
					—	—	74	BU	—	—	—
					—	—	75	BV	—	—	—
					—	—	76	BW	—	—	—
					—	—	77	BX	—	—	—
					—	—	78	BY	—	—	—
					—	—	79	BZ	—	—	—
					—	—	80	CA	—	—	—
					—	—	81	CB	—	—	—
					—	—	82	CC	—	—	—
					—	—	83	CD	—	—	—
					—	—	84	CE	—	—	—
					—	—	85	CF	—	—	—
					—	—	86	CG	—	—	—
					—	—	87	CH	—	—	—
					—	—	88	CI	—	—	—
					—	—	89	CJ	—	—	—
					—	—	90	CK	—	—	—
					—	—	91	CL	—	—	—
					—	—	92	CM	—	—	—
					—	—	93	CN	—	—	—
					—	—	94	CO	—	—	—
					—	—	95	CP	—	—	—
					—	—	96	CQ	—	—	—
					—	—	97	CR	—	—	—
					—	—	98	CS	—	—	—
					—	—	99	CT	—	—	—
					—	—	100	CU	—	—	—
					—	—	101	CV	—	—	—
					—	—	102	CW	—	—	—
					—	—	103	CX	—	—	—
					—	—	104	CY	—	—	—
					—	—	105	CZ	—	—	—
					—	—	106	DA	—	—	—
					—	—	107	DB	—	—	—
					—	—	108	DC	—	—	—
					—	—	109	DD	—	—	—
					—	—	110	DE	—	—	—
					—	—	111	DF	—	—	—
					—	—	112	DG	—	—	—
					—	—	113	DH	—	—	—
					—	—	114	DI	—	—	—
					—	—	115	DJ	—	—	—
					—	—	116	DK	—	—	—
					—	—	117	DL	—	—	—
					—	—	118	DM	—	—	—
					—	—	119	DN	—	—	—
					—	—	120	DO	—	—	—
					—	—	121	DP	—	—	—
					—	—	122	DQ	—	—	—
					—	—	123	DR	—	—	—
					—	—	124	DS	—	—	—
					—	—	125	DT	—	—	—
					—	—	126	DU	—	—	—
					—	—	127	DV	—	—	—
					—	—	128	DW	—	—	—
					—	—	129	DX	—	—	—
					—	—	130	DY	—	—	—
					—	—	131	DZ	—	—	—
					—	—	132	EA	—	—	—
					—	—	133	EB	—	—	—
					—	—	134	EC	—	—	—
					—	—	135	ED	—	—	—
					—	—	136	EE	—	—	—
					—	—	137	EF	—	—	—
					—	—	138	EG	—	—	—
					—	—	139	EH	—	—	—
					—	—	140	EI	—	—	—
					—	—	141	EJ	—	—	—
					—	—	142	EK	—	—	—
					—	—	143	EL	—	—	—
					—	—	144	EM	—	—	—
					—	—	145	EN	—	—	—
					—	—	146	EO	—	—	—
					—	—	147	EP	—	—	—
					—	—	148	EQ	—	—	—
					—	—	149	ER	—	—	—
					—	—	150	ES	—	—	—
					—	—	151	ET	—	—	—
					—	—	152	EU	—	—	—
					—	—	153	EV	—	—	—
					—	—	154	EW	—	—	—
					—	—	155	EX	—	—	—
					—	—	156	EY	—	—	—
					—	—	157	EZ	—	—	—
					—	—	158	FA	—	—	—
					—	—	159	FB	—	—	—
					—	—	160	FC	—	—	—
					—	—	161	FD	—	—	—
					—	—	162	FE	—	—	—
					—	—	163	FF	—	—	—
					—	—	164	FG	—	—	—
					—	—	165	FH	—	—	—
					—	—	166	FI	—	—	—
					—	—	167	FJ	—	—	—
					—	—	168	FK	—	—	—
					—	—	169	FL	—	—	—
					—	—	170	FM	—	—	—
					—	—	171	FN	—	—	—
					—	—	172	FO	—	—	—
					—	—	173	FP	—	—	—
					—	—	174	FQ	—	—	—
					—	—	175	FR	—	—	—
					—	—	176	FS	—	—	—
					—	—	177	FT	—	—	—
					—	—	178	FU	—	—	—
					—	—	179	FV	—	—	—
					—	—	180	FW	—	—	—
					—	—	181	FX	—	—	—
					—	—	182	FY	—	—	—
					—	—	183	FZ	—	—	—
					—	—	184	GA	—	—	—
					—	—	185	GB	—	—	—
					—	—	186	GC	—	—	—
					—	—	187	GD	—	—	—
					—	—	188	GE	—	—	—
					—	—	189	GF	—	—	—
					—	—	190	GH	—	—	—
					—	—	191	GI	—	—	—
					—	—	192	GJ	—	—	—
					—	—	193	GK	—	—	—
					—	—	194	GL	—	—	—
					—	—	195	GM	—	—	—
					—	—	196	GN	—	—	—
					—	—	197	GO	—	—	—
					—	—	198	GP	—	—	—

BEI Industrial Encoder Division
 BEI MOTION SYSTEMS COMPANY
 7230 Hollister Avenue • Goleta, California 93117-2891


Specification

924 - 02004 - 001

General Specifications

Type L25

Incremental Optical Encoder



ACTUAL SIZE

Notice: The design and specifications of the instruments and accessories illustrated and described in this publication are subject to improvement without notice.

E	Per ECN 1831		PREP BY D. McGuire 8/18/77
D	Per ECN 1613	1-17-83	CHK D. LaPlante
C	Updated per ECN 1372		APPD Jerry E. Jandt
REV	DESCRIPTION	DATE	1979 BEI Electronics, Inc.

02004-001

SHEET 1 of 1
REV D

BEI Industrial Encoder Division
 BEI MOTION SYSTEMS COMPANY
 7230 Hollister Avenue • Goleta, California 93117-2891

TITLE General Specifications Type L25 Incremental Optical Encoder	NO. D2004-D01 Sht <u>2</u>	Rev D
<p style="text-align: center;"><u>SPECIFICATIONS</u></p> <p>1.0 Scope: This specification describes the BEI Industrial Encoder Division Low Torque, Instrument Grade Type L25 Incremental Optical Encoder.</p> <p>2.0 <u>Mechanical Specifications</u></p> <p>2.1 Dimensions See Figure 2</p> <p>2.2 Shaft Diameter .2497/.2495 Dia.</p> <p>2.3 Optional Flat on Shaft .50 long X .03 deep</p> <p>2.4 Shaft Loading Up to 5 lbs Axial and 8 lbs Radial</p> <p>2.5 Shaft Runout .0005 T.I.R. Max.</p> <p>2.6 Starting Torque at 25°C 0.07 Oz. -In. Max.</p> <p>2.7 Starting Torque at 25°C (With optional sealed bearings) 1.0 Oz. -In. Max.</p> <p>2.8 Bearings Class ABEC 7</p> <p>2.9 Shaft 416 Stainless Steel</p> <p>2.10 Housing Die Cast Aluminum</p> <p>2.11 Cover Drawn Aluminum, .060" Wall</p> <p>2.12 Bearing Life (mfr's specifications) 1×10^9 Revs at rated shaft loading</p> <p>2.13 Moment of Inertia 4.1×10^{-4} Oz. In. Sec.²</p> <p>2.14 Slew Speed 5000 RPM Max.</p> <p>2.15 Weight 13 Oz. Typ.</p>		


Industrial Encoder Division

BEI MOTION SYSTEMS COMPANY


7230 Hollister Avenue • Goleta, California 93117-2891

TITLE		NO.		Rev	
General Specifications Type L2S Incremental Optical Encoder		02004-001		D	
		Sht 3			
3.0	<u>Electrical Specifications</u>				
3.1	Code	Incremental			
3.2	Counts Per Shaft Turn	1 to 2S40			
3.3	Supply Voltage	See Table I			
3.4	Current Requirements	TTL 200 Ma Max, 150 Ma Typ CMOS 150 Ma Max, 12S Ma Typ			
3.5	Output Format	2 Channels (A and B) in quadrature $\pm 27^{\circ}$ electrical at 10 Khz See Figure 1			
3.6	Output Format Options	Index and Complementary outputs are available			
3.7	Output Options	See Table I			
TABLE I					
<u>I.C. Number</u>	<u>Type</u>	<u>Feature</u>	<u>Optional Pull-up Resistor</u>	<u>Output</u>	<u>Supply Voltage + 5V</u>
SN7404	T ² L	Totem Pole		16 MA/SV	+5 VDC
SN7406	T ² L	Open Col- lector Hi-Voltage	470 Ohms	40 MA/30V	+S VDC
SN74C04	CMOS				S to 1S VDC*
MC680	HTL	Totem Pole			1S VDC
MC681	HTL	Open Col- lector	1SK Ohms		1S VDC
MC689	HTL	Open Col- lector Hi-Voltage	1SK Ohms	20V	1S VDC
OM8830	T ² L	Line Driver			S VDC
MM88C30	CMOS	Line Driver			S to 1S VDC*
*Specify actual Voltage					

BEI Industrial Encoder Division
 BEI MOTION SYSTEMS COMPANY
 7230 Hollister Avenue • Goleta, California 93117-2891

TITLE	General Specifications Type L25 Incremental Optical Encoder		NO.	Rev
			02004-001 Sht 4	0
3.8	Illumination	Incandescent Lamp (40,000 hours life) LEO, Optional (Index up to 1270 CPT only)		
3.9	Frequency Response (Channels A and B)	100 kHz		
3.10	Frequency Response (Index)	100 kHz		
4.0	<u>Environmental Specifications</u>			
4.1	Temperature			
	Operating	0 to 70°C Standard		
	Storage	-25 to 90°C		
4.2	Shock	50 G's for 11 MSEC duration		
4.3	Vibration	5 to 2000 HZ @ 20 G's		
4.4	Humidity	98% RH without condensation		
5.0	<u>Options - For the following option capabilities, consult factory for complete specifications.</u>			
5.1	Direction Sensing	Pulse Output X1, X2 or X4		
5.2	Interpolation	Multiplied squarewave output X5		
5.3	Dual Resolution	Selectable Output		
5.4	Sinewave	Differential amplified outputs		

BEI Industrial Encoder Division
 BEI MOTION SYSTEMS COMPANY
 7230 Hollister Avenue • Goleta, California 93117-2891



BEI Industrial Encoder Division
 BEI MOTION SYSTEMS COMPANY
 7230 Hollister Avenue • Goleta, California 93117-2891





FIGURE 2 - DIMENSIONS


TITLE	General Specifications Type L25 Incremental Optical Encoder		NO.	Rev
			02004-001 Sht <u>7</u>	0

FIGURE 3
Face Mount Options




F1

10-32 UNF-28
.188 Min. Deep
3 places equally spaced on a
1.875 Dia. bolt circle.




F2

4-40 UNC-28
.250 Min. Deep
4 places equally spaced
on a 1.272 Dia. bolt circle
(.900 square, Ref)



F3

4-40 UNC-28
.250 Min. deep
4 places equally spaced
on a 2.000 Dia. bolt circle



F4

6-32 UNC-28
.250 Min. deep
3 places equally spaced
on a 2.000 Dia. bolt circle

TITLE General Specifications Type L25 Incremental Optical Encoder				NO. 02004-001		Rev D	
TABLE II OUTPUT TERMINATIONS							
MS3102E-16S-1P					MS3102E-18-1P		
Output Option		Channels A, B and Z		Ch. A & B with Complements	Ch. A & Z with Complements	Pin	Ch. A,B & Z with Complements
Pin	A	Channel	A	A	A	A	A
	B		B	B	\bar{A}	B	B
	C		Z	\bar{A}	Z	C	Z
	D		+V	+V	+V	D	+V
	E		No Conn.	\bar{B}	\bar{Z}	E	No Conn.
	F		Ground	Ground	Ground	F	Ground
	G		Case Ground	Case Ground	Case Ground	G	Case Ground
						H	\bar{A}
						I	\bar{B}
						J	\bar{Z}
WIRE OR 0A15P CONNECTOR TERMINATION							
Function		Wire Color		0A15P Pin Number			
Channel	A	Yellow		13			
	B	Blue		14			
	Z	Orange		15			
	\bar{A}	White-Yellow		10			
	\bar{B}	White-Blue		11			
	\bar{Z}	White-Orange		12			
	+5V	Red		6			
	Ground	Black		1			
	Case Ground	Green		9			


Industrial Encoder Division

BEI MOTION SYSTEMS COMPANY

7230 Hollister Avenue • Goleta, California 93117-2891

TITLE		NO.	Rev
General Specifications		D2004-001	
Type L25		Sht 9	D
Incremental Optical Encoder			

6.0 Ordering Information: Encoder may be specified using the following model numbering system:

TYPE: _____
 L = Light Duty

BASIC SIZE: _____
 25 = 2.500

HOUSING CONFIGURATION LETTER: _____
 G = 2.62 Dia Servo Mount (Fig. 2)

FACE MOUNT OPTIONS (Fig. 3) _____
 F1, F2 or F3
 Blank = None

SHAFT SEAL CONFIGURATION: _____
 SB = Seal Integral with Bearing
 Blank = Shielded Bearing

CYCLES PER TURN: _____
 Enter Cycles:
 500 = 500 cycles
 2500 = 2500 cycles
 Etc.

NO. OF CHANNELS: _____
 A = Single Channel
 AB = Dual Quadrature Channels
 ABZ = Dual with Index
 AZ = Single with Index

COMPLEMENTS: _____
 C = Complementary Outputs
 Blank = None

OUTPUT I.C. _____
 7406, 8830, 7404, 88C30, etc (See Table I)
 Followed by "R" = Pull-up Resistor

ILLUMINATION: _____
 Blank = Incandescent (Standard)
 LED = Light Emitting Diode (Optional)

OUTPUT TERMINATION LOCATION: _____
 E = End
 S = Side (Pigtail only)

OUTPUT TERMINATION: _____
 M16 = MS3102E16S-IP Connector
 M18 = MS3102E18-IP Connector
 D15 = DA15P
 C = Pigtail cable followed by length, i.e.
 C18 = Pigtail cable 18" long

S = Special Non-Standard Features _____
 Specified on purchase order or customer's spec

DEVELOPMENT OF DATA ACQUISITION AND CONTROL
FACILITIES FOR THE OPTIMIZATION OF
DRIVE LINE EFFICIENCY

by

KENT DOUGLAS FUNK

B.S., KANSAS STATE UNIVERSITY, 1984

AN ABSTRACT OF A MASTER'S THESIS

submitted in partial fulfillment of the
requirements for the degree

MASTER OF SCIENCE

Department of Mechanical Engineering

KANSAS STATE UNIVERSITY
Manhattan, Kansas

1986

ABSTRACT

Due to escalating fuel costs and increased capital costs associated with operating and owning agricultural tractors, considerable research has been conducted to improve the fuel efficiency and work rate of these units. The primary focus of this research has been to accurately define field load variations and to optimize engine power utilization. The potential savings from tractor performance optimization depends upon several factors; load variability, power level, engine characteristics, transmission characteristics, and tractive efficiency.

A review of previous engine optimization work has identified several limitations which may lead to non-optimal solutions. These limitations can be reduced by: using closed loop drive line controls, a transmission which has a large number of discrete ratios or a continuously variable transmission, and developing optimization algorithms which consider the entire drive line rather than focusing only on the engine.

A joint study of Computer Control of Agricultural Tractor Drive Lines was initiated in April, 1984, between the Agricultural Engineering and Mechanical Engineering Departments at Kansas State University. The objective of this effort is to develop and test a computer control system for optimizing the performance of a diesel engine and a continuously variable transmission as applied in an agricultural tractor. One of the primary tasks of this study is to develop laboratory facilities in order

to study drive line efficiency.

In order to fulfill the project's computer needs, two systems were developed. One system uses an ADAC 1000 data acquisition computer and is responsible for the supervisory functions, data recording, sub-system controls, and conversion of all analog data into digital forms. The other system uses a Motorola MC68000ECB single board computer and is responsible for drive line control and optimization.

The work completed on the ADAC 1000 falls into two main categories; a complete system upgrade, and development of a large software package. The structure of the software package is based upon concepts used in concurrent programming in order to preserve real time capabilities.

The work completed on the MC68000ECB includes both hardware and software developments. The hardware developments include bus expansion buffering, I/O expansion, optical isolation, and digital interfacing to numerous external devices. The software developed provides the framework for all future developments. Currently, the software executes a fully interactive environment which is useful for drive line mapping.

This project is on-going with the test facility completed, performance data collected, and a basic optimization algorithm outlined. Plans for future work include: analyzing the collected data to establish relationships between control inputs and drive line outputs, and developing a computer simulation of the optimization algorithm in order to evaluate dynamic and performance considerations.